Section 1 pre-assignment

1. Pick up your kit.

In this pre-assignment you will connect your arduino and confirm that you can communicate with it. We will then explore some very basic i/o capabilities with the Arduino.

```
2. Download and install the Arduino software from https://www.arduino.cc/
     en/Main/Software.
  3. Connect your Arduino to your computer.
  4. Copy and past the blink program
 Blink
  Turns an LED on for one second, then off for one second, repeatedly.
 Most Arduinos have an on-board LED you can control. On the UNO, MEGA and ZERO
  it is attached to digital pin 13, on MKR1000 on pin 6. LED_BUILTIN is set to
  the correct LED pin independent of which board is used.
  If you want to know what pin the on-board LED is connected to on your Arduino
  model, check the Technical Specs of your board at:
  https://www.arduino.cc/en/Main/Products
  modified 8 May 2014
  by Scott Fitzgerald
  modified 2 Sep 2016
  by Arturo Guadalupi
  modified 8 Sep 2016
  by Colby Newman
  This example code is in the public domain.
 http://www.arduino.cc/en/Tutorial/Blink
// the setup function runs once when you press reset or power the board
void setup() {
  // initialize digital pin LED_BUILTIN as an output.
 pinMode(LED_BUILTIN, OUTPUT);
}
// the loop function runs over and over again forever
void loop() {
  digitalWrite(LED_BUILTIN, HIGH); // turn the LED on (HIGH is the voltage level)
```