

Assembly Instructions: Aura Smart LED Nightstand (Model NS-20)

Document Overview

This manual guides you through the assembly and electrical connection of the Aura Smart LED Nightstand.

! IMPORTANT: Assemble this item on a clean, carpeted, or padded surface to prevent scratching the premium wood finish. Do not use power tools for assembly, as they can strip the pre-drilled pilot holes.

Specifications & Requirements

Estimated Time

- Assembly:** 30–40 minutes
- Difficulty:** Medium (1 person required, 2 recommended for lifting)

Tools Required

- Phillips-head Screwdriver (Not included)
- Flat-head Screwdriver (Not included)

Hardware Components

Verify all components are present before discarding any packaging.

Item	Component Name	Qty
H1	Cam Lock Bolt	8
H2	Cam Lock Nut	8
H3	Wood Dowel	6
H4	M6x30mm Leg Screws	4
E1	LED Light Strip (Pre-installed on Back Panel)	1
E2	AC Power Adapter	1

Structural Parts Diagram

- P1:** Top Panel (with wireless charging pad)
- P2:** Left Side Panel
- P3:** Right Side Panel
- P4:** Bottom Shelf

- **P5:** Back Panel (with LED track)
- **P6:** Solid Wood Legs (x4)

Assembly Steps

Step 1: Prep the Side Panels

1. Lay the **Left Side Panel (P2)** and **Right Side Panel (P3)** flat on your work surface with the pre-drilled holes facing upward.
2. Screw four **Cam Lock Bolts (H1)** into the designated outer holes on each panel using a Phillips-head screwdriver. Tighten until the threading is no longer visible.
3. Insert three **Wood Dowels (H3)** into the center alignment holes on **Panel (P2)**. Repeat for **Panel (P3)**.

Step 2: Connect the Bottom Shelf and Side Panels

1. Align the **Wood Dowels (H3)** on the **Left Side Panel (P2)** with the matching holes on the side of the **Bottom Shelf (P4)**.
2. Press the pieces firmly together until the seam is flush.
3. Insert two **Cam Lock Nuts (H2)** into the large circular housings on the underside of **Panel (P4)**.
4. Use a flat-head screwdriver to turn the nuts clockwise (180°) to lock the panels securely together.
5. Repeat this process to attach the **Right Side Panel (P3)** to the opposite side of the shelf.

Step 3: Slide in the Back Panel

1. Locate the guide channels routed along the inside back edges of the assembled frame.
2. Orient the **Back Panel (P5)** so the attached **LED Light Strip (E1)** faces inward toward the front of the unit.
3. Slide **Panel (P5)** down into the guide channels until it rests flush against the bottom shelf.
4. Route the integrated LED power cable through the cut-out slot at the bottom corner of the back panel.

Step 4: Attach the Top Panel

1. Lower the **Top Panel (P1)** onto the top edges of the side and back panels, ensuring the remaining **Cam Lock Bolts (H1)** seat cleanly into the top holes.
2. Insert the remaining four **Cam Lock Nuts (H2)** into the top interior corners of the side panels.
3. Rotate the nuts clockwise to lock the top panel into place.

Step 5: Install the Legs and Power Connection

1. Carefully flip the assembled nightstand upside down.
2. Align the mounting bracket of each **Solid Wood Leg (P6)** with the four corner holes on the underside of the unit.
3. Secure each leg tightly using the **M6x30mm Leg Screws (H4)** and a Phillips-head screwdriver.
4. Flip the unit upright. Connect the **AC Power Adapter (E2)** to the LED cable extending from the back panel, then plug it into a standard wall outlet.