

- In case that extension material is longer than 300mm
- Join an extension material and a chassis frame by butt welding, and then fit a reinforcement on the outer side of them.

Installing extension material (2)

