

- 4 Precautions at fixing with double-ended brackets
 - For fixing of the rear body, the use of U-bolt is most recommended. Note the following when using the double-ended brackets due to various restrictions. Only fix with bolts on chassis frame. Do not weld.
 - •Follow "3-1 DRILLING OR WELDING A CHASSIS FRAME" for hole location, etc.
 - •For the location of fixing, follow "4-4 ② Fixing prohibited areas" and do not drill holes or weld in that area.
 - Use fastening bolt vertically as shown in below figure.

