

- (5) Pipes, cables, and wire harness
 - Maintain the following clearance.

Between rear body and movable (engine, mission, etc.) wire harness and piping	40mm or more (most approached)
Between rear body and half fixed wiring and piping (wire harnesses cables, fuel piping)	10mm or more from most approached position
Between rear body and fixed wire harnesses and piping	battery cables: 15mm or more other wire harnesses: 10mm or more

Note: When above condition is difficult to be satisfied, clip fix to avoid contact with rear body.

• Corrosion of pipes and cables promotes on tank truck, vacuum truck, etc. due to water and dew condensation at low-temperature part. Place protection board or keep pipes, cables and wires away from water dripping or dew condensation part.

6 Cab

•When the vehicle is moving, the whole cab moves in various directions. Also, when a cab tilts, rear body may contact with the cab or cab chassis components such as an air inlet duct attached to the cab. Taking these into account, provide sufficient clearances between them as shown below to prevent the cab from contacting with anything.

Clearance of cab

