

③ Precautions at fixing with U-bolts

• When using U-bolts to fix a sub frame on the channel-shaped side member, be sure to use the following reinforcement for preventing chassis frame and sub frame flange deformation.

Installing of reinforcement Wooden reinforcement Sub frame Pipes, harnesses, and wires Reinforcement Chassis frame 10mm or more side member U-bolt Steel reinforcement Sub frame Pipes, harnesses, and wires Reinforcement Chassis frame 10mmor more side member U-bolt

