

5-3 POWER SUPPLY FOR REAR BODY

There is no service terminal for this vehicle. If installing additional equipments, refer to the following.

- 1 Precautions for connecting of additional equipments
 - When adding any other equipments or using a large-load equipment for a short time within the capacity of the power generator,
 - Connect such equipments directly to the battery as instructed under "3-6 ② How to extract power from the positive battery terminal".
 - When installing additional equipments always follow the instructions in this guide because failure to follow these instructions will impair the functions of the vehicle and cause serious problems such as vehicle fire.