avrSerial

Generated by Doxygen 1.8.3.1

Sun Apr 28 2013 15:55:39

# **Contents**

1	Maiı	n Page			1
2	Mod	lule Inde	ex		3
	2.1	Module	es		3
3	File	Index			5
	3.1	File Lis	st		5
4	Mod	lule Doo	cumentatio	on	7
	4.1	UART	Library .		7
		4.1.1	Detailed	Description	8
		4.1.2	Macro De	efinition Documentation	8
			4.1.2.1	BAUD	8
			4.1.2.2	FLOWCONTROL	8
			4.1.2.3	FLOWMARK	8
			4.1.2.4	RX_BUFFER_SIZE	9
			4.1.2.5	TX_BUFFER_SIZE	9
			4.1.2.6	XOFF	9
			4.1.2.7	XON	9
		4.1.3	Function	Documentation	9
			4.1.3.1	serialAvailable	9
			4.1.3.2	serialClose	9
			4.1.3.3	serialGet	10
			4.1.3.4	serialGetBlocking	11
			4.1.3.5	serialHasChar	11
			4.1.3.6	serialInit	11
			4.1.3.7	serialRxBufferEmpty	12
			4.1.3.8	serialRxBufferFull	12
			4.1.3.9	serialTxBufferEmpty	13
			4.1.3.10	serialTxBufferFull	13
			4.1.3.11	serialWrite	14
			4.1.3.12	serialWriteString	14

ii CONTENTS

 15
17
 17
 18
 18
 19
 19
 19
21
 21
22

## Main Page

This is a serial library for many different Atmel AVR MCUs. It is using two FIFO Buffers per USART module for interrupt driven UART communication. XON/XOFF Flow control for incoming data can be enabled for all UART modules, it will operate independently for each.

Device-specific configuration is in serial\_device.h. You should be able to easily add new AVR MCUs. Just get the relevant register and bit names from the data-sheet.

A small test application is included. It will be built when calling either of these commands

```
make all
make test.hex
```

You can also flash it with

```
make program
```

just adjust your programmer type and port in the makefile.

For normal use, either include serial.c, serial.h and serial\_device.h in your project, or build a statically-linked library by calling

```
make lib
```

and linking this to your project, as well as including serial.h.

The current Doxygen Documentation can be found in doc/ and on the web or as PDF...

## License

Everything is released under a BSD 2-Clause License.

Copyright (c) 2012, Thomas Buck All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE

2 Main Page

ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

# **Module Index**

2.1	Modules
Here i	s a list of all modules:
114	ART Library

**Module Index** 

# File Index

## 3.1 File List

Here is a list of all documented files with brief descriptions:

test.c .		??
	UART Library device-specific configuration	19
serial_de		
	UART Library Header File	18
serial.h		
	UART Library Implementation	17
serial.c		

6 File Index

## **Module Documentation**

## 4.1 UART Library

UART Library enabling you to control all available UART Modules.

## **Files**

· file serial.c

UART Library Implementation.

· file serial.h

UART Library Header File.

· file serial\_device.h

UART Library device-specific configuration.

#### **Macros**

• #define RX\_BUFFER\_SIZE 32

If you define this, a '\r' (CR) will be put in front of a '\n' (LF) when sending a byte.

• #define TX\_BUFFER\_SIZE 16

TX Buffer Size in Bytes (Power of 2)

• #define FLOWCONTROL

Defining this enables incoming XON XOFF (sends XOFF if rx buff is full)

• #define FLOWMARK 5

Space remaining to trigger xoff/xon.

• #define XON 0x11

XON Value.

#define XOFF 0x13

XOFF Value.

• #define BAUD(baudRate, xtalCpu) ((xtalCpu)/((baudRate)\*16l)-1)

Calculate Baudrate Register Value.

## **Functions**

• uint8\_t serialAvailable (void)

Get number of available UART modules.

• void serialInit (uint8\_t uart, uint16\_t baud)

Initialize the UART Hardware.

void serialClose (uint8 t uart)

Stop the UART Hardware.

void setFlow (uint8 t uart, uint8 t on)

Manually change the flow control.

uint8\_t serialHasChar (uint8\_t uart)

Check if a byte was received.

uint8\_t serialGetBlocking (uint8\_t uart)

Wait until a character is received.

• uint8 t serialGet (uint8 t uart)

Read a single byte.

uint8\_t serialRxBufferFull (uint8\_t uart)

Check if the receive buffer is full.

uint8\_t serialRxBufferEmpty (uint8\_t uart)

Check if the receive buffer is empty.

• void serialWrite (uint8 t uart, uint8 t data)

Send a byte.

void serialWriteString (uint8\_t uart, const char \*data)

Send a string.

• uint8\_t serialTxBufferFull (uint8\_t uart)

Check if the transmit buffer is full.

uint8\_t serialTxBufferEmpty (uint8\_t uart)

Check if the transmit buffer is empty.

## 4.1.1 Detailed Description

UART Library enabling you to control all available UART Modules. With XON/XOFF Flow Control and buffered Receiving and Transmitting.

## 4.1.2 Macro Definition Documentation

4.1.2.1 #define BAUD( baudRate, xtalCpu ) ((xtalCpu)/((baudRate)\*16l)-1)

Calculate Baudrate Register Value.

**Examples:** 

test.c.

Definition at line 45 of file serial.h.

## 4.1.2.2 #define FLOWCONTROL

Defining this enables incoming XON XOFF (sends XOFF if rx buff is full)

Definition at line 62 of file serial.c.

#### 4.1.2.3 #define FLOWMARK 5

Space remaining to trigger xoff/xon.

Definition at line 64 of file serial.c.

Referenced by serialGet().

4.1 UART Library 9

## 4.1.2.4 #define RX\_BUFFER\_SIZE 32

If you define this, a '\r' (CR) will be put in front of a '\n' (LF) when sending a byte.

Binary Communication will then be impossible!RX Buffer Size in Bytes (Power of 2)

Definition at line 54 of file serial.c.

Referenced by serialGet(), and serialRxBufferFull().

#### 4.1.2.5 #define TX\_BUFFER\_SIZE 16

TX Buffer Size in Bytes (Power of 2)

Definition at line 58 of file serial.c.

Referenced by serialTxBufferFull(), and serialWrite().

#### 4.1.2.6 #define XOFF 0x13

XOFF Value.

Definition at line 66 of file serial.c.

Referenced by setFlow().

#### 4.1.2.7 #define XON 0x11

XON Value.

Definition at line 65 of file serial.c.

Referenced by serialGet(), and setFlow().

## 4.1.3 Function Documentation

## 4.1.3.1 uint8\_t serialAvailable ( void )

Get number of available UART modules.

Returns

number of modules

**Examples:** 

test.c.

Definition at line 113 of file serial.c.

## 4.1.3.2 void serialClose ( uint8\_t uart )

Stop the UART Hardware.

#### **Parameters**

uart UART Module to stop

Definition at line 148 of file serial.c.

References serialTxBufferEmpty().

```
148
        if (uart >= UART_COUNT)
149
150
            return;
151
        uint8_t sreg = SREG;
152
153
        sei();
154
        while (!serialTxBufferEmpty(uart));
        while (*serialRegisters[uart][SERIALB] & (1 << serialBits[uart][SERIALUDRIE])); // Wait while Transmit</pre>
155
       Interrupt is on
156
        cli();
157
        *serialRegisters[uart][SERIALB] = 0;
158
         *serialRegisters[uart][SERIALC] = 0;
159
        SREG = sreg;
160 }
```

## 4.1.3.3 uint8\_t serialGet ( uint8\_t uart )

Read a single byte.

#### **Parameters**

```
uart UART Module to read from
```

**Returns** 

Received byte or 0

**Examples:** 

test.c.

Definition at line 217 of file serial.c.

References FLOWMARK, RX\_BUFFER\_SIZE, and XON.

Referenced by serialGetBlocking().

```
218
         if (uart >= UART_COUNT)
219
              return 0;
220
         uint8_t c;
2.2.1
222
223 #ifdef FLOWCONTROL
         rxBufferElements[uart]--;
225
         if ((flow[uart] == 0) && (rxBufferElements[uart] <= FLOWMARK)) {</pre>
              while (sendThisNext[uart] != 0);
226
              sendThisNext[uart] = XON;
227
228
              flow[uart] = 1;
229
              if (shouldStartTransmission[uart]) {
230
                  shouldStartTransmission[uart] = 0;
                  *serialRegisters[uart][SERIALB] |= (1 << serialBits[uart][SERIALUDRIE]); // Enable Interrupt
*serialRegisters[uart][SERIALA] |= (1 << serialBits[uart][SERIALUDRE]); // Trigger Interrupt
231
232
              }
233
234
235 #endif
237
         if (rxRead[uart] != rxWrite[uart])
238
              c = rxBuffer[uart][rxRead[uart]];
239
              rxBuffer[uart][rxRead[uart]] = 0;
             if (rxRead[uart] < (RX_BUFFER_SIZE - 1)) {</pre>
240
241
                  rxRead[uart]++;
242
              } else {
243
                  rxRead[uart] = 0;
244
245
              return c;
246
         } else {
247
             return 0:
248
         }
249 }
```

4.1 UART Library

## 4.1.3.4 uint8\_t serialGetBlocking ( uint8\_t uart )

Wait until a character is received.

## **Parameters**

```
uart UART Module to read from
```

#### Returns

Received byte

Definition at line 209 of file serial.c.

References serialGet(), and serialHasChar().

```
209
210    if (uart >= UART_COUNT)
211        return 0;
212
213    while(!serialHasChar(uart));
214    return serialGet(uart);
215 }
```

## 4.1.3.5 uint8\_t serialHasChar ( uint8\_t uart )

Check if a byte was received.

## **Parameters**

```
uart UART Module to check
```

## Returns

1 if a byte was received, 0 if not

## **Examples:**

test.c.

Definition at line 198 of file serial.c.

Referenced by serialGetBlocking().

## 4.1.3.6 void serialInit ( uint8\_t uart, uint16\_t baud )

Initialize the UART Hardware.

## **Parameters**

uart	UART Module to initialize
baud	Baudrate. Use the BAUD() macro!

## Examples:

test.c.

Definition at line 117 of file serial.c.

```
117
118
         if (uart >= UART_COUNT)
119
               return;
120
         // Initialize state variables
121
         rxRead[uart] = 0;
122
123
         rxWrite[uart] = 0;
124
         txRead[uart] = 0;
         txWrite[uart] = 0;
125
126
         shouldStartTransmission[uart] = 1;
127 #ifdef FLOWCONTROL
128
         sendThisNext[uart] = 0;
129
         flow[uart] = 1;
130
         rxBufferElements[uart] = 0;
131 #endif
132
         // Default Configuration: 8N1
133
          *serialRegisters[uart][SERIALC] = (1 << serialBits[uart][SERIALUCSZ0]) | (1 << serialBits[uart][
134
       SERIALUCSZ1]);
135
136
          // Set baudrate
137 #if SERIALBAUDBIT == 8
       *serialRegisters[uart][SERIALUBRRH] = (baud >> 8);
*serialRegisters[uart][SERIALUBRRL] = baud;
138
139
140 #else
141
         *serialBaudRegisters[uart] = baud;
142 #endif
143
       *serialRegisters[uart][SERIALB] = (1 << serialBits[uart][SERIALRXCIE]); // Enable Interrupts

*serialRegisters[uart][SERIALB] |= (1 << serialBits[uart][SERIALRXEN]) | (1 << serialBits[uart][SERIALTXEN]); // Enable Receiver/Transmitter
144
145
146 }
```

## 4.1.3.7 uint8\_t serialRxBufferEmpty ( uint8\_t uart )

Check if the receive buffer is empty.

## **Parameters**

```
uart UART Module to check
```

### Returns

1 if buffer is empty, 0 if not.

Definition at line 258 of file serial.c.

```
258
259
        if (uart >= UART_COUNT)
260
            return 0;
261
262
        if (rxRead[uart] != rxWrite[uart]) {
263
            return 0;
        } else {
264
265
            return 1:
266
267 }
```

## 4.1.3.8 uint8\_t serialRxBufferFull ( uint8\_t uart )

Check if the receive buffer is full.

4.1 UART Library

#### **Parameters**

```
uart UART Module to check
```

## Returns

1 if buffer is full, 0 if not

Definition at line 251 of file serial.c.

References RX\_BUFFER\_SIZE.

4.1.3.9 uint8\_t serialTxBufferEmpty ( uint8\_t uart )

Check if the transmit buffer is empty.

#### **Parameters**

```
uart UART Module to check
```

## Returns

1 if buffer is empty, 0 if not.

Definition at line 317 of file serial.c.

Referenced by serialClose().

```
317
318     if (uart >= UART_COUNT)
319         return 0;
320
321     if (txRead[uart] != txWrite[uart]) {
322         return 0;
323     } else {
324         return 1;
325     }
326 }
```

4.1.3.10 uint8\_t serialTxBufferFull ( uint8\_t uart )

Check if the transmit buffer is full.

#### **Parameters**

```
uart UART Module to check
```

## **Returns**

1 if buffer is full, 0 if not

Definition at line 310 of file serial.c.

References TX\_BUFFER\_SIZE.

Referenced by serialWrite().

```
310
311    if (uart >= UART_COUNT)
312        return 0;
313
314        return (((txWrite[uart] + 1) == txRead[uart]) || ((txRead[uart] == 0) && ((txWrite[uart] + 1) == tx_BUFFER_SIZE)));
315 }
```

4.1.3.11 void serialWrite ( uint8\_t uart, uint8\_t data )

Send a byte.

#### **Parameters**

uart	UART Module to write to
data	Byte to send

## **Examples:**

test.c.

Definition at line 273 of file serial.c.

References serialTxBufferFull(), and TX\_BUFFER\_SIZE.

Referenced by serialWriteString().

```
274
           if (uart >= UART_COUNT)
275
                return;
276
277 #ifdef SERIALINJECTCR
278
         if (data == '\n') {
279
                serialWrite(uart, '\r');
280
281 #endif
282
          while (serialTxBufferFull(uart));
283
          txBuffer[uart][txWrite[uart]] = data;
if (txWrite[uart] < (TX_BUFFER_SIZE - 1)) {</pre>
284
285
                txWrite[uart]++;
286
288
                txWrite[uart] = 0;
289
290
           if (shouldStartTransmission[uart]) {
                shouldStartTransmission(uart) = 0;
*serialRegisters[uart][SERIALB] |= (1 << serialBits[uart][SERIALUDRIE]); // Enable Interrupt
*serialRegisters[uart][SERIALA] |= (1 << serialBits[uart][SERIALUDRE]); // Trigger Interrupt</pre>
291
292
293
295 }
```

4.1.3.12 void serialWriteString ( uint8\_t uart, const char \* data )

Send a string.

#### **Parameters**

uart	UART Module to write to
data	Null-Terminated String

## **Examples:**

test.c.

Definition at line 297 of file serial.c.

4.1 UART Library

References serialWrite().

```
2.97
                                                              {
298
        if (uart >= UART_COUNT)
299
            return;
300
301
        if (data == 0) {
302
            serialWriteString(uart, "NULL");
        } else {
303
304
            while (*data != '\0') {
305
               serialWrite(uart, *data++);
306
307
308 }
```

4.1.3.13 void setFlow ( uint8\_t uart, uint8\_t on )

Manually change the flow control.

Flow Control has to be compiled into the library!

#### **Parameters**

uart	UART Module to operate on
on	1 of on, 0 if off

Definition at line 163 of file serial.c.

References XOFF, and XON.

```
163
164
           if (uart >= UART_COUNT)
165
                 return;
166
           if (flow[uart] != on) {
   if (on == 1) {
167
168
                       // Send XON
169
                       while (sendThisNext[uart] != 0);
171
                       sendThisNext[uart] = XON;
172
                       flow[uart] = 1;
                       if (shouldStartTransmission[uart]) {
    shouldStartTransmission[uart] = 0;
    *serialRegisters[uart][SERIALB] |= (1 << serialBits[uart][SERIALUDRIE]);
    *serialRegisters[uart][SERIALA] |= (1 << serialBits[uart][SERIALUDRE]); // Trigger</pre>
173
174
175
176
          Interrupt
177
178
                 } else {
179
                       // Send XOFF
180
                       sendThisNext[uart] = XOFF;
181
                       flow[uart] = 0;
182
                       if (shouldStartTransmission[uart]) {
                             shouldStartTransmission[uart] = 0;
*serialRegisters[uart][SERIALB] |= (1 << serialBits[uart][SERIALUDRIE]);
*serialRegisters[uart][SERIALA] |= (1 << serialBits[uart][SERIALUDRE]); // Trigger</pre>
183
184
185
          Interrupt
186
187
188
                  // Wait till it's transmitted
189
                  while (*serialRegisters[uart][SERIALB] & (1 << serialBits[uart][SERIALUDRIE]));</pre>
           }
190
191 }
```

## **File Documentation**

## 5.1 serial.c File Reference

## **UART** Library Implementation.

```
#include <avr/io.h>
#include <avr/interrupt.h>
#include <stdint.h>
#include "serial.h"
#include "serial_device.h"
```

## **Macros**

• #define RX\_BUFFER\_SIZE 32

If you define this, a '\r' (CR) will be put in front of a '\n' (LF) when sending a byte.

• #define TX\_BUFFER\_SIZE 16

TX Buffer Size in Bytes (Power of 2)

• #define FLOWCONTROL

Defining this enables incoming XON XOFF (sends XOFF if rx buff is full)

• #define FLOWMARK 5

Space remaining to trigger xoff/xon.

• #define XON 0x11

XON Value.

• #define XOFF 0x13

XOFF Value.

## **Functions**

• uint8\_t serialAvailable (void)

Get number of available UART modules.

• void serialInit (uint8\_t uart, uint16\_t baud)

Initialize the UART Hardware.

• void serialClose (uint8\_t uart)

Stop the UART Hardware.

void setFlow (uint8\_t uart, uint8\_t on)

Manually change the flow control.

• uint8\_t serialHasChar (uint8\_t uart)

18 File Documentation

Check if a byte was received.

uint8\_t serialGetBlocking (uint8\_t uart)

Wait until a character is received.

• uint8\_t serialGet (uint8\_t uart)

Read a single byte.

• uint8\_t serialRxBufferFull (uint8\_t uart)

Check if the receive buffer is full.

uint8 t serialRxBufferEmpty (uint8 t uart)

Check if the receive buffer is empty.

void serialWrite (uint8\_t uart, uint8\_t data)

Send a byte.

• void serialWriteString (uint8\_t uart, const char \*data)

Send a string.

• uint8\_t serialTxBufferFull (uint8\_t uart)

Check if the transmit buffer is full.

uint8\_t serialTxBufferEmpty (uint8\_t uart)

Check if the transmit buffer is empty.

## 5.1.1 Detailed Description

**UART** Library Implementation.

Definition in file serial.c.

## 5.2 serial.h File Reference

UART Library Header File.

#### **Macros**

• #define BAUD(baudRate, xtalCpu) ((xtalCpu)/((baudRate)\*16l)-1)

Calculate Baudrate Register Value.

## **Functions**

uint8\_t serialAvailable (void)

Get number of available UART modules.

void serialInit (uint8\_t uart, uint16\_t baud)

Initialize the UART Hardware.

void serialClose (uint8\_t uart)

Stop the UART Hardware.

void setFlow (uint8\_t uart, uint8\_t on)

Manually change the flow control.

• uint8\_t serialHasChar (uint8\_t uart)

Check if a byte was received.

uint8\_t serialGet (uint8\_t uart)

Read a single byte.

uint8 t serialGetBlocking (uint8 t uart)

Wait until a character is received.

• uint8\_t serialRxBufferFull (uint8\_t uart)

Check if the receive buffer is full.

uint8\_t serialRxBufferEmpty (uint8\_t uart)

Check if the receive buffer is empty.

• void serialWrite (uint8\_t uart, uint8\_t data)

Send a byte.

• void serialWriteString (uint8\_t uart, const char \*data)

Send a string.

uint8\_t serialTxBufferFull (uint8\_t uart)

Check if the transmit buffer is full.

• uint8\_t serialTxBufferEmpty (uint8\_t uart)

Check if the transmit buffer is empty.

## 5.2.1 Detailed Description

UART Library Header File.

Definition in file serial.h.

## 5.3 serial\_device.h File Reference

UART Library device-specific configuration.

## 5.3.1 Detailed Description

UART Library device-specific configuration. Contains Register and Bit Positions for different AVR devices. Definition in file serial\_device.h.

20 File Documentation

## **Example Documentation**

## 6.1 test.c

Initializes all available UART Modules. Then prints a welcome message on each and waits for incoming characters, which will be repeated on the UART module they were received on.

```
* test.c
 * Copyright (c) 2012, Thomas Buck <xythobuz@me.com>
 * Redistribution and use in source and binary forms, with or without
 \star modification, are permitted provided that the following conditions
 \star - Redistributions of source code must retain the above copyright notice,
     this list of conditions and the following disclaimer.
 \star - Redistributions in binary form must reproduce the above copyright
     notice, this list of conditions and the following disclaimer in the
     documentation and/or other materials provided with the distribution.
 * THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS
 \star "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED
 \star TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR \star PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR
 * CONTRIBUTORS BE LIBBLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL,
* EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO,
 * PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA,
 \star PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF
 * LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING * NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS * SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.
#include <avr/interrupt.h>
#include <stdint.h>
#include "serial.h"
int main(void) {
    // Initialize UART modules
     for (int i = 0; i < serialAvailable(); i++) {</pre>
         serialInit(i, BAUD(38400, F_CPU));
    // Enable Interrupts
    // Print Welcome Message
    for (int i = 0; i < serialAvailable(); i++) {</pre>
         serialWriteString(i, "Hello from UART");
serialWrite(i, i + '0');
         serialWriteString(i, "...:)\n");
    // Wait for incoming bytes
     for(;;) {
         for (int i = 0; i < serialAvailable(); i++) {</pre>
              if (serialHasChar(i)) {
```

```
serialWrite(i, serialGet(i));
}
}
return 0;
}
```

## Index

BAUD
UART Library, 8
FLOWCONTROL
UART Library, 8
FLOWMARK
UART Library, 8
DV DV 01
RX_BUFFER_SIZE
UART Library, 8
serial.c, 17
serial.h, 18
serial device.h, 19
serialAvailable
UART Library, 9
serialClose
UART Library, 9
serialGet
UART Library, 10
serialGetBlocking
UART Library, 10
serialHasChar
UART Library, 11
serialInit
UART Library, 11
serialRxBufferEmpty
UART Library, 12
serialRxBufferFull
UART Library, 12
serialTxBufferEmpty
UART Library, 13
serialTxBufferFull
UART Library, 13
serialWrite
UART Library, 14
serialWriteString
UART Library, 14
setFlow
UART Library, 15
TX_BUFFER_SIZE
UART Library, 9
LIART Library 7
UART Library, 7 BAUD, 8
FLOWCONTROL, 8
FLOWMARK, 8
RX_BUFFER_SIZE, 8 serialAvailable, 9
ochalavallable, 🗸

serialClose, 9

```
serialGet, 10
     serialGetBlocking, 10
     serialHasChar, 11
     serialInit, 11
     serialRxBufferEmpty, 12
     serialRxBufferFull, 12
     serialTxBufferEmpty, 13
     serial Tx Buffer Full,\, \color{red} \textbf{13}
     serialWrite, 14
     serialWriteString, 14
     setFlow, 15
     TX_BUFFER_SIZE, 9
     XOFF, 9
     XON, 9
XOFF
     UART Library, 9
XON
     UART Library, 9
```