WEDGIE.DEV

You've got a wedgie.

A pocket computer: a Raspberry Pi Pico, a screen, and a secure chip wedged in between. It runs one app at a time: games, tools, or a wallet signer.




1. Go to wedgie.dev in Chrome.

2. Plug in your wedgie.

Screen doesn't light up? Flip the USB-C plug over. Some only work one way up.

The buttons



Green says yes. Red says no. The joystick and gray buttons do whatever the app wants.

Get started

1. Plug it into a computer with a **USB-C data cable** (some cables only charge). The screen lights up. **No light? Flip the plug over**: some only work one way up.
2. A drive called **WEDGIE** shows up. Open **Open wedgie** on it, or go to **wedgie.dev/connect** in **Chrome** or **Edge**. Safari and Firefox can't talk to USB.
3. Click **Connect** and pick your wedgie.
4. Pick an app. The wedgie asks **Install?** on its screen. Press **green**.

> A new wedgie says **No software** until you pick an app. That's normal.

Apps

Games: Frog, Grove, Bunker, Blocks, 2048, Blackjack. Tools: Buttons, Keypad. And **Safe Signer**, a hardware signer for a Safe multisig. More every week.

Switch apps anytime at **wedgie.dev/connect**. Game saves stay when you switch or update.

Is it safe?

- **Plugging it in gives a computer nothing.** It's locked.
- **Nothing installs or signs without a press of green** on the wedgie itself. No website or program can press it.
- **Apps on the shelf and the firmware are signed** by wedgie.dev. The wedgie checks before it installs.
- **Keys are made inside the secure chip** and never leave it.

> An app can do anything on the wedgie. Only install apps from the shelf, or code you trust.

Safe Signer

Makes your wedgie an owner of a Safe multisig. Install it, then go to **wedgie.dev/safe**.

- The first time it opens, it says **No key**. Press green: the chip makes a key and **locks it for good**. Nobody ever sees it, not even us.
- It shows what a transaction does. Green signs, red says no.
- Keep a second owner on your Safe. If the chip breaks, its key is gone.

> If Safe Signer shows an address the very first time you open it, someone made a key before you. Don't use it. Email us.

Make your own app

Go to **wedgie.dev/code**. Write it yourself, or have your AI agent write it. Try it in the browser, then put it on your wedgie. Agents: read **wedgie.dev/skill.md**.

If something's off

The screen doesn't light up

Flip the USB-C plug over. Some only work one way up. Still dark? Try another cable.

It doesn't show up on the computer

Try another cable (charge-only cables are common) and another USB port.

"No software"

Pick an app at wedgie.dev/connect.

An app is stuck or crashes when it starts

Hold **X** (the gray one next to red) while you plug it in. It starts without the app. Then pick another app.

"wedgie broke"

Press **B** to try again.

The page says the firmware is old

Click update and press green on the wedgie.

Still broken

Go to **wedgie.dev/test** in Chrome. It wipes the wedgie, puts everything back on, and tests the screen, buttons and chip. Your game saves come back. It never touches the chip's keys. To wipe it, push a paperclip into the small hole in the base while you plug it in.

Help

Email **wedgie@buidlguidl.com**
Show it off: **@wedgiedev** on X.
Made by **BuidlGuidl**. Open source, MIT: **github.com/clawdbotatg/wedgie-dev**