

# CompTIA A+ Core 1 Playbook

*IT Labs*

*Prepared by Garrick White*

## 4.1.10 Configure BIOS/UEFI Security

You are the IT administrator for a small corporate network. You need to configure additional security in the BIOS for the computer in Office 1.

- Restart the computer in the BIOS.
  - Press **F2** while the computer is booting.
- Configure the following security settings:
  - Add an admin password used to make changes to BIOS settings.
    - Password: **t67xab1**
  - Add a password that prevents hard disk access even when the hard disk is moved to another system.
    - Password: **dog8b0b** (0 is a zero)
  - Enable the TPM.
  - Enable chassis intrusion detection to show an alert during POST when an intrusion is detected.
  - Save your changes.
- Restart the computer to verify the changes you have made.

Complete this lab as follows:

1. Set the admin password.
  1. From the taskbar, select **Start**.  
The Start window is shown.
  2. From the bottom right of the Start window, select the **power icon**.
  3. Select **Restart**.
  4. When the *Restart* text disappears, press **F2** (or **Delete**) to access the BIOS settings.
  5. From the left pane, expand **Security**.
  6. Select **Admin Password** to set the admin password.
  7. Type **t67xab1** in the *Enter new password* field.
  8. Type **t67xab1** in the *Confirm new password* field.
  9. Select **OK**.
2. Set the hard disk password.
  1. From the left pane, under Security, select **Internal HDD-1 Password** to configure a hard drive password.
  2. Type **dog8b0b** in the *Enter new password* field. (0 is a zero.)
  3. Type **dog8b0b** in the *Confirm new password* field. (0 is a zero.)
  4. Select **OK**.
  5. Read the warning message on the screen and then select **Yes**.
3. Enable TPM.
  1. From the left pane, under Security, select **TPM Security**.
  2. From the right pane, select **TPM Security**.
  3. Select **Apply**.
  4. Select **Activate**.
  5. Select **Apply**.
4. Enable intrusion detection.
  1. From the left pane, under Security, select **Chassis Intrusion**.
  2. Select **Enable**.
  3. Select **Apply**.
  4. Select **Exit** to exit and save your changes.  
The system automatically reboots.
5. Verify the changes made.
  1. Press **F2** (or **Delete**) during the BIOS load to test the admin password.  
If you do not press the Delete key in time, select the **Send Ctrl + Alt + Del** button at the bottom of the screen.
  2. Enter **t67xab1** when you are prompted for the administrative password.
  3. Select **OK**.  
Notice that the admin password was set correctly.
  4. Select **Exit** to exit the BIOS.

5. Type **dog8b0b** when prompted for the hard drive password. (0 is a zero.)
6. Press **Enter**.  
Note that the hard drive password was set correctly. The system loads the operating system.