$$V_{ADIBLC} = \frac{(V_{gsteff} + 2v_t)}{\theta_{rout}(1 + P_{DIBLCB}V_{bseff})} \left(1 - \frac{A_{bulk}V_{dsat}}{A_{bulk}V_{dsat} + V_{gsteff} + 2v_t}\right)$$

$$(3.5.5)$$

$$\theta_{rout} = P_{DIBLC1} \left[\exp(-D_{ROUT} \frac{L_{eff}}{2l_{t0}}) + 2 \exp(-D_{ROUT} \frac{L_{eff}}{l_{t0}}) \right] + P_{DIBLC2}$$

$$\frac{1}{V_{ASCBE}} = \frac{P_{scbe2}}{L_{eff}} \exp\left(\frac{-P_{scbe1} litl}{V_{ds} - V_{dsat}}\right)$$

$$(3.5.5)$$

3.6 Single Current Expression for All Operating Regimes of V_{gs} and V_{ds}

The V_{gsteff} function introduced in Chapter 2 gave a unified expression for the linear drain current from subthreshold to strong inversion as well as for the saturation drain current from subthreshold to strong inversion, separately. In order to link the continuous linear current with that of the continuous saturation current, a smooth function for V_{ds} is introduced. In the past, several smoothing functions have been proposed for MOSFET modeling [22-24]. The smoothing function used in BSIM3 is similar to that proposed in [24]. The final current equation for both linear and saturation current now becomes

$$I_{ds} = \frac{I_{dso(Vdseff)}}{1 + \frac{R_{ds}I_{dso(Vdseff)}}{V_{dseff}}} \left(1 + \frac{V_{ds} - V_{dseff}}{V_{A}}\right) \left(1 + \frac{V_{ds} - V_{dseff}}{V_{ASCBE}}\right)$$
(3.6.1)

Most of the previous equations which contain V_{ds} and V_{dsat} dependencies are now substituted with the V_{dseff} function. For example, Eq. (3.5.4) now becomes