ERROR CODES

Contents

Chapter 3	ERROR CODES	3–1
3.1	A	3–4
3.1.1	ACAL Alarm Code	3-4
3.1.2	APSH Alarm Code	
3.1.3	ARC Alarm Code	3-58
3.1.4	ASBN Alarm Code	3-90
3.1.5	ATGP Alarm Code	3-117
3.1.6	ATZN Alarm Code	3-118
3.2	В	3-124
3.2.1	BBOX Alarm Code	3-124
3.2.2	BRCH Alarm Code	3-129
3.3	C	3-132
3.3.1	CALM Alarm Code	3-132
3.3.2	CD Alarm Code	3-139
3.3.3	CMND Alarm Code	3-145
3.3.4	CNTR Alarm Code	3-148
3.3.5	COND Alarm Code	3-151
3.3.6	COPT Alarm Code	3-152
3.3.7	CPMO Alarm Code	3-157
3.3.8	CVIS Alarm Code	3-197
3.4	D	3-308
3.4.1	DIAG Alarm Code	3-308
3.4.2	DICT Alarm Code	3-310
3.4.3	DJOG Alarm Code	3-317
3.4.4	DMDR Alarm Code	3-321
3.4.5	DMER Alarm Code	3-323
3.4.6	DNET Alarm Code	3-334
3.4.7	DTBR Alarm Code	3-358
3.4.8	DX Alarm Code	3-359
3.5	E	3-362

3.5.1	ELOG Alarm Code	3-362
3.6	F	3-363
3.6.1	FILE Alarm Code	3-363
3.6.2	FLPY Alarm Code	3-378
3.6.3	FRCE Alarm Code	3–381
3.6.4	FRSY Alarm Code	3-439
3.6.5	FXTL Alarm Code	3-443
3.7	H	3-465
3.7.1	HOST Alarm Code	3-465
3.7.2	HRTL Alarm Code	3–497
3.8	1	3-509
3.8.1	IBSS Alarm Code	3-509
3.8.2	ICRZ Alarm Code	3-562
3.8.3	IFPN Alarm Code	3-564
3.8.4	INTP Alarm Code	3-569
3.8.5	IRPK Alarm Code	3-645
3.8.6	ISD Alarm Code	3-673
3.8.7	ISDT Alarm Code	3-701
3.9	J	3–707
3.9.1	JOG Alarm Code	3–707
3.10	K	3-714
3.10.1	KALM Alarm Code	3-714
		-
3.11	L	3-714
3.11.1	LANG Alarm Code	3-714
3.11.2	LECO Alarm Code	3–720
3.11.3	LNTK Alarm Code	3–731
3.11.4	LSTP Alarm Code	3-742
3.12	M	3-745
3.12.1	MACR Alarm Code	3-745
3.12.2	MARL Alarm Code	3-747
3.12.3	MASI Alarm Code	3-752
3.12.4	MCTL Alarm Code	3-759
3.12.5	MEMO Alarm Code	3-762
3.12.6 3.12.6	MENT Alarm Code	3-778
3.12.7	MHND Alarm Code	3-781
3.12.7 3.12.8	MOTN Alarm Code	3-800
3.12.0 3.12.9	MUPS Alarm Code	3-879
3.13	N	3–881
3.13.1	NCBN Alarm Code	3–881
3.14	0	3-884
3.14.1	OPTN Alarm Code	3-884
3.14.2	OS Alarm Code	3-891
3.15	P	3-893
3.15.1	PALL Alarm Code	3-893
3.15.2	PALT Alarm Code	3-930
3.15.3	PICK Alarm Code	3-932
3.15.4	PMON Alarm Code	3-939
3.15.5	PNT1 Alarm Code	3-941
3.15.6	PNT2 Alarm Code	3-1110
3.15.7	PRIO Alarm Code	3-1239
3.15.8	PROC Alarm Code	3-1293
3.15.9	PROF Alarm Code	3-1294

3.15.10	PROG Alarm Gode	3-1297
3.15.11	PTPG Alarm Code	3-1307
3.15.12	PWD Alarm Code	3–1309
3.16	Q	3-1319
3.16.1	QMGR Alarm Code	3-1319
3.17	R	3-1320
3.17.1	RIPE Alarm Code	3-1320
3.17.2	ROUT Alarm Code	3-1324
3.17.3	RPC Alarm Code	3-1331
3.17.4	RPM Alarm Code	3-1333
3.17.5	RRMC Alarm Code	3-1335
3.17.6	RTCP Alarm Code	3-1339
3.18	S	3-1342
3.18.1	SCIO Alarm Code	3-1342
3.18.2	SDTL Alarm Code	3-1344
3.18.3	SEAL Alarm Code	3-1358
3.18.4	SENC Alarm Code	3-1418
3.18.5	SENS Alarm Code	3-1419
3.18.6	SHAP Alarm Code	3-1421
3.18.7	SPOT Alarm Code	3-1428
3.18.8	SPRM Alarm Code	3-1464
3.18.9	SRIO Alarm Code	3-1465
3.18.10	SRVO Alarm Code	3-1468
3.18.11	SSPC Alarm Code	3-1564
3.18.12	SVGN Alarm Code	3-1579
3.18.13	SVTL Alarm Code	3-1663
3.18.14	SYST Alarm Code	3-1665
3.19	T	3–1711
3.19.1	TAST Alarm Code	3–1711
3.19.2	TCPP Alarm Code	3-1715
3.19.3	TG Alarm Code	3-1720
3.19.4	THSR Alarm Code	3–1724
3.19.5	TJOG Alarm Code	3–1733
3.19.6	TMAT Alarm Code	3-1734
3.19.7	TOOL Alarm Code	3–1738
3.19.8	TPIF Alarm Code	3-1744
3.19.9	TRAK Alarm Code	3–1776
3.19.10	TRSV Alarm Code	3–1779
3.20	٧	3-1786
3.20.1	VARS Alarm Code	3-1786
3.21	W	3-1799
3.21.1	WEAV Alarm Code	3-1799
3.21.2	WNDW Alarm Code	3-1804
3.22	Χ	3-1810
3.22.1	XMLF Alarm Code	