## Tutorial de Embedded Linux

Primeiramente é necessário a definição da escolha do Toolchain, e no meu caso escolhi um pré-construido chamado CrossToll-NG:

• O clone do github:

```
guilherme@guilherme-VirtualBox:~$ git clone https://github.com/crosstool-ng/crosstool-ng.git
Cloning into 'crosstool-ng'...
remote: Enumerating objects: 41245, done.
remote: Counting objects: 100% (1950/1950), done.
remote: Compressing objects: 100% (1107/1107), done.
remote: Total 41245 (delta 902), reused 1572 (delta 798), pack-reused 39295
Receiving objects: 100% (41245/41245), 15.56 MiB | 1.09 MiB/s, done.
Resolving deltas: 100% (26115/26115), done.
```

Abrindo diretórios doe encontrando o arquivo Dockerfile:

```
guilherme@guilherme-VirtualBox:~$ ls
                 code.c
arquivo.txt code.o
beerme.sh
                 crosstool-ng programa
                                                                                                       testeutf8.txt
                                    program.c syscont.py
code
code1
                                    program.o temp
guilherme@guilherme-VirtualBox:~$ cd crosstol-ng
bash: cd: crosstol-ng: No such file or directory
guilherme@guilherme-VirtualBox:~$ cd crosstool-ng
guilherme@guilherme-VirtualBox:-/crosstool-ng$ ls
bash-completion configure.ac ct-ng.in issue_template.md licenses.d Makefile.am README.md
 ootstrap
                      COPYING
                                                       LICENSE
                                                                                 maintainer paths.sh.in scripts
guilherme@guilherme-VirtualBox:~/crosstool-ng$ cd testing
guilherme@guilherme-VirtualBox:~/crosstool-ng/testing$ cd docker
guilherme@guilherme-VirtualBox:~/crosstool-ng/testing/docker$ ls
alpine3.15 centos7 common-s
archlinux centos-stream9 dmgr.sh
                                      common-scripts docker-remove-all.sh
guilherme@guilherme-VirtualBox:~/crosstool-ng/testing/docker$ cd ubuntu21.10
guilherme@guilherme-VirtualBox:~/crosstool-ng/testing/docker/ubuntu21.10$ ls
Dockerfile
```

 Checando as dependências do Dockerfile e verificando se todas as bibliotecas estão instaladas:

```
ROM ubuntu:21.10
ARG CTNG UID=1000
ARG CTNG GID=1000
RUN groupadd -g $CTNG_GID ctng
RUN useradd -d /home/ctng -m -g $CTNG_GID -u $CTNG_UID -s /bin/bash ctng
# Non-interactive configuration of tzdata
ENV DEBIAN FRONTEND noninteractive
ENV DEBCONF NONINTERACTIVE SEEN true
RUN { echo ˈtzdata tzdata/Āreas select Etc'; echo 'tzdata tzdata/Zones/Etc select UTC'; } | debconf-set-sele
lons
RUN apt-get update
RUN apt-get install -y gcc g++ gperf bison flex texinfo help2man make libncurses5-dev
nvthon3-dev autoconf automake libtool libtool-bin gawk wget bzip2 xz-utils unzip
RUN wget -0 /sbin/dumb-init https://github.com/Yelp/dumb-init/releases/download/v1.2.5/dumb-init 1.2.5 x86 6
RUN chmod a+x /sbin/dumb-init
RUN echo 'export PATH=/opt/ctng/bin:$PATH' >> /etc/profile
ENTRYPOINT [ "/sbin/dumb-init",
 'Dockerfile" 20L, 853C
                                                                                                            1,1
```

## Executar o arquivo bootstrap

```
guilherme@guilherme-VirtualBox:~/crosstool-ng$ ./bootstrap
INFO :: *** Generating package version descriptions
INFO :: Master packages: android-ndk autoconf automake avr-libc binutils bison
cloog dtc duma elf2flt expat gcc gdb gettext glibc glibc-ports gmp gnuprumcu isl
libelf libiconv libtool linux ltrace m4 make mingw-w64 moxiebox mpc mpfr musl n
curses newlib-nano newlib picolibc strace uClibc-ng zlib
INFO :: Generating 'config/versions/android-ndk.in'
INFO :: Generating 'config/versions/autoconf.in'
INFO :: Generating 'config/versions/automake.in'
INFO :: Generating 'config/versions/avr-libc.in'
INFO :: Generating 'config/versions/binutils.in'
INFO :: Generating 'config/versions/bison.in'
INFO :: Generating 'config/versions/cloog.in'
INFO :: Generating 'config/versions/dtc.in'
INFO :: Generating 'config/versions/duma.in'
INFO :: Generating 'config/versions/elf2flt.in'
INFO :: Generating 'config/versions/expat.in'
INFO :: Generating 'config/versions/gcc.in'
INFO :: Generating 'config/versions/gdb.in'
INFO :: Generating 'config/versions/gettext.in'
```

• Executando o configure

```
guilherme@guilherme-VirtualBox:~/crosstool-ng$ ./configure --enable-local
checking for a BSD-compatible install... /usr/bin/install -c
checking whether build environment is sane... yes
checking for a thread-safe mkdir -p... /usr/bin/mkdir -p
checking for gawk... gawk
checking whether make sets $(MAKE)... yes
checking whether make supports nested variables... yes
checking how to create a pax tar archive... gnutar
checking whether make supports nested variables... (cached) yes
checking whether to enable maintainer-specific portions of Makefiles... yes
checking build system type... x86_64-pc-linux-gnu
checking host system type... x86_64-pc-linux-gnu
checking whether ln -s works... yes
checking whether install takes --strip-program option... yes
checking for ggrep... no
checking for grep... grep
checking for absolute path to grep... /usr/bin/grep
```

• Executando o make e o make install

```
guilherme@guilherme-VirtualBox:~/crosstool-ng$ make
 usr/bin/make all-recursive
make[1]: Entering directory '/home/quilherme/crosstool-ng'
Making all in kconfig
make[2]: Entering directory '/home/guilherme/crosstool-ng/kconfig'
             lexer.lex.c
  LEX
  YACC
             parser.tab.c
parser.y:103.1-11: warning: POSIX Yacc does not support %destructor [-Wyacc]
  103 | %destructor {
/usr/bin/make all-am
nake[3]: Entering directory '/home/guilherme/crosstool-ng/kconfig'
             conf.o
  CC
             confdata.o
  CC
             expr.o
  CC
             symbol.o
  CC
             preprocess.o
  CC
             util.o
             parser.tab.o
  CC
             lever lev o
  CC
             nconf-expr.o
  CC
             nconf-symbol.o
  CC
             nconf-preprocess.o
  CC
             nconf-util.o
  CC
             nconf-parser.tab.o
             nconf-lexer.lex.o
  CCLD
             nconf
             mconf.o
  CC
             lxdialog/checklist.o
  CC
             lxdialog/inputbox.o
  CC
             lxdialog/menubox.o
  CC
             lxdialog/textbox.o
  CC
             lxdialog/util.o
  CC
             lxdialog/yesno.o
  CCLD
             mconf
make[3]: Leaving directory '/home/guilherme/crosstool-ng/kconfig'
make[2]: Leaving directory '/home/guilherme/crosstool-ng/kconfig'
make[2]: Entering directory '/home/guilherme/crosstool-ng'
  GEN
             ct-ng
  GEN
             bash-completion/ct-ng
  GEN
             docs/ct-ng.1
make[2]: Leaving directory '/home/guilherme/crosstool-ng'
make[1]: Leaving directory '/home/guilherme/crosstool-ng'
guilherme@guilherme-VirtualBox:~/crosstool-ng$ make install
Making install in kconfig
make[1]: Entering directory '/home/guilherme/crosstool-ng/kconfig'
/usr/bin/make install-am
make[2]: Entering directory '/home/guilherme/crosstool-ng/kconfig'
make[3]: Entering directory '/home/guilherme/crosstool-ng/kconfig'
   /usr/bin/mkdir -p '/usr/local/libexec/crosstool-ng'
/usr/bin/mkdir: cannot create directory '/usr/local/libexec': Permission denied
make[3]: *** [Makefile:502: install-pkglibexecPROGRAMS] Error 1
make[3]: Leaving directory '/home/guilherme/crosstool-ng/kconfig'
make[2]: *** [Makefile:874: install-am] Error 2
make[2]: Leaving directory '/home/guilherme/crosstool-ng/kconfig'
make[1]: *** [Makefile:868: install] Error 2
make[1]: Leaving directory '/home/guilherme/crosstool-ng/kconfig'
make: *** [Makefile:2485: install-recursive] Error 1
```

Utilizando o distclean e o list-samples do ct-ng

```
guilherme@guilherme-VirtualBox:~/crosstool-ng$ ./ct-ng distclean
  CLEAN scripts
  CLEAN log
  CLEAN build dir
  CLEAN .config
```

```
guilherme@guilherme-VirtualBox:~/crosstool-ng$ ./ct-ng list-samples
Status Sample name
        aarch64-ol7u9-linux-gnu
        aarch64-rpi3-linux-gnu
        aarch64-rpi4-linux-gnu
        aarch64-unknown-linux-android
        aarch64-unknown-linux-gnu
        aarch64-unknown-linux-uclibc
        alphaev56-unknown-linux-gnu
        alphaev67-unknown-linux-gnu
        arc-arc700-linux-uclibc
        arc-archs-linux-gnu
        arc-multilib-elf32
        arc-multilib-linux-gnu
        arc-multilib-linux-uclibc
        arm-bare_newlib_cortex_m3_nommu-eabi
        arm-cortex_a15-linux-gnueabihf
        arm-cortexa5-linux-uclibcgnueabihf
        arm-cortex_a8-linux-gnueabi
        arm-cortexa9_neon-linux-gnueabihf
        x86_64-w64-mingw32,arm-cortexa9_neon-linux-gnueabihf
        armeb-unknown-eabi
        armeb-unknown-linux-gnueabi
        armeb-unknown-linux-uclibcgnueabi
        arm-multilib-linux-uclibcgnueabi
        arm-nano-eabi
[L...]
        arm-ol7u9-linux-gnueabi
        arm-ol7u9-linux-qnueabihf
        arm-picolibc-eabi
        arm-unknown-eabi
        arm-unknown-linux-gnueabi
```

```
arm-unknown-linux-musleabi
          arm-unknown-linux-uclibcgnueabi
          arm-unknown-linux-uclibcgnueabihf
armv6-nommu-linux-uclibcgnueabi
armv6-unknown-linux-gnueabi
          armv6-unknown-linux-gnueabihf
          armv7-rpi2-linux-gnueabihf
          armv8-rpi3-linux-gnueabihf
armv8-rpi4-linux-gnueabihf
L...
          i586-geode-linux-uclibc
          i686-centos6-linux-gnu
i686-centos7-linux-gnu
i686-nptl-linux-gnu
          i686-ubuntu14.04-linux-gnu
i686-ubuntu16.04-linux-gnu
          i686-w64-minaw32
          m68k-unknown-elf
          m68k-unknown-uclinux-uclibc
          powerpc-unknown-linux-uclibc,m68k-unknown-uclinux-uclibc
          mips64el-multilib-linux-uclibc
          mips64-unknown-linux-gnu
mips-ar2315-linux-gnu
          mipsel-multilib-linux-gnu
mipsel-sde-elf
          mipsel-unknown-linux-gnu
          mips-malta-linux-gnu
          mips-unknown-elf
          mips-unknown-linux-gnu
          mips-unknown-linux-uclibc
```

```
mips-unknown-linux-uclibc
moxie-unknown-elf
moxie-unknown-moxiebox
x86_64-multilib-linux-uclibc,moxie-unknown-moxiebox
msp430-unknown-elf
nios2-altera-linux-gnu
i686-w64-mingw32,nios2-spico-elf
nios2-unknown-elf
powerpc-405-linux-gnu
powerpc64le-unknown-linux-gnu
powerpc64-multilib-linux-gnu
powerpc64-unknown-linux-gnu
powerpc-8540-linux-gnu
powerpc-860-linux-qnu
powerpc-e300c3-linux-gnu
powerpc-e500v2-linux-gnuspe
x86_64-multilib-linux-uclibc,powerpc-unknown-elf
powerpc-unknown-linux-gnu
powerpc-unknown-linux-uclibc
powerpc-unknown_nofpu-linux-gnu
riscv32-hifive1-elf
riscv32-unknown-elf
riscv64-unknown-elf
riscv64-unknown-linux-gnu
s390-ibm-linux-qnu
s390-unknown-linux-gnu
s390x-ibm-linux-gnu
s390x-unknown-linux-gnu
sh-multilib-linux-qnu
sh-multilib-linux-uclibc
sh-unknown-elf
sparc64-multilib-linux-gnu
sparc-leon-linux-uclibc
```

```
sparc-unknown-linux-gnu
        tic6x-uclinux
        x86 64-centos6-linux-gnu
        x86_64-centos7-linux-gnu
        x86 64-multilib-linux-gnu
        x86_64-multilib-linux-musl
        x86_64-multilib-linux-uclibc
        x86 64-w64-mingw32,x86 64-pc-linux-gnu
[L..X]
        x86 64-ubuntu14.04-linux-gnu
        x86_64-ubuntu16.04-linux-gnu
        x86 64-unknown-linux-gnu
        x86 64-unknown-linux-uclibc
[L..X]
        x86 64-w64-mingw32
        xtensa-fsf-elf
[L...]
        xtensa-fsf-linux-uclibc
L (Local)
                : sample was found in current directory
                 : sample was installed with crosstool-NG
G (Global)
X (EXPERIMENTAL): sample may use EXPERIMENTAL features
                : sample is currently broken
B (BROKEN)
0 (OBSOLETE)
                : sample needs to be upgraded
```

No menuconfig desse arquivo, retirar o read-only

```
Paths and misc options

Arrow keys navigate the menu. <Enter> selects submenus ---> (or empty submenus ----). Highlighted
letters are hotkeys. Pressing <Y> includes, <N> excludes, <M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </> for Search. Legend: [*] built-in [] excluded <M> module
< > module capable
                   [*] Install licenses
                  [ ] Render the toolchain read-only
[*] Strip host toolchain executables
                   [ ] Strip target toolchain executables
                       *** Downloading ***
Download agent (wget) --->
                   [ ] Forbid downloads
                         Force downloads
                   (10) Connection timeout
                   (--passive-ftp --tries=3 -nc --progress=dot:binary) Extra options to wget
                   [ ] Stop after downloading tarballs
                          Use a mirror
                   [*] Verify download digests (checksums)
                  Digest algorithm (SHA-512) --->
[] Verify detached signatures
                       *** Extracting ***
                   [ ] Force extractions
                   [*] Override config.{guess,sub}
[ ] Stop after extracting tarballs
                       Patches origin (Bundled only) --->
                           <Select> < Exit > < Help > < Save > < Load >
```

Construir toolchain

```
æguilherme-VirtualBox:~/crosstool-ng$ ./ct-ng build
Performing some trivial sanity checks
Number of open files 1024 may not be sufficient to build the toolchain; increasing to 2048
INFO
WARN
[INFO
           Build started 20220312.233029
TNFO
           Building environment variables
          Directory '/home/guilherme/src' does not exist.
Will not save downloaded tarballs to local storage.
[WARN ]
WARN
           Preparing working directories
[EXTRA]
[EXTRA]
           Installing user-supplied crosstool-NG configuration
[EXTRA]
EXTRA1
           Dumping internal crosstool-NG configuration
[EXTRA]
             Building a toolchain for:
                build = x86_64-pc-linux-qnu
[EXTRA]
[EXTRA]
                host = x86_64-pc-linux-gnu
FXTRA1
                target = alphaev4-unknown-elf
           Dumping internal crosstool-NG configuration: done in 0.14s (at 00:02)
[EXTRA]
INFO ]
[INFO ]
           Retrieving needed toolchain components' tarballs
             Retrieving 'zlib-1.2.11'
Verifying SHA512 checksum for 'zlib-1.2.11.tar.xz'
[EXTRA]
EXTRA1
             Retrieving 'gmp-6.2.1'
[EXTRA]
             Verifying SHA512 checksum for 'gmp-6.2.1.tar.xz'
[EXTRA]
             Retrieving 'mpfr-4.1.0'
[EXTRA]
             Verifying SHA512 checksum for 'mpfr-4.1.0.tar.xz'
[EXTRA]
             Retriéving 'isl-0.24'
Verifying SHA512 checksum for 'isl-0.24.tar.xz'
[EXTRA]
[EXTRA]
             Retrieving 'mpc-1.2.1'
Verifying SHA512 checksum for 'mpc-1.2.1.tar.gz'
[EXTRA]
[EXTRA]
             Retriéving 'binutils-2.38'
Verifying SHA512 checksum for 'binutils-2.38.tar.xz'
[EXTRA]
EXTRA1
             Retrieving 'gcc-11.2.0'
[EXTRA]
             Verifying SHA512 checksum for 'gcc-11.2.0.tar.xz
         Retrieving 'newlib-4.1.0'
Verifying SHA512 checksum for 'newlib-4.1.0.tar.gz'
Retrieving needed toolchain components' tarballs: done in 244.17s (at 04:06)
[EXTRA]
[EXTRA]
[INFO ]
[INFO]
INFO ]
          Extracting and patching toolchain components
            Extracting zlib-1.2.11
Patching zlib-1.2.11
[EXTRA]
[EXTRA]
EXTRA]
            Extracting gmp-6.2.1
            Patching gmp-6.2.1
Extracting mpfr-4.1.0
EXTRA]
[EXTRA]
            Patching mpfr-4.1.0
Extracting isl-0.24
Patching isl-0.24
[EXTRA]
[EXTRA]
[EXTRA]
            Extracting mpc-1.2.1
[EXTRA]
            Patching mpc-1.2.1
[EXTRA]
EXTRA]
            Extracting binutils-2.38
           /home/guilherme/crosstool-ng/scripts/functions: line 298: printf: write error: No space left on devic
home/guilherme/crosstool-ng/scripts/functions: line 298: printf: write error: No space left on device'
ERROR
[04:10] / /home/guilherme/crosstool-ng/scripts/functions: line 298: printf: write error: No space left on devic
FRROR 1
[04:10] / /home/quilherme/crosstool-ng/scripts/functions: line 298: printf: write error: No space left on devic
[ERROR] >> Build failed in step 'Extracting and patching toolchain components'
[04:10] / /home/guilherme/crosstool-ng/scripts/functions: line 298: printf: write error: No space left on devic
[ERROR] >> called in step '(top-level)'
[04:10] / /home/guilherme/crosstool-ng/scripts/functions: line 298: printf: write error: No space left on devic
[ERROR]
[04:10] / /home/guilherme/crosstool-ng/scripts/functions: line 298: printf: write error: No space left on devic
```

Executando o programa construído

```
CT_BINUTILS_2_30_or_later=y
CT_BINUTILS_later_than_2_27=y
CT_BINUTILS_2_27 or later=y
CT BINUTILS later than 2 26=y
CT BINUTILS 2 26 or later=y
# GNU binutils
CT BINUTILS LINKER LD=y
CT BINUTILS LINKERS LIST="ld"
CT BINUTILS LINKER DEFAULT="bfd"
# CT BINUTILS PLUGINS is not set
CT BINUTILS RELRO=m
CT BINUTILS DETERMINISTIC ARCHIVES=y
CT BINUTILS EXTRA CONFIG ARRAY=""
CT ALL BINUTILS CHOICES="BINUTILS"
# end of Binary utilities
# C-library
CT_LIBC_NEWLIB=y
# CT_LIBC_NONE is not set
CT_LIBC="newlib"
CT_LIBC_CHOICE_KSYM="NEWLIB"
CT_THREADS="none"
CT_LIBC_NEWLIB_SHOW=y
# Options for newlib
CT LIBC NEWLIB PKG KSYM="NEWLIB"
CT NEWLIB DIR NAME="newlib"
CT_NEWLIB_PKG_NAME="newlib"
CT NEWLIB SRC RELEASE=y
# CT_NEWLIB_SRC_DEVEL is not set
CT NEWLIB PATCH ORDER="global"
CT_NEWLIB_V_4_1=y
# CT_NEWLIB_V_3_3 is not set
# CT_NEWLIB_V_3_2 is not set
# CT NEWLIB V 3 1 is not set
# CT NEWLIB V 3 0 is not set
# CT NEWLIB V 2 5 is not set
CT NEWLIB VERSION="4.1.0"
CT_NEWLIB_MIRRORS="ftp://sourceware.org/pub/newlib"
CT NEWLIB ARCHIVE FILENAME="@{pkg name}-@{version}"
CT NEWLIB ARCHIVE DIRNAME="@{pkg name}-@{version}"
CT_NEWLIB_ARCHIVE_FORMATS=".tar.gz"
CT_NEWLIB_SIGNATURE_FORMAT=""
CT LIBC NEWLIB TARGET CFLAGS=""
# CT LIBC NEWLIB IO C99FMT is not set
# CT LIBC NEWLIB IO LL is not set
```

CT\_BINUTILS\_later\_than\_2\_30=y

# CT LIBC NEWLIB IO FLOAT is not set

```
CT_LIBC_NEWLIB_IO_C99FMT is not set CT_LIBC_NEWLIB_IO_LL is not set
 FCT_LIBC_NEWLIB_IO_FLOAT is not set
FCT_LIBC_NEWLIB_IO_POS_ARGS is not set
CT_LIBC_NEWLIB_FVWRITE_IN_STREAMIO=y
CT_LIBC_NEWLIB_UNBUF_STREAM_OPT=y
CT_LIBC_NEWLIB_FSEEK_OPTIMIZATION=y
 CT_LIBC_NEWLIB_DISABLE_SUPPLIED_SYSCALLS is not set
CT_LIBC_NEWLIB_REGISTER_FINI is not set
CT_LIBC_NEWLIB_ATEXIT_DYNAMIC_ALLOC=y
# CT_LIBC_NEWLIB_GLOBAL_ATEXIT is not set
 # CT_LIBC_NEWLIB_LITE_EXIT is not set
 CT_LIBC_NEWLIB_REENT_SMALL is not set
CT_LIBC_NEWLIB_MULTITHREAD=y
# CT_LIBC_NEWLIB_RETARGETABLE_LOCKING is not set
# CT_LIBC_NEWLIB_EXTRA_SECTIONS is not set
CT_LIBC_NEWLIB_WIDE_ORIENT=y
CT_LIBC_NEWLIB_ENABLE_TARGET_OPTSPACE=y
# CT_LIBC_NEWLIB_LTO is not set
# CT_LIBC_NEWLIB_NANO_MALLOC is not set
# CT_LIBC_NEWLIB_NANO_FORMATTED_IO is not set
 T LIBC NEWLIB EXTRA CONFIG ARRAY=""
 T_ALL_LIBC_CHOICES="AVR_LIBC BIONIC GLIBC MINGW_W64 MOXIEBOX MUSL NEWLIB NONE UCLIBC_NG":
CT_LIBC_SUPPORT_THREADS_NONE=y
CT_LIBC_PROVIDES_CXA_ATEXIT=y
  Common C library options
CT THREADS NONE=y
  end of C-library
 T_THREADS_NONE=y
  end of C-library
  C compiler
CT CC CORE NEEDED=y
CT_CC_SUPPORT_CXX=y
 T_CC_SUPPORT_FORTRAN=y
 CT_CC_SUPPORT_ADA=y
CT_CC_SUPPORT_OBJC=y
CT_CC_SUPPORT_OBJCXX=y
CT_CC_SUPPORT_GOLANG=y
CT_CC_GCC=y
CT_CC="gcc'
CT_CC_CHOICE_KSYM="GCC"
CT_CC_GCC_SHOW=y
  Options for gcc
CT_CC_GCC_PKG_KSYM="GCC"
CT GCC DIR NAME="gcc"
 T GCC USE GNU=y
CT_GCC_USE="GCC"
CT GCC PKG NAME="gcc"
CT GCC SRC RELEASE=y
# CT_GCC_SRC_DEVEL is not set
CT_GCC_PATCH_ORDER="global"
CT GCC V 11=y
```

# CT\_GCC\_V\_10 is not set # CT\_GCC\_V\_9 is not set # CT\_GCC\_V\_8 is not set # CT\_GCC\_V\_7 is not set

```
# CT_GCC_V_10 is not set
# CT_GCC_V_9 is not set
# CT_GCC_V_8 is not set
# CT_GCC_V_7 is not set
# CT_GCC_V_6 is not set
# CT_GCC_V_5 is not set
# CT_GCC_V_5 is not set
CT_GCC_VERSION="11.2.0"
CT<sup>-</sup>GCC<sup>-</sup>MIRRORS="$(CT Mirrors GNU gcc/gcc-${CT GCC VERSION}) $(CT Mirrors sourceware gcc/releases/gcc-${CT GCC V
ERSION})
ERSION})"
CT_GCC_ARCHIVE_FILENAME="@{pkg_name}-@{version}"
CT_GCC_ARCHIVE_DIRNAME="@{pkg_name}-@{version}"
CT_GCC_ARCHIVE_FORMATS=".tar.xz .tar.gz"
CT_GCC_SIGNATURE_FORMAT=""
CT_GCC_later_than_11=y
CT_GCC_11 or_later=y
CT_GCC_later_than_10=y
CT_GCC_10 or later=y
CT_GCC_tater_than_10=
CT_GCC_10_or_later=y
CT_GCC_1ater_than_9=y
CT_GCC_later_than_8=y
CT_CC_GCC_CORE_EXTRA_CONFIG_ARRAY=""
CT_CC_GCC_EXTRA_CONFIG_ARRAY=""
CT_CC_GCC_STATIC_LIBSTDCXX=y
  Optimisation features
CT CC GCC USE GRAPHITE=y
CT CC GCC USE LT0=y
CT CC GCC LTO ZSTD=m
# Settings for libraries running on target
CT CC GCC ENABLE TARGET OPTSPACE=y
# CT_CC_GCC_LIBMUDFLAP is not set
# CT_CC_GCC_LIBSSP is not set
   CT CC GCC LIBQUADMATH is not set
# Misc. obscure options.
CT_CC_CXA_ATEXIT=y
CT_CC_GCC_TM_CLONE_REGISTRY=m
# CT_CC_GCC_DISABLE_PCH is not set
CT CC GCC LDBL 128=m
# CT CC GCC BUILD ID is not set
CT CC GCC LNK HASH STYLE DEFAULT=y
# CT_CC_GCC_LNK_HASH_STYLE_SYSV is not set
# CT_CC_GCC_LNK_HASH_STYLE_GNU is not set
# CT_CC_GCC_LNK_HASH_STYLE_BOTH is not set
CT_CC_GCC_LNK_HASH_STYLE="'
CT_CC_GCC_DEC_FLOATS_AUTO=y
# CT CC GCC DEC FLOATS BID is not set
  CT CC GCC DEC FLOATS DPD is not set
# CT CC GCC DEC FLOATS NO is not set
CT CC GCC DEC FLOATS="'
CT_ALL_CC_CHOICES="GCC"
```

```
# Additional supported languages:
#
CT_CC_LANG_CXX is not set
# CT_CC_LANG_FORTRAN is not set
# end of C compiler
#
# Debug facilities
#
# CT_DEBUG GOB is not set
# CT_DEBUG GOB is not set
# CT_DEBUG_STRACE is not set
# CT_DEBUG_STRACE is not set
CT_ALL_DEBUG_CHOICES="DUNA GOB LTRACE STRACE"
# end of Debug facilities
#
# Companion libraries
#
# Companion libraries
#
# CT_COMP_LIBS_CHECK is not set
# CT_COMP_LIBS_CLOOG is not set
# CT_COMP_LIBS_EXPAT is not set
CT_COMP_LIBS_GRITEXT is not set
CT_COMP_LIBS_GMP=yc
CT_COMP_LIBS_GMP=yc
CT_COMP_LIBS_GMP=yc
CT_COMP_LIBS_GMP=yc
CT_COMP_LIBS_GMP=yc
CT_GMP_DIR_NAME="gmp"
CT_GMP_DIR_NAME="gmp"
CT_GMP_PRC_DEVEL is not set
CT_GMP_VERSION="6.2.1"
CT_GMP_VERSION="6.2.1"
CT_GMP_VERSION="6.2.1"
CT_GMP_VERSION="6.2.1"
CT_GMP_VERSION="6.2.1"
```