

Basic maintenance of a vehicle (Practical demonstration)

Exterior

Step 1 Organize cleaning materials.



Step 2 Fill up one of the buckets with warm water.



Basic maintenance of a vehicle

Practical demonstration (continues)

Step 3 Soak sponge in the soapy bucket and apply solutions to the car.



Step 4 Use hose or bucket of clean water to rinse off bubbles.



Basic maintenance of a vehicle

Practical demonstration (continues)

Step 5 Buff the car dry.



Step 6 Apply wax or polish for extra shine and protection.



Basic maintenance of a vehicle (Practical demonstration)

Interior

Step 1 Take out and clean floor mats.



Step 2 Vacuum the interior of the car.



Basic maintenance of a vehicle (Practical demonstration)

Interior

Step 3 Clean dust on the dashboard.



Step 4 Carefully clean the console.



Basic maintenance of a vehicle (Practical demonstration)

Interior

Step 5 Wipe interior windows.



Step 6 Take care of seats.



Basic maintenance of a vehicle (Practical demonstration)

Interior

Step 7 Deodorize.



Final maintenance.

