1. Please insure you have install USB driver of this radio on your computer.



- 2. Install the TP660/620 upgrade Setup software.
- 3. After installation, run this software. See figure 1






Figure 1

- 4. Connects your radio to pc by programming cable.
 - 5. Press PTT and top button (organge button on the top of radio) and turn on the radio at same time to enter upgrading mode. Then the red and green LED will flash.
 - 6. Click "Open upgrade file" to find upgrading file-"T P660_DMR-D1 1.18.bin".





7. Then click "download upgrade file" button to upgrade your radio.