

/tb_router/valid1
/tb_router/valid0
/tb_router/throughput_cnt
/tb_router/starvation_prev_cnt
/tb_router/reset
/tb_router/pass_count
/tb_router/out1
/tb_router/out0
/tb_router/latency_tracker
/tb_router/in1
/tb_router/in0
/tb_router/fail_count
/tb_router/crc_error1
/tb_router/crc_error0
/tb_router/conflict_cnt
/tb_router/clk
0
00000000000000000000000000001000
00000000000000000000000000000000
0 ps
50 ps
100 ps
150 ps
200 ps
250 ps
300 ps
350 ps
400 ps
450 ps
500 ps