





## **CAN Bus Line Driver**




## Level shifters














## H-Bridge Control Logic








## Control Logic Signals:

$$ENB == LOW -> Z$$

The Dual Bridges can be configured to run as a Mono Block. Jumper position (1-2) -> MONO mode. Jumper position (2-3) -> DUAL mode.

WARNING: ALL jumpers blocks must be set to the correct option.



LcsNodes-Dual-Block-Controller-Board - Bridge-Control - Page 4 of 7

