

Analog Input/Output part 1








Analog vs. Digital


Analog

- 영어의 analogous(비슷한) 에서 유래함
- 수학적으로 정확하게 표현하면, 아날로그는 연속적 = continuous

Digital

- 디지털의 어원은 손가락이라는 라틴어 digit에서 유래됨
- 디지털은 불연속적 = 이산적 = discrete





Analog vs. Digital

❖ 디지털의 장점

- 노이즈에 강하다
- 온도 특성이 좋다
- 데이터 처리가 편하다.


❖ 아날로그의 장점

■ 원본 데이터에 충실하다.



아날로그-디지털 변환 과정

- ❖ ADC (Analog to Digital Converter): 아날로그 데이터를 디지털 데이터로 변환
- ❖ DAC (Digital to Analog Converter): 디지털 데이터를 아날로그 데이터로 변환









❖ ADC 1단계: 필터링


- 본래 신호를 정확히 "표본화(Sampling)"하기 위해 잡음 등의 신호를 차단하는 과정
- Ex) 음성 신호의 경우 원하는 대역폭에 대한 신호만 필터링한다.


❖ ADC 2단계: 표본화 (Sampling)

- 아날로그 파형을 디지털 형태로 변환하기 위해 표본을 취하는 것을 의미
- 표본화율(Sampling Rate): 1초 동안에 취한 표본수(디지털화하는 횟수)를 말하며, 단위는 주파수와 같은 Hz를 사용















❖ ADC 2단계: 표본화 (Sampling)

- 아날로그 파형을 디지털 형태로 변환하기 위해 표본을 취하는 것을 의미
- 표본화율(Sampling Rate): 1초 동안에 취한 표본수(디지털화하는 횟수)를 말하며, 단위는 주파수와 같은 Hz를 사용
 - o.1초마다 샘플링을 수행하며, sampling rate는 10Hz








❖ ADC 2단계: 표본화 (Sampling)

 Sampling rate가 높아지면 본래 신호 특성을 더 잘 유지 할 수 있지만, 데이터양이 많아 진다.



❖ ADC 2단계: 표본화 (Sampling)

- 나이퀴스트 정리(Nyquist theorem)
 - 최대 주파수 성분이 f_{max} 인 아날로그 신호는 적어도 $2f_{max}$ 이상의 sampling rate로 샘플링할 경우 원 신호를 완전히 복원할 수 있다.
- 나이퀴스트 주파수 (Nyquist Rate) = 최소 샘플링 주파수
 - 표본화 정리에 따라 원래의 정보를 재생할 수 있도록 신호가 갖는 최고 주파수(f_{max})의 두 배가 되는 표본화 주파수(f_s)를 말함
 - $f_s = 2f_{max}$






❖ ADC 3단계: 양자화 (Quantization)

- 표본화에서 얻어진 수치를 대표 값으로 n 개의 레벨로 분해하고, 샘플 값을 근사 시키는 과정
- 디지털 형태로 표현할 때 어느 정도의 정밀도를 가지고 표현할 것인지를 의미.
- 표본화된 각 점에서 값을 표현하기 위해 사용되는 비트 수

❖ ADC 4단계: 부호화 (Coding)

■ 양자화된 값을 비트로 변환






아날로그 데이터 처리

❖ 아날로그 데이터 입력

- ATmega256o 마이크로컨트롤러에는 16채널의 10비트 해상도 아날로그-디지털 변환기 (ADC)가 포함되어 있음
- 각 채널에는 'Ao'에서 'A15'까지의 상수가 할당
 - Ao는 디지털 54번, A15는 디지털 69번과 동일함





아날로그 데이터 입력

❖ 16 채널의 ADC


■ 하나의 아날로그-디지털 변환기를 공유하므로 동시에 여러 채널 사용은 불가능

❖ 10비트 해상도


- o에서 1023 사이의 정수값 반환
- 1023에 해당하는 기준 전압은 ATmega256o의 동작 전압인 5V가 일반적으로 사용됨
 - 기준 전압은 analogReference 함수로 변경 가능
- 5V / 1024 ≅ 4.9mV 전압 차이 인식 가능



❖ 아날로그 신호를 디지털화 하여 인코딩 하는 방법










- Pulse Width Modulation (PWM) is a technique of modulation of a digital signal in order to obtain an analog value.
- It based on generating a square wave with a given frequency
- In the square wave, the "0" part and the "1" part have different duration
- **❖** The difference, in percentage, is called duty cycle





The Duty Cycle is defined as the percentage of Ton with respect to the total period Ppwm of the signal:





PWM has multiple utilisations:

- 1. To simply transfer an analog value over a digital line; devices receiving a PWM signal can interpret the "analog value" by measuring the duration of the "1" part with respect to the total frequency;
- 2. To modulate a typical on/off system; e.g. to change the intensity of a light generated by a lamp, a LED, etc.;
- 3. To drive power systems without affecting performances; e.g. To drive a DC motor.



아날로그 데이터 처리

❖ 아날로그 데이터 출력

- ATmega256o에서 아날로그 데이터 출력은 불가능
- 펄스 폭 변조(PWM:Pulse Width Modulation) 신호를 통해 아날로그 데이터 출력과 유사한 효과를 얻을 수 있음
 - PWM 신호는 디지털 신호의 일종임
 - PWM 신호 출력 함수가 analogWrite이므로 흔히 아날로그 데이터 출력으로 불림
- 15개의 핀으로 PWM 신호 출력 가능
 - 디지털 2번~13번
 - 디지털 44번 ~ 46번
- o과 255 사이의 값을 출력



아날로그 데이터 입출력 함수

int analogRead(uint8_t pin)

- 매개변수

• pin : 핀 번호

• **반환값**: 0에서 1023 사이의 정수값

void analogReference(uint8_t type)

- 매개변수

• type : DEFAULT, INTERNAL, INTERNAL1V1, INTERNAL2V56, EXTERNAL 중 한 가지

■ 반환값 : 없음

void analogWrite(uint8_t pin, int value)

- 매개변수

• pin : 핀 번호

* value: 듀티 사이클(duty cycle). 0(항상 OFF)에서 255(항상 ON) 사이의 값

• **반환값** : 없음



기준 전압 설정 옵션

| 옵션 | 설명 |
|--------------|---|
| DEFAULT | μC의 동작 전압(5V)으로 설정 |
| INTERNAL | 내부 기준 전압(1.1V)으로 설정 ATmega2560에서는 사용 불가능 |
| INTERNAL1V1 | 내부 1.1V로 설정 ATmega2560에서만 사용 가능 |
| INTERNAL2V56 | 내부 2.56V로 설정 ATmega2560에서만 사용 가능 |
| EXTERNAL | AREF 핀에 인가된 0~5V 사이 전압으로 설정 |





Analog Input with a Potentiometer


- Experimental Sequence
- Connecting a Potentiometer and printing Out the Resistance Value (Sketch 7-1)
- ② Lighting 4 LEDs According to the Value of a Potentiometer (Sketch 7-2)
- **3** Check the Result






1 Connecting a Potentiometer

❖ A potentiometer is a simple knob that provides a variable resistance









1 Printing out the Resistance Value of a


Potentiometer

```
Sketch 7-1
```

```
int vResistor = A0; // Pin A0 connected to a Potentiometer

void setup() {
   Serial.begin(9600); // Open the serial port at 9600 bps
   pinMode(vResistor, INPUT);
}


void loop() {
   // Read the value form a potentiometer and print it
   Serial.println(analogRead(vResistor));
   delay(1000); // Wait for a second (1000ms)
}
```







2 Controlling a LED Lighting using a Potentiometer



Reuse the potentiometer circuit of experiment ①

Control the number of LEDs turned on, according to the resistance value of the potentiometer





2 Controlling a LED Lighting using a Potentiometer

Sketch 7-2

```
int vResistor = A0; // Pin A0 connected to a Potentiometer
int pins_LED[] = {2, 3, 4, 5}; // Pins connected to LEDs
void setup() {
 Serial.begin(9600); // Open the serial port at 9600 bps
 pinMode(vResistor, INPUT);
 for (int i = 0; i < 4; i++) {
   pinMode(pins LED[i], OUTPUT);
   digitalWrite(pins LED[i], LOW);
                                           Conversion of 10 bit value into 2 bit
                                           value through bit shifting
void loop() {
 int adc = analogRead(vResistor); // Read the value form a potentiometer
 int count led = (adc >> 8) + 1; // Calculate the number of LEDs turned on
 for (int i = 0; i < 4; i++) { // LEDs output
   if (i < count led)</pre>
     digitalWrite(pins_LED[i], HIGH);
   else
     digitalWrite(pins_LED[i], LOW);
 // Printing out the ADC value and the number of LEDs turned on
 Serial.println(String("ADC : ") + adc + ", LED count : " + count led);
 delay(1000); // Wait for a second (1000ms)
```





3 Check the Result

- Show your Sketch code
- **❖** Show the execution of Sketch 7-2
- **❖** Answer the TA's questions and insert the score result to PLMS LAB 5





PWM Analog Output

- Experimental Sequence
- **1** Adjusting the Brightness of RGB LED (Sketch 7-3)

Keep the circuit for 4 LEDs

- 2 Adjusting the Brightness of LEDs using a Potentiometer (1) (Sketch 7-4)
- 3 Adjusting the Brightness of LEDs using a Potentiometer (2) (Sketch 7-5)
- **4** Check the Result







❖ RGB LED


- Consists of one common pin and three R,G,B control pin
- In the case of common anode type, GND output for a control pin make the light turn on (cf. Common cathode)


Brightness Control : Common anode type

- Maximum brightness : analogWrite(o)
- Minimum brightness: analogWrite(255)














1 Connecting an RGB LED







1 Adjusting the Brightness of an RGB LED

```
Sketch 7-3
// Pins connected to an RGB LED
                                       // Adjusting Green color.
                                       // Turn off Blue and Red color
int RGB_LED[] = \{6, 7, 8\};
                                         digitalWrite(RGB_LED[0], HIGH);
void setup() {
                                         digitalWrite(RGB LED[2], HIGH);
  for (int i = 0; i < 3; i++) {
                                         for (int i = 255; i >= 0; i--) {
    pinMode(RGB_LED[i], OUTPUT);
                                            analogWrite(RGB LED[1], i);
                                           delay(10);
void loop() {
                                       // Adjusting Red color.
  // Adjusting Blue color.
                                       // Turn off Green and Blue color
  // Turn off Green and Red color
                                         digitalWrite(RGB LED[0], HIGH);
  digitalWrite(RGB_LED[1], HIGH);
                                         digitalWrite(RGB LED[1], HIGH);
  digitalWrite(RGB_LED[2], HIGH);
                                         for (int i = 255; i >= 0; i--) {
  for (int i = 255; i >= 0; i--) {
                                            analogWrite(RGB_LED[2], i);
    analogWrite(RGB LED[0], i);
                                           delay(10);
    delay(10);
```





2 Adjusting the Brightness of LEDs using a

Potentiometer (1)

Sketch 7-4

```
int pins LED[] = \{2, 3, 4, 5\}; // Pins connected to LEDs
void setup() {
  Serial.begin(9600);
  for (int i = 0; i < 4; i++) {
     pinMode(pins LED[i], OUTPUT);
  pinMode(A0, INPUT); // Pin A0 connected to a Potentiometer
void loop() {
  int ADC value = analogRead(A0); // ADC value
  int PWM value = ADC_value >> 2; // PWM value
  Serial.print(String("ADC value : ") + ADC value);
  Serial.println(String(", PWM value : ") + PWM value);
  for (int i = 0; i < 4; i++) { // Adjusting the brightness of LEDs
     analogWrite(pins LED[i], PWM value);
                                                                                                COM10
                                                                                                                      전송
  delay(1000);
                                                                          MDG VATAE - TOTO, TWM VATAE - 234
                                                                          ADC value: 1019, PWM value: 254
                                                                          ADC value: 1018, PWM value: 254
                                                                          ADC value : 900, PWM value : 225
                                                                          ADC value: 765, PWM value: 191
                                                                          ADC value: 676, PWM value: 169
                                                                          ADC value : 540, PWM value : 135
                                                                          ADC value : 397, PWM value : 99
                                                                          ADC value: 300, PWM value: 75
                                                                          ADC value: 70, PWM value: 17
                                                                          ADC value : 12, PWM value : 3
                                                                          ADC value : 12. PWM value : 3
                                                                                                  새 줄
                                                                                                             9600 보드 레이트
                                                                          ✔ 자동 스크롤
```




Lab.5-2 3 Adjusting the Brightness of LEDs using a

Potentiometer (2)

```
int pins_LED[] = {2, 3, 4, 5}; // Pins connected to LEDs
void setup() {
  Serial.begin(9600);
  for (int i = 0; i < 4; i++) {
    pinMode(pins LED[i], OUTPUT);
  // Pin A0 connected to a Potentiometer
  pinMode(A0, INPUT);
void loop() {
  int ADC value = analogRead(A0); // ADC value
  int PWM value [4] = \{0, \};
  Serial.println(String("ADC value : ") + ADC value);
 for (int i = 3; i >= 0; i--) {
  // Calculating the brightness of each LED
    if (ADC value >= 256 * i) {
      PWM value[i] = ADC value - 256 * i;
      ADC value -= (PWM value[i] + 1);
    // Adjusting the brightness of LEDs
    analogWrite(pins_LED[i], PWM_value[i]);
    Serial.print(" ");
    Serial.print(PWM value[i]);
  Serial.println();
  delay(500);
```

Sketch 7-5







4 Check the Result

- Show your Sketch code
- **❖** Show the execution of Sketch 7-3 and 7-5
- ❖ Answer the TA's questions and insert the score result to PLMS LAB 5



맺는말

❖ 아날로그 데이터 입력

- 10비트 해상도의 ADC를 통해 0~1023 사이의 양자화된 디지털 값 입력
- 16 채널
- 1023에 해당하는 기준 전압을 설정하여야 함

❖ 아날로그 데이터 출력

- ATmega256o에는 DAC가 없으므로 아날로그 데이터 출력은 불가능
- 디지털 신호의 일종인 펄스 폭 변조 신호를 통해 아날로그 데이터와 유사한 효과를 얻을 수 있음
- LED 밝기 제어, 모터 속도 제어 등에 PWM 신호가 사용





Write a Sketch code performs the following operation

- Turns on 4 LEDs in order
 - Each LED is connected to digital pin 2,3,4,5, respectively
- Turns on a LED with adjusting the brightness from 0% to 100% using PWM
 - For example, the brightness of the LED connected to digital pin 2 is adjusted from o(0%) to 255(100%), then initialized to o(0%)

| Digital pin | Initial Brightness | Initial analogWrite value |
|-------------|-----------------------|------------------------------|
| 2 | 0% | 0 |
| 3 | 25% | 63 |
| 4 | 50% | 127 |
| 5 | 75% | 191 |

- Submission
 - Insert your Sketch code to PLMS HW 5
 - Submit a link to the video recording the result of your work.

