

		TITLE: TASK RISK ASSESSMENT			DOCUMENT NUMBER: FC-GL-EHS-MAN-0501-F3 (Tab Q)									
		REGION: GLOBAL		ISSUE: 7		DATE: 21-Sep-2021		PAGE: 1 of 1						
WORK ACTIVITY:		PROCEDURE REFERENCE NUMBER			Iss / Rev		TRA No.		Iss / Rev: Date:					
Management of Laydown Area(s)		FC-EHS-Laydown Areas-Fundamentals			1.0		TRA_FC-EHS-Laydown Areas-Fundamenta		1.0 21-Sep-2022					
PERSONNEL IMPACTED (Tick all applicable)														
☒ FieldCore Employees ☐ GE Employees ☒ Customer ☒ Contractors ☒ Affiliates ☐ Public ☐ Others (Specify)														
Special Notes: This TRA focusses on the fundamentals of managing of Laydown Area. Every task needs also to be assessed bringing all the aspects of the workplace, task to be done and tools to be used into consideration. Apply the controls documented within this TRA in addition to the controls that need to be applied specific to the task.														
Severity		Frequency			SEVERITY					Risk Rating		Strategy		
					S1 S2 S3 S4 S5 F5 5 6 7 8 9 F4 4 5 6 7 8 F3 3 4 5 6 7 F2 2 3 4 5 6 F1 1 2 3 4 5					High		Intervention - (Critical Step)		
S4		Severe			F4			Quarterly			Medium		PPE cannot be assigned as a Primary Defense	
S3		Significant			F3			Annually			Low		Control	
S2		Moderate			F2			Bi-Annually					Do not proceed - additional defenses required	
S1		Minor			F1			> two years					Monitor	
													Maintain Defenses	
*Risk = (Severity + Frequency) -1														
TASK STEPS		POTENTIAL RISK (PR)				DEFENCES:		CONTROLLED RISK (CR)						
		HAZARDS:		S	F			PR*	S	F	CR*	SAFE METHOD OF WORK		
1	Traffic Movements In the laydown area.	Traffic Movements, Overhead lines, Materials blocking exits, Materials obscuring view		2	4	5	Banksman, Barriers, Warning Signs, Ground Loading Study, Access Control, Overhead Goalposts	2	1	2	Where reasonable access to vehicles into laydown areas should be restricted. The ground should be checked to ensure it can support the load of the vehicle and there are no uneven surfaces that could cause loss of control of the vehicle. Separation of vehicles and pedestrians should be effectively managed, ideally thorough barriers or with a dedicated banksman for low duration movements. Vehicles should not be parked where they can block access/egress or access to emergency equipment or where they can obscure safety critical line of sight. Where there are overhead electrical lines then goalposts must be deployed to prevent vehicle access that will infringe on electrical safety distances.			
2	Storage of Large and Heavy Materials in laydown area	Fragile Floor Surface, Materials blocking exits, Materials obscuring view, Obstacles in Pathway, Poor Lighting, Sharp Edges		2	3	4	Laydown Planning, Pallet Inspections, Ground Loading Study, Emergency Response Access/Egress checks, Walking Surface Inspection	2	1	2	The ground/floor must have a documented assessment to confirm that it can support the weight of the load without any type of instability or collapse (flooring SWL markings can be used where available) Large materials should be layed down where they do not block pathways, obscure view, block lighting or have sharp edges exposed to passing pedestrians. Pallets must be inspected before use and be able to securely support any load without becoming unstable			
3	Crane Operations	Suspended Loads, Dropped Objects, Soft Ground, Overhead lines		3	3	5	Banksman, Barriers, Crane/Lifting Plan, Examination Certification, Ground Loading Study, PPE Assessment, Pre-use Inspection, Warning Signs, Weather Forecasting, POWLA (Lifting)	1	2	2	A crane or lifting plan, supported by a POWLA, must be in place and effectively communicated to all affected persons. The ground hardness (load bearing capacity) must be assessed and documented by a qualified person. All lifting equipment must be certified as examined and fit for use and a pre-use inspection must also take place of any lifting accessories used. PPE assessment should be conducted to determine the level of PPE to be worn in the area when the crane is operating (e.g. safety helmets) Access to the area must be controlled by barriers and warning signs to ensure that nobody can enter the cone of danger of the drop object one during lifting operations.			

4	Forklift Operations	Forklift Operations, Soft Ground, Uneven Ground, Fragile Floor Surface, Traffic Movements	4	4	7	Trained Authorised Persons, Forklift Selection, Banksman, Ground Loading Study, Pre-use Inspection, Flashing Beacons, Seat Belt	2	2	3	The correct type of forklift must be selected for the terrain in which it will operate. Standard Warehouse forklifts should not be used on rough terrain as this can present a forklift rollover risk. Only authorised forklift operators may use the forklift and they must be trained and authorised for the type of forklift that they will use e.g. telescopic boom training or counter balance training. The forklift should be subject to a daily inspection and a pre-use inspection. Forklift movements in the laydown area must be supported with a banks person and the condition of the ground assessed, soft and uneven ground should be assessed to ensure forklifts cannot rollover.
5	Forklift Charging	Hazardous Substances, Trailing Hoses & Cables, Electric Shock, Fire Hazards, Explosive Atmosphere	2	3	4	Access Control, Cable & Hose Management, Fire Fighting Equipment/Alarms, Warning Signs, Electrical Protection (RCD/GFCI), Safety Data Sheets	1	1	1	Hydrogen can be released during charging so this must only be carried out in a well ventilated area. Charging units must be inspected, certified and have electrical protection i.e. MCB/Fuses Fire fighting and spill management equipment must be immediately available at the charging station. Hoses and Cables must be managed so as not to cause a trip hazard and access to the area should be restricted and marked with warning signs - absolutely no smoking near this area.
6	Operation of portable generators and lighting towers	Spills to Ground, Electric Shock, Overhead lines	3	3	5	Examination Certification, Overhead Goalposts, Electrical Protection (RCD/GFCI), Spill Kits	2	1	2	Lighting towers must be collapsed before they are moved and movement must be planned so as not to encroach the safety distance of any overhead electricity lines. The generators must be certified and inspected and have electrical protection built into their operational controls. Refuelling must be done with spill prevention measures in place - any spills, not matter how minor must be managed and remediated immediately and reported into Gensuite.
7	Storage and use of chemicals	Hazardous Substances, Fire Hazards, Releases to Land, Releases to Water	1	4	4	Chemical Cabinet, Safety Data Sheets, Warning Signs, Spill Kits	1	2	2	The correct type and size of chemical cabinet should be in place with the correct provision to separate incompatible substances. The chemical cabinet should be marked with appropriate warning labels for the type of chemical and hazard presented. Where required by risk the chemical cabinets should be grounded/earthed. Safety Data Sheets and emergency response materials (Spill kit, fire fighting & PPE) should be readily available to manage any type of incident.
8	Manual movement & storage of materials	Manual Handling, Poor Lighting, Dropped Objects, Uneven Ground, Wet Walking Surfaces, Heavy Objects, Sharp objects	3	4	6	Correct Manual Handling Technique, Walking Surface Inspection, Shelf Storage Planning, Anti-Slip Mats, Additional Lighting, POWRA	2	2	3	Good manual handling practice must be used every time a load is moved manually. If the load is very heavy then ensure that a second person or mechanical aid is used to assist. Ensure that the path of carrying the load is free from slip, trip & fall hazards prior to beginning the activity. Walk down the path and eliminate or mitigate any walking surface hazards. Heavy items should be stored to remove then without injury e.g. do not place very heavy objects on shelves above chest height where reasonable. Shelves need to be secure and persons should not stand on shelves to access materials. Cut resistant gloves must be worn for handling any materials.
9	Industrial Processes (Start-up/Shut-down & routine operation)	Explosive Atmosphere, Fire Hazards, Hot Surfaces, Noise, Rotating Equipment, Electricity	4	2	5	Access Control, Barriers, Container Positioning, Laydown Planning, Warning Signs, Stop Work,	3	1	3	Laydown planning must account for any potential plant operations whether they are routine, start-up, testing or shutdown. Not laydown materials should be in the line of fire of any plant related event. All equipment must be outside of any zone where there is the potential of an explosive atmosphere, hot surface, rotating equipment or noise that may cause harm. Barriers and warning signs must be in place to control access to any plant area that can be impacted by operation. If the risk to employees from operational plant cannot be eliminated or mitigated to a low risk then a STOP Work must be called.

10	Laydown management in challenging weather conditions.	Fragile Floor Surface, Soft Ground, Wet Walking Surfaces, Spills to Ground, High Winds, Lightning	2	4	5	Weather Forecasting, Walking Surface Inspection, Ground Loading Study, Management of Change	1	3	3	Weather conditions should be reviewed ahead using weather forecasting. Heavy rain can soften ground conditions so planning should be in place to ensure a qualified person can reassess ground conditions where safety may be compromised by weather. Wind conditions can impact lifting operations so where wind speed increase or is predicted to increase mitigation should be planned in advance to prevent lifting operations that may be negatively impacted by wind. Heavy rain can also impact spill prevention strategies so spill trays and other spill prevention measures need extra attention and management during heavy rain conditions.
11	Positioning of tool and accommodation containers.	Materials blocking exits, Materials obscuring view, Poor Lighting, Soft Ground, Uneven Ground, Wet Walking Surfaces, Door Hazards	2	4	5	Container Positioning, Door Vision Panel, Housekeeping, Walking Surface Inspection, Latched Doors, Step/Stair Management	2	1	2	Tool and accommodation containers should not block walkways or emergency access routes or obscure line of sight and impact lighting conditions. Doors on containers should be latched and have door dampers and vision panels fitted where there is a risk of them slamming or opening onto personnel. Steps from containers should be even and fitted with hand rails and should exit onto a good even walking surface.
12	Walking around the laydown area	Materials blocking exits, Materials obscuring view, Poor Lighting, Soft Ground, Uneven Ground, Wet Walking Surfaces, Slippery Walking Surface, Trip and Fall Hazards	2	4	5	Cable & Hose Management, Housekeeping, Step/Stair Management, Walking Surface Inspection, Management of Change, Safety Signs	2	2	3	The walking areas must be inspected frequently and any slip, trip or falls hazards managed immediately. This requires personnel to carefully walk down personnel routes frequently and this should also happen formally when there is a significant change to the laydown area e.g. new materials or adverse weather. Steps need to be constructed and inspected so that they are not uneven or exit onto uneven walking surfaces. Hazard Hunts to identify Slip, Trip and Fall Hazards should be conducted periodically.
13	Use of Flatbeds for Storage	Falls from Height, Dropped Objects	3	3	5	Elevated Access Platform., Dropped Object Prevention Equipment, Chocked Wheels, Fall Arrest	2	1	2	There should be certified access platforms to access the flatbed. Materials should be stored stably on the flatbed to prevent objects falling off. Dropped object prevention measure such as netting, access control should be employed near any flatbed storage location. Fall arrest equipment must be worn where there are unprotected edges where the fall is greater than 6ft (1.8m)

EQUIPMENT / MATERIAL / PPE REQUIRED

Cut resistant gloves, coveralls, safety helmet, safety glaseses and safety shoes in line with FieldCore PPE procedure requirements. Fire Fighting/Prevention Equipment. Spill Prevention Kits. Chemical Cabinets, Safety Data Sheets and Chemical PPE as required. Certified Elevated Work Platform. Fall restraint/Harness with 100% tie-off if required when there is an unprotected edge presents a fall hazard of 6ft (1.8m).

ASSESSED BY	SIGNATURE:		PRINT NAME:	Mark Edwards	DATE:	21-Sep-2022
REVIEWED & APPROVED BY	SIGNATURE:	Mo Naser	PRINT NAME:	Mo Naser	DATE:	21-Sep-2022