

	TITLE:		DOCUMENT NUMBER:			
	TASK RISK ASSESSMENT		REGION: GLOBAL	ISSUE: 5	DATE: 30-April-2020	PAGE 1 of 1

WORK ACTIVITY:	REFERENCE NUMBER (Reference Procedure)	WDI Rev. No.	Date:
Mobile Elevated Platforms to include Cherry Pickers	TRA_MEWPs_Generic	N/A	14th June 2022

PERSONNEL IMPACTED (Tick all applicable)

☒ FieldCore Employees
 ☒ GE Employees
 ☒ Customer
 ☒ Contractors
 ☒ Affiliates
 ☐ Public
 ☐ Others (Specify) _____

Severity		Frequency		FREQUENCY	SEVERITY					Risk Rating	Strategy	
S1	S2	S3	S4		S5							
S5	Major	F5	Monthly		F5	5	6	7	8	9	High	Intervention - (Critical Step)
S4	Severe	F4	Quarterly		F4	4	5	6	7	8	Medium	PPE cannot be assigned as a Primary Defense
S3	Significant	F3	Annually		F3	3	4	5	6	7		Control
S2	Moderate	F2	Bi-Annually		F2	2	3	4	5	6		Do not proceed - additional defenses required
S1	Minor	F1	> two years	F1	1	2	3	4	5	Low	Monitor	
Maintain Defenses												

*Risk = (Severity + Frequency) -1

TASK STEPS		POTENTIAL RISK (PR)			DEFENSES:	CONTROLLED RISK (CR)				
		HAZARDS:	S	F		PR*	S	F	CR*	
1	Operating near people	Collison with pedestrians, Dropped Objects	4	2	5	Banksman, Barriers, Certified Operators, Flashing Beacon, High Visibility clothing, Route Planning, Secure loose Items, Segregate MEWP and Personnel, Fall Arrest (harness)	3	1	3	A Fall Arrest Harness attached to a secure anchor point must be worn at all times when working on a MEWP. Plan the route of the MEWP and ensure that barriers or banksman are used to ensure seperation of the MEWP and pedestrians. Make sure the work platform is fitted with effective guard rails and toe boards. Barrier off the area around the platform so that falling tools or objects do not strike people below.
2	Operating near overhead electric lines	Electric Shock	4	2	5	Banksman, Barriers, Certified Operators, Route Planning, Overhead lines approach boundaries, Overhead lines warning signs	1	1	1	Route planning, barriers, warning signs and a banksman should be in place to ensure operators do not operate a MEWP close to overhead cables. Where reasonable overhead cables should be de-energised using LOTO.
3	Operating near suspended moving loads	Struck by Moving load, Dropped Objects, Fall from Height	4	3	6	Banksman, Barriers, Certified Operators, Route Planning, Stop Crane Operations, Fall Arrest (harness)	1	1	1	Where reasonably possible all crane operations should be suspended if they can bring moving suspended loads into the safe approach zone of the MEWP. Where suspended loads need to be handled by MEWP operators then there should be an effective and tested communication system set-up between the MEWP and Crane operators.
4	Operating near fixed objects & structures	Entrapment between platform and fixed structure., Crush Injury	3	3	5	Banksman, Barriers, Certified Operators, Fall Arrest (harness), Route Planning, Hard Hats	2	1	2	Ensure that the area is surveyed and any potential crush or trap points are identified and a plan to avoid them is in place. There should be a rescue plan in place to rescue personnel in the event of an unplanned incident. A Safety Helmet secured with a chin strap must be worn when operating a MEWP.
5	Keeping MEWP Stable	Ground Unable to Support weight, Unstable/Uneven Surfaces, Unstable in High Winds	5	2	6	Outriggers, Spreader Plates, Ground Hardness Monitor, Wind speed Monitor, Basket Load control, Fall Arrest (harness)	2	1	2	The platform should be used on firm and level ground. Any temporary covers should be strong enough to withstand the applied pressure. Localised ground features, eg trenches, manholes and uncompacted backfill, can all lead to overturning. Outriggers must be extended and chocked before raising the platform. Spreader plates may be necessary. Ensure that the basket, or work platform, is not overloaded with weight to make the MEWP unstable. There should be a rescue plan in place to rescue personnel in the event of an unplanned incident.
6	Use of MEWP during poor weather conditions	Unstable in High Winds, Unstable/Uneven Surfaces, Dropped Objects, Fall from Height, Ground Unable to Support weight	4	2	5	Certified Operators, Maintenance and Pre-use Inspection, Ground Hardness Monitor, Wind speed Monitor	1	1	1	High winds can tilt platforms and make them unstable. Set a maximum safe wind speed for operation. Storms and snowfalls can also damage platforms. Inspect the platform before use after severe weather. Heavy rain can cause the ground to soften and this situation should be carefully monitored in the event of prolonged rain or a period of heavy rain.

7	Managing people, equipment and tools at height	Dropped Objects, Fall from Height	2	4	5	Barriers, Basket Load control, Fall Arrest (harness), Guard Rails, High Visibility clothing, Housekeeping, Pre-Use Inspection, Secure loose Items	1	1	1	Make sure the work platform is fitted with effective guard rails and toe boards. if used to install materials check the weight and dimensions of materials and consider any manual handling and load distribution issues. You may need additional lifting equipment to transport materials to the work position. Keeping the platform tidy will reduce the risk of the operator tripping or losing balance while in the basket
8	Transporting the MEWP between work areas	Collison with pedestrians, Unstable/Uneven Surfaces, Collision with overhead electric lines	4	2	5	Segregate MEWP and Personnel, Route Planning, Flashing Beacon, Certified Operators, High Visibility clothing	1	1	1	Moving the MEWP should be carefully planned to ensure that pedestrian and other traffic are not impacted. High Visibility clothing and flashing beacons will make the MEWP and pedestrians more visible. Roue planning executed and supported by a banksmans must be in place.
9	Managing technical failure of MEWP	Stranded at Height, Oil Leaks from MEWP	2	3	4	Spill prevention kit, Rescue Arrangement, Pre-Use Inspection	1	1	1	A pre-use inspection should confirm that the MEWP is certified and there are no obvious mechanical defects. Any oil leaks should be managed using spill prevention techniques at the very earliest oppportunity. In the event of mechanical failure there must be a plan in place to rescue any workers stranded on the MEWP platform.
EQUIPMENT / MATERIAL / PPE REQUIRED										
Fall arrest harness attached to a secure anchor point at all times. Safety Helmet with Chin Strap. Spill Prevention Kit. Spreader Plates. Wind Monitor.										
ASSESSED BY:		SIGNATURE: 			PRINT NAME: Mark Edwards			DATE: 14th June 2022		
REVIEWED & APPROVED BY		SIGNATURE: Gonzalo Arroyo Gomez			PRINT NAME: Gonzalo Arroyo Gomez			DATE: 14th June 2022		