

TITLE:
TASK RISK ASSESSMENT

DOCUMENT NUMBER:
FC-GL-EHS-MAN-0501-F3

REGION:
GLOBAL

ISSUE:
5

DATE:
30-April-2020

PAGE
1 of 1

WORK ACTIVITY:	REFERENCE NUMBER (Reference Procedure)	WDI Rev. No.	Date:
Lifting and Travelling using Telehandlers	TRA_Telehandlers_Generic	N/A	16th June 2021

PERSONNEL IMPACTED (Tick all applicable)

☒ FieldCore Employees ☒ GE Employees ☒ Customer ☒ Contractors ☒ Affiliates ☐ Public ☐ Others (Specify) _____

Severity	Frequency	SEVERITY	Risk Rating	Strategy
		S1 S2 S3 S4 S5		Intervention - (Critical Step)
S5 Major	F5 Monthly	F5 5 6 7 8 9	High	PPE cannot be assigned as a Primary Defense
S4 Severe	F4 Quarterly	F4 4 5 6 7 8	Medium	Control
S3 Significant	F3 Annually	F3 3 4 5 6 7		Do not proceed - additional defenses required
S2 Moderate	F2 Bi-Annually	F2 2 3 4 5 6	Low	Monitor
S1 Minor	F1 > two years	F1 1 2 3 4 5		Maintain Defenses

*Risk = (Severity + Frequency) -1

TASK STEPS		POTENTIAL RISK (PR)			DEFENSES:	CONTROLLED RISK (CR)			SAFE METHOD OF WORK
		HAZARDS:	S	F	PR*	S	F	CR*	
1	Travelling Around People	Struck By Telehandler Chassis, Struck by Moving load, Dropped Loose Components, Speeding	4	2	5	2	2	3	The supervisor must carry out a toolbox take before work starts covering the task to be carried out, personnel involved, work area, risks, exclusion zones and procedures. The load should then be secured, strapped down or fastened where necessary. If the load obscures the operator's view when travelling, a banksman should be used. A banksman should also be used when reversing. Seat belts must be worn at all times.
2	Keeping Telehandler Stable	Ground Unable to Support weight, Telehandler Overloaded, Telehandler component Failure, Unstable in High Winds, Speeding, Unstable/Uneven Surfaces	4	3	6	1	2	2	Before setting off, the boom should be telescoped in as far as possible and the load lowered as close to the ground as possible to increase stability whilst travelling. Seat belts must be worn at all times.
3	Using Handler for Suspended Loads	Struck by Moving load, Dropped Loose Components, Unstable in High Winds, Overhead Electrical Lines, Ground Unable to Support weight	2	3	4	2	2	3	When using extension forks the safe working limit should be reduced as the standard rated capacity. If the operator is unable to clearly see the load's final position, a qualified banksman should be used. Ensure ground conditions are stable to prevent overturning, ensure there are not power lines nearby. Make sure the load and radius of the lift does not cause the telehandler to become unstable and overturn. Rigging/slinging should be certified and attached by a competent person who should carry out a pre-lift briefing with all affected persons. Taglines and effective communication should be used to ensure the suspended load is secured. If there are high winds then the lift needs to be suspended.
4	Moving materials with Telehandler	Dropped Loose Components, Struck by Moving load, Struck By Telehandler Boom, Struck By Telehandler Chassis	2	3	4	1	2	2	The load should then be secured, strapped down or fastened where necessary. Seat belts must be worn at all times. Before lifting the load the operator should check ground conditions to make sure it is suitable for them to drive and use stabilisers on and place the load onto. Spreader mats should be used if the ground conditions or weight of the load make it necessary to do so
5	Driving Telehandler on Site Roads	Speeding, Overhead Electrical Lines, Unstable/Uneven Surfaces	4	3	6	1	2	2	Seat Belts to be worn at all times. Ensure that the Telehandler is maintained in a good condition e.g. tyres etc... Before setting off, the boom should be telescoped in as far as possible and the load lowered as close to the ground as possible to increase stability whilst travelling.

6	Attaching Rigging and Slings (Work at height)	Work at Height, Manual Handling	2	3	4	Ladder, Correct Manual Handling Technique	1	1	1	When attaching or removing rigging and slings at height then a secure ladder or elevated platform should be used to prevent climbing. The rigging can be heavy so good manual handling techniques should be used. Hold load close to body, keep back straight and use knees to bend. Use two people or mechanical lifting aids if the load is excessive in weight for one person.
7	Telehandler component Failure	Oil Leaks from Telehandler, Dropped Loose Components	1	4	4	Spill Kit, Secure Lose Items, Maintenance and Pre-use Inspection	1	1	1	The Telehandler should be maintained and examined within manufactureres recommendations and records should be avalable and checked to confirm. The Telehandler should be subject to a daily pre-use inspection. Spill kits should be availaable and the Telehandler should be inspected for Hydraulic and Engine Oil leaks on a daily basis.
8	Preventing Driver Distraction	Dropped Loose Components, Radio/Phone Use, Foot Control Configuration	2	3	4	Pre-Use Inspection, Certified Operators, Stop Vehicle	1	1	1	Radio and Mobile telephones shall not be used whilst the Telehandler is in motion. All loose materials must be secured to prevent objects dropping into the footwell and potentially interfering with the safe operation of the foot controls. Ensure the cab windows are clean and there are no marks or dirt to block view or distract the driver.
EQUIPMENT / MATERIAL / PPE REQUIRED										
All rigging and lifting equipment should be certified and pre-use inspected. High Visibility clothing for personnel in Telehandler operational area. Seat Belt fully functional and used. Daily Inspection checklist. Spill Kit.										
ASSESSED BY:		SIGNATURE: Mark Edwards			PRINT NAME: Mark Edwards			DATE: 16th June 2021		
REVIEWED & APPROVED BY		SIGNATURE: Mark Edwards			PRINT NAME: Mark Edwards			DATE: 16th June 2021		