

DIY PVC Chicken Feeder Guide

Materials & Tools Needed

- 3" PVC pipe (approx. 30" long)
- 3" PVC Y-connector + 3" extension
- 2 PVC end caps (top and bottom)
- Small nuts & bolts
- Lightweight chain (~10")
- Optional: funnel, PVC cement, heat gun
- Tools: saw, drill, ruler, marker

Step 1: Cut the PVC Tube

1. Cut the PVC pipe to around 30".
2. Prepare a short 3" straight extension to connect under the Y-joint.

Step 2: Add the Bottom Feeding Section

1. Attach the Y-connector at the bottom.
2. Add the short extension below the Y.
3. Cap the bottom for cleaning or pest prevention.

Step 3: Add the Feed Tray

1. Cut a shallow tray from a plastic bucket.
2. Position under the Y-connector and mark holes.
3. Drill and bolt it securely in place.

Step 4: Hanging & Filling

1. Drill two holes near the top for a chain.
2. Attach the chain with bolts.
3. Cap the top and fill with feed.

DIY PVC Chicken Feeder Guide

Benefits & Maintenance

- Easy to fill and clean
- Minimizes feed waste
- Pest and weather resistant
- Monitor feed level and check hardware monthly