

FLO Onboarding Portal

Comprehensive User Manual

Version 2.0 | April 2026

This manual documents the complete onboarding process for customers and FLO administrators. It covers all 5 phases, the 6 Pillars assessment, portal navigation, data intake, training, and go-live procedures.

DOCUMENT INFO

Prepared for	FLO BPA Compliance Platform customers and administrators
Maintained by	HAC Texas / FLO team
Contact	support@hacflo.com
Website	hacflo.com



Table of Contents

This manual is organized into 8 chapters. Use the table below to jump to a section. In Microsoft Word or Google Docs, right-click the table and select Update Field to refresh page numbers.

Table of Contents	2
1. Overview	3
1.1 What the Portal Does	3
1.2 Key Concepts	3
Phases	3
Steps	3
The 6 Pillars	3
Ball in Court	3
Next Step Card	3
1.3 Typical Timeline	4
2. Getting Started	5
2.1 Receiving Your Invitation	5
2.2 Signing In	5
2.3 Portal Navigation	5
2.4 Signing Out	5
3. Your Journey: The 5 Phases	7
3.1 Phase 1: Pre-Onboarding Assessment & Kick-off	7
The 6 Pillars Framework	7
Step 1a: Provide Your Organization Details	7
Step 1b: Schedule Your 6-Pillar Assessment Session	7
Self-Service Alternative	8
Step 1c: Confirm Your Testing Frequency Model	8
Step 1d: FLO Documents the Assessment and Prepares the Migration Plan	8
3.2 Phase 2: Data Collection & Migration	9
Step 2a: Send Us Your Data	9
Step 2b: Optional API Integration	9
Step 2c: FLO Cleans, Deduplicates, and Migrates Your Data	9
Step 2d: Review Your Data in Staging	9
Step 2e: Sign Off on Migrated Data	9
3.3 Phase 3: Setup & Configuration	10
Step 3a: Provide Your Branding	10
Step 3b: Joint Setup Session - Notice Templates	10
Step 3c: Joint Setup Session - Compliance Rules and Testing Frequency	10
Step 3d: Confirm Setup Looks Correct	10
3.4 Phase 4: Training	10
Step 4a: Schedule Training Sessions	10
Step 4b: Attend Utility Admin Training (2 hours, live)	11
Step 4c: Attend Utility Staff Training (1.5 hours, live)	11
Step 4d: FLO Publishes the Tester Self-Service Landing Page	11
Step 4e: Add Your Team Members to the Platform	11



3.5 Phase 5: UAT & Go-Live	11
4. Status Tab	13
4.1 Progress Banner	13
4.2 Ball-in-Court Indicator	13
4.3 Next Step Card	13
4.4 Action Item Columns	13
5. Master Data Spreadsheet (Optional)	14
5.1 Spreadsheet Structure	14
5.2 Tab Reference	14
5.3 Cross-References Between Tabs	15
6. Admin Panel (FLO Staff Only)	16
6.1 Project Setup	16
Project Fields	16
Creating the First Customer User	16
6.2 User Management	16
Adding Users	16
Available Roles	17
Removing Users	17
6.3 Phase Management	17
6.4 Reset Project	17
7. Frequently Asked Questions	18
8. Glossary	20



1. Overview

The FLO Onboarding Portal is your central workspace for getting your BPA Compliance Platform configured and live. It guides you through five sequential phases with clear instructions, real-time progress tracking, and unambiguous indicators of who owns each task at any moment.

1.1 What the Portal Does

- Walks you through 5 onboarding phases from Pre-Onboarding Assessment to Go-Live
- Tracks progress in real time with completion percentages and phase status
- Shows whose turn it is (yours, FLO's, or joint) for every task
- Captures organization details and compliance preferences directly in the portal
- Documents the 6-Pillar assessment with your CSM
- Accepts your data however you have it: raw files, master template, or shared link
- Gives FLO administrators tools to set up projects and manage users

1.2 Key Concepts

Phases

The onboarding process is divided into 5 sequential phases. Each phase contains a set of steps. Phases are not hard-locked: you can browse any phase to see what is expected, even if it is not the active one. Steps within each phase should generally be completed in order.

Steps

Each step belongs to a phase and has an owner: you (client), FLO, or both (joint). Client steps have clickable checkboxes. FLO steps show a clock icon and can only be marked complete by FLO administrators. Some steps include inline forms, file uploads, scheduling tools, or links to external resources.

The 6 Pillars

FLO's onboarding is built around the 6 Pillars of Cross-Connection Control compliance: Legal Foundation, Discovery, Protection, Testing, Remediation, and Inspection Continuity. Phase 1 includes a guided assessment of where your program stands on each pillar. This shapes how FLO is configured for your jurisdiction.

Ball in Court

The portal always shows whose turn it is. The Status tab displays a ball indicator showing whether you or FLO currently has pending action items. This makes handoffs transparent and prevents stalls.

Next Step Card

At the top of both the Journey and Status tabs, a highlighted card always shows the next action item that needs your attention. Click it to jump directly to that step in the right phase.



1.3 Typical Timeline

PHASE	DURATION	LEAD
1. Pre-Onboarding Assessment & Kick-off	Week 1	Joint
2. Data Collection & Migration	1-3 Weeks	Joint
3. Setup & Configuration	Half Day (Joint Session)	Joint
4. Training	Half Day (Joint Session)	Joint
5. UAT & Go-Live	3-5 Days	Joint

Tip: Total onboarding typically takes 6 to 8 weeks from kick-off to go-live, depending on data complexity and your team's availability for joint sessions.



2. Getting Started

2.1 Receiving Your Invitation

Your FLO Customer Success Manager (CSM) sets up your project in the Admin Panel and creates your user account. You will receive an email containing two pieces of information:

1. Your project code (e.g., SPR-2026-001)
2. Your login email address

No password required.

FLO uses passwordless access for the demo and pilot environments. You sign in with just your email and the project code. In the production hosted version, this will likely be replaced with a magic link or single sign-on. Your CSM will tell you which model is in use when your portal goes live.

2.2 Signing In

3. Open the portal URL in your browser. The portal works on desktop and mobile.
4. Enter your project code in the first field.
5. Enter your email address in the second field.
6. Click Sign In.

The portal opens to the Your Journey tab, which is your primary workspace.

Tip: If you see an error, verify that your project code matches exactly (it is case-sensitive) and that your email matches what your CSM registered.

2.3 Portal Navigation

The portal has two main tabs for customers and a third tab for FLO administrators:

TAB	PURPOSE	WHO SEES IT
Your Journey	Step-by-step phases with instructions, forms, scheduling, and file uploads	Everyone
Status	Overall progress dashboard with completion ring, ball-in-court indicator, and action item lists	Everyone
Admin	Project setup, user management, and phase status controls	FLO Admin and CSM only

2.4 Signing Out

Click your name and avatar in the top-right corner of the navigation bar. This signs you out and returns you to the login screen.



3. Your Journey: The 5 Phases

This chapter walks through each phase in detail. Each section covers the duration, lead, what happens, and every step inside the phase.

3.1 Phase 1: Pre-Onboarding Assessment & Kick-off

Duration: Week 1 | **Lead:** Joint (you and FLO together)

Phase 1 sets the foundation. Instead of asking you to fill out reams of paperwork, FLO comes to you. We walk through the 6 Pillars of Cross-Connection Control compliance together, document where your program stands, and use that picture to configure FLO around your reality. This phase is conversational. No data uploads are required.

The 6 Pillars Framework

The assessment is structured around the 6 pillars that define a complete CCC program:

PILLAR	NAME	FOCUS
P1	Legal Foundation	An up-to-date CCC ordinance is the legal basis for your entire program.
P2	Discovery	Every cross-connection hazard in your service area must be identified.
P3	Protection	Each location must have the correct BPA type for its hazard level.
P4	Testing	Regular testing per TCEQ regulations and city ordinance.
P5	Remediation	Failed tests must be corrected and verified with a passing retest.
P6	Inspection Continuity	CSI inspections close the loop and surface new hazards.

Step 1a: Provide Your Organization Details

An inline form appears in the portal capturing the basics: organization name, service area, state, project lead contact info, IT contact, approximate counts of facilities and tester companies, current legacy system, and team roles. Auto-saves as you type. Takes about 5 minutes.

Step 1b: Schedule Your 6-Pillar Assessment Session

This is the centerpiece of Phase 1. Click Schedule My Session to open a scheduling form. Pick a preferred date and time, and choose between in-person (HAC Texas comes to you) or virtual (Teams or Zoom). The session is 1 to 2 hours and walks through each pillar with your CSM and an HAC Texas expert.

Why a guided session is recommended: a real conversation with field experts surfaces program gaps and opportunities that a self-service questionnaire cannot. Most customers find this is the highest-value hour of the entire onboarding process.

Self-Service Alternative

If you prefer to look at things yourself first, the portal also links to the CCC Compliance Assessment tool. This tool covers the same 6 pillars and produces a score with recommendations.



Note on the assessment tool framing

The CCC Compliance Assessment tool was originally built for prospects evaluating their CCC program. Since you are already a FLO customer, the recommendations focus on general program health rather than FLO-specific configuration. Use it to surface gaps, but bring the results to your CSM session for the practical follow-up.

Step 1c: Confirm Your Testing Frequency Model

A dropdown with five options:

MODEL	DESCRIPTION
Calendar Year	All assemblies due by December 31. Compliance clock resets January 1. Creates year-end workload concentration.
Rolling 12 Months	Each assembly due 12 months from its last passing test. Spreads workload evenly throughout the year.
Fixed Anniversary	Each assembly due on the same date each year, anchored to installation or first test date.
Custom / Hybrid	Different frequencies for different assembly types or hazard levels (e.g., RP every 6 months, DC annually).
Not sure	Pick this if you want your CSM to help you decide based on your jurisdiction and ordinance.

Below the dropdown is a free-text field for notes and regulatory references. Use this to cite the state or local code that drives your choice.

Step 1d: FLO Documents the Assessment and Prepares the Migration Plan

This is a FLO-owned step. Your CSM compiles the assessment notes, identifies data gaps, and prepares a migration plan tailored to what you have. The clock icon indicates this step is in FLO's court.

Phase Completion

When all 4 steps are checked off, a celebration modal appears confirming Phase 1 is complete. The next phase activates automatically.

3.2 Phase 2: Data Collection & Migration

Duration: 1–3 Weeks | **Lead:** Joint

This is where your data moves into FLO. The most important thing to understand: you do not need to format your data into our template unless you want to. FLO does the cleanup, normalization, and migration regardless of how the data arrives.



Step 2a: Send Us Your Data

Two equal options are presented side by side. Pick whichever is faster for you. Both work the same way for FLO.

- Option A: Send what you have. Drop any files into the upload area. Excel, CSV, exports from your old system, scanned documents, anything. FLO parses and converts it.
- Option B: Use our master template. If you prefer structured data, download FLO_Onboarding_Forms.xlsx (8 tabs covering facilities, contacts, assemblies, testers, test history, surveys), fill it in offline, and upload it back.
- Or share a link. Paste a Google Drive, SharePoint, or Dropbox link instead of uploading. Make sure the link gives view access to your CSM.

Tip: Most customers find Option A faster, especially if they are migrating from a legacy system that already produces structured exports. Option B is helpful if you are starting from paper records and want a structured place to enter data manually.

Step 2b: Optional API Integration

If you want FLO to integrate with your utility billing system for automatic customer updates (addresses, ownership changes, account status), tell us now via a simple yes/no toggle. If you say yes, additional fields appear asking for the billing system name and a technical contact. Most customers skip this at launch and revisit it later.

Step 2c: FLO Cleans, Deduplicates, and Migrates Your Data

FLO-owned. We parse your files, normalize formats (addresses, phone numbers, dates), match facilities by address, link assemblies to facilities, and import everything into a staging environment. If we have questions during this process, your CSM will reach out.

Step 2d: Review Your Data in Staging

Joint. Your CSM walks you through the imported data on a call. Spot-check facilities, assemblies, contacts, and test history. Flag anything that looks wrong.

Step 2e: Sign Off on Migrated Data

Confirm the data in staging is accurate. This is the green light to proceed with platform setup.

3.3 Phase 3: Setup & Configuration

Duration: Half Day (Single Joint Session) | **Lead:** Joint

A single half-day working session where FLO and your team configure the platform together. Notice templates, branding, compliance rules, and notification automation all happen in one sitting. The goal is for you to learn how to make changes yourself, so you are not dependent on FLO for routine adjustments later.

Step 3a: Provide Your Branding

An inline form captures three pieces of information:

- Sender display name (e.g., Springfield Water – Backflow Compliance)



- Reply-to email address (where property owners and testers will reach you)
- Logo upload (PNG or JPG, transparent background preferred)

Step 3b: Joint Setup Session – Notice Templates

FLO provides default notice templates for: 60/30/7-day test due reminders, overdue notices, non-compliance escalation, tester certification expiry warnings, and gauge calibration expiry. In the joint session, you review each template, duplicate any you want to customize, and edit wording, regulatory references, or legal language to match your jurisdiction.

Step 3c: Joint Setup Session – Compliance Rules and Testing Frequency

Based on your Phase 1 answers, FLO configures the compliance calendar, due date calculations, grace periods, and notification triggers. You watch the configuration happen in real time so you can adjust later if needed.

Step 3d: Confirm Setup Looks Correct

Review the configuration summary together. Make any final tweaks before training begins.

3.4 Phase 4: Training

Duration: 1 Week | **Lead:** FLO

Your team learns how to use the platform. Training combines live sessions, self-service video content, and an in-platform AI assistant called Ask Flo for ongoing reference.

Step 4a: Schedule Training Sessions

Live sessions are scheduled with your CSM. Two sessions cover utility users; tester companies are handled separately via a self-service landing page.

Step 4b: Attend Utility Admin Training (2 hours, live)

Full platform walkthrough including: dashboard navigation, managing users, running compliance reports, customizing notice templates, the Resolution Center for failed tests, and configuration toggles.

Step 4c: Attend Utility Staff Training (1.5 hours, live)

Day-to-day platform usage including: searching facilities, viewing assemblies, reviewing test results, generating reports, and using Ask Flo for self-service help.

Step 4d: FLO Publishes the Tester Self-Service Landing Page

FLO-owned. Tester companies and field testers get their own login URL with video tutorials, an Ask Flo chatbot, and an 800-number fallback for users who prefer to call. Most testers find the platform intuitive and need minimal training.

Step 4e: Add Your Team Members to the Platform

Now that your admins know how, they add utility staff directly. User management is fully self-service from this point forward. No need to go through FLO for routine user adds, role changes, or removals.



Tip: Ask Flo is the in-platform AI assistant. Anyone can click the Ask Flo button to get instant answers to platform questions, find tutorial videos, or troubleshoot common issues. Encourage your team to use it before calling support.

3.5 Phase 5: UAT & Go-Live

Duration: 3–5 Days | **Lead:** Joint

The final phase. Your team tests the platform in production with real data, verifies everything works, and signs off. Then FLO flips the switch and your platform goes live.

7. Log in as Utility Admin and verify your dashboard.
8. Search 3 or more facilities and verify data accuracy against your source records.
9. Submit a test report in test mode (walk through the tester flow).
10. Trigger a notice send in test mode and verify the email arrives with correct content and branding.
11. Verify due dates calculating correctly for 3 or more assemblies.
12. Run a compliance status report and confirm the numbers make sense.
13. Sign off on UAT (formal approval).
14. Go-live confirmed. Platform is LIVE.

Your CSM provides 2 to 4 weeks of hypercare support after go-live. Hypercare means elevated responsiveness and priority assistance as your team transitions from onboarding to day-to-day operations.

4. Status Tab

The Status tab provides an at-a-glance dashboard of your onboarding progress. It contains four sections, each designed to answer a specific question.

4.1 Progress Banner

A dark teal banner at the top displays:

- Progress ring: Visual percentage of all steps completed across all 5 phases
- Current phase name and number
- Days remaining until your target go-live date
- Number of completed phases out of 5

4.2 Ball-in-Court Indicator

On the right side of the banner, a ball indicator answers the question "whose turn is it?"

- Your Turn (yellow background) when you have more pending items than FLO
- FLO's Turn (teal background) when FLO has more pending items
- Done (green background) when all steps are complete

4.3 Next Step Card

Below the banner, the Next Step card shows the single most important action item that needs your attention right now. Click it to jump directly to that step in the Journey tab.

4.4 Action Item Columns

Two side-by-side panels:

- Your Items: All incomplete steps assigned to you, sorted by phase. Click any item to jump to it in the Journey tab.
- Waiting on FLO: All incomplete steps assigned to FLO. Informational only (you cannot mark them complete).

5. Master Data Spreadsheet (Optional)

The FLO_Onboarding_Forms.xlsx file is an optional structured template you can use in Phase 2 if you prefer to enter data into a fixed format. It is one of two equally valid ways to submit your data. The other option is to send raw files in any format and let FLO handle the conversion.

Optional, not required.

If your existing system already exports clean data (Excel, CSV, or even paper records you can scan), it is usually faster to send what you have via Option A in Phase 2 and let FLO do the conversion. The master template is most useful when you are starting from scratch or want full control over the data structure.

5.1 Spreadsheet Structure

The workbook contains 16 tabs total: 8 data entry tabs and 8 corresponding instruction tabs. Each data tab has:

- A title section (rows 1–4) with the form name and instructions
- Column headers (row 6)
- Format notes (row 7) describing expected values for each field
- Data entry area (row 8 onward) with color-coded columns: yellow for required, grey for optional

5.2 Tab Reference

TAB	FORM NAME	ONE ROW PER	KEY FIELDS
A	Facilities / Locations	Physical location	Address, property type, water account #, hazard level
B	Contact Information	Contact (min. 1 per facility)	Contact type, name, email, phone, linked facility ID(s)
C	Assembly (BPA) Information	BPA assembly	Serial #, type (RP/DC/PVB/SVB), manufacturer, size, status
D	Tester Company	Licensed tester company	Company name, license #, expiry, primary contact
E	Tester User Accounts	Individual tester	Certification #, expiry, certifying org, platform role
F	Test Kit / Gauge	Gauge	Serial #, calibration date, expiry, manufacturer
G	Test History	Historical test event	Test date, result, assembly ID, tester name, PSI readings
H	CSI & Survey History	CSI/survey event	Survey date, type, hazard findings, corrective actions

5.3 Cross-References Between Tabs

Several tabs reference records in other tabs. These links matter for data integrity:

- Form B (Contacts) references Facility IDs from Form A

- Form C (Assemblies) references Facility IDs from Form A
- Form E (Tester Users) references Tester Company names from Form D
- Form F (Test Kits) references Tester Users from Form E and Companies from Form D
- Form G (Test History) references Assembly IDs from Form C, Facility IDs from Form A, and Tester names from Form E
- Form H (Survey History) references Facility IDs from Form A

Tip: If you choose to use the master template, fill in Form A (Facilities) and Form D (Tester Companies) first. Other tabs depend on the IDs you create in those two.

6. Admin Panel (FLO Staff Only)

The Admin tab is visible only to users with the Admin or CSM role. It provides three management sections accessed via the left sidebar.

6.1 Project Setup

The first screen you see when setting up a new customer. Configures the project itself and creates the first customer user in one form.

Project Fields

- Project Code (required): A unique identifier like SPR-2026-001
- Organization Name (required): The customer's name as displayed in the portal
- CSM Name: The assigned Customer Success Manager
- Target Go-Live Date: Drives the "Days Left" counter on the Status tab

Creating the First Customer User

Below the project fields, two more inputs let you create the customer's first user account:

- Full Name (required)
- Email (required)

Click Save & Create User to save the project and create the user simultaneously. A toast notification confirms the invitation was sent. The user can then sign in with their email plus the project code. No password is needed.

First Login Behavior

When a new project has not yet been saved, the portal automatically opens to the Admin tab so you can complete setup. Once the project is saved, subsequent logins open to the Journey tab.

6.2 User Management

View all users for the current project. The table shows name, email, and role. Add and remove users from this screen.

Adding Users

15. Click the + Add button in the section header.
16. Enter the user's name and email.
17. Select a role from the dropdown.
18. Click Add. A toast notification confirms the user was created.



Available Roles

ROLE	ACCESS LEVEL
Client Lead	Full customer access to Journey and Status tabs
IT Contact	Same as Client Lead, designated for technical coordination
Utility Staff	Same as Client Lead, for general staff members
CSM (FLO)	Full access including Admin tab; can mark FLO-owned steps complete
Admin (FLO)	Full access including all admin functions

Removing Users

Click the X button next to any user (except yourself) to remove them. You cannot remove your own account.

6.3 Phase Management

A table showing all 5 phases with a dropdown to change each phase's status:

- Pending: Not yet started. Visible to users but no steps are active.
- Active: Currently in progress. Steps can be checked off.
- Complete: All steps done. Shows a green checkmark and completion card.

Use this to manually activate a phase (e.g., if a customer needs to start Phase 2 work in parallel before Phase 1 is formally complete) or to mark a phase complete when work was confirmed outside the portal.

6.4 Reset Project

The Reset button on the Project Setup page clears all data and returns the portal to its initial empty state. This is destructive and cannot be undone. Use only in demo or testing situations.

7. Frequently Asked Questions

Do I have to use the master spreadsheet template?

No. Phase 2 offers two equal options: send raw files in any format, or use the structured master template. Both produce the same end result. Pick whichever is faster for you.

Can I work on phases out of order?

Yes. All phases are expandable and browsable from day one. You can read what is expected in any phase and start preparing. However, steps within a phase should generally be completed in sequence, and some steps depend on outputs from earlier phases.

What happens if I close the browser mid-phase?

All progress saves automatically. Form fields save as you type, and step completions save immediately. When you sign back in, everything is where you left it.

Can multiple people from my organization use the portal?

Yes. Your CSM can create multiple user accounts with different roles. All users on the same project see the same progress and can complete client-owned steps together.

What is the 6-Pillar Assessment and why does it matter?

The 6 Pillars are the foundation of a complete Cross-Connection Control compliance program: Legal Foundation, Discovery, Protection, Testing, Remediation, and Inspection Continuity. The assessment in Phase 1 documents where your program stands on each pillar, which helps FLO configure the platform around your reality and shows you where the biggest gaps are.

What if FLO finds errors in my data?

Your CSM will contact you with specific details about what needs fixing and where. You can correct the source data and re-upload, or your CSM can resolve clarifying questions on a call.

What does "Ball in Court" mean?

It shows whose turn it is right now. "Your Turn" means there are steps waiting for you. "FLO's Turn" means FLO has pending work. "Done" means all steps are complete.

How long does onboarding take?

Typically 6 to 8 weeks from kick-off to go-live. The biggest variable is Phase 2 (data collection), which depends on how quickly you can gather your source data. FLO-owned phases run on predictable timelines.

What is Ask Flo?



Ask Flo is the in-platform AI assistant available throughout FLO. Anyone can click the Ask Flo button to ask questions about how to use the platform, find tutorial videos, or troubleshoot common issues. It is the fastest way to get answers without contacting support.

What happens after go-live?

Your CSM provides 2 to 4 weeks of hypercare support (elevated responsiveness, priority assistance). After hypercare, you transition to standard support. The platform is fully self-service for day-to-day operations including user management, report generation, and notice customization.

8. Glossary

TERM	DEFINITION
BPA	Backflow Prevention Assembly: a device installed on a water supply line to prevent contaminated water from flowing back into the potable water supply.
RP	Reduced Pressure Zone Assembly: a type of BPA providing the highest level of protection.
DC	Double Check Valve Assembly: a type of BPA for low-to-moderate hazard applications.
PVB	Pressure Vacuum Breaker: a BPA commonly used for irrigation systems.
SVB	Spill-Resistant Vacuum Breaker: similar to PVB but resistant to back-pressure.
CCC	Cross-Connection Control: the regulatory program for preventing backflow contamination of potable water systems.
CSI	Customer Service Inspection: a Texas-specific term for the inspection that identifies cross-connection hazards at a facility. Other states call this a "survey."
TCEQ	Texas Commission on Environmental Quality: the state agency that oversees water utility regulation in Texas, including CCC compliance.
CSM	Customer Success Manager: your primary FLO contact responsible for onboarding coordination and ongoing support.
UAT	User Acceptance Testing: the final validation by the client before go-live.
Ask Flo	FLO's in-platform AI assistant for self-service help and tutorials.
LMS	Learning Management System: the self-paced video library for ongoing learning.
Hypercare	A period of elevated support (2 to 4 weeks) immediately following go-live.
The 6 Pillars	FLO's framework for a complete CCC program: Legal Foundation, Discovery, Protection, Testing, Remediation, Inspection Continuity.

End of Document

Compliance Done Right

FLO BPA Compliance Platform | hacflo.com | support@hacflo.com