


PLANT SIDE (Drake multibody)

ESTIMATOR SIDE (sensors only — truth-isolation lint)



commands are truth-free; the only state the estimator sees crosses through the sensor models (linted by class).