# ECSE 426 ISA, Assemblers and Labs

#### Zeljko Zilic

Room 536 McConnell Building

zeljko@ece.mcgill.ca

www.macs.ece.mcgill.ca/~zeljko







## Course Organization

- Prerequisites: ECSE-323 and EDEC 206
- Instructor: Prof. Zeljko Zilic, Rm. 546, McConnell

398-1834, Fax: 398-4470, MyCourses

e-mail: <u>zeljko@ece.mcgill.ca</u>

- Office Hours: Wed. 12:30-13:30; by appointment; online
- O TAS: A. Suyyagh, M. Janidarmian, S. Ding, C. Dong
- Tutorials: As announced throughout semester (Thu slot)
- Lab Demoing: Thu and Fri
- Manned Lab (TAs): Tue-Fri, as per calendar in MyCourses



#### Course Content

- Top-down approach to microprocessor programming and design
- Lectures focus on structured computer organization, and progress through "layers":
  - Problem-oriented language (embedded C) + assembly language
  - Instruction set architecture
  - Microarchitecture
  - Hardware
- Introduction of design principles and impact on real-world architectures
  - ARM Cortex M4 Architecture and ARM Cortex M family in general

Acknowledgements: Hamacher, Vranesic, Zaky, Manjikian for "Computer Organization and Emb. Systems". [HVZM11]



## Course Objectives Rephrased

- Understand microprocessor-based systems
- Get familiar with basic tools
- Skills in machine interfacing, assembler and embedded C programming
- Design a sizeable embedded system
  - Previous projects: Music player, file swapping system, PDAs (with handwriting recognition), wireless data collection systems
- Build teamwork skills




## Today's Lecture

- ISA
  - Processor Resources
  - Instruction Types
  - Addressing Modes
- Assembly Language and Tutorial Complement
  - Introduction to the ARM Assembler
  - Lab 1 Overview and Hints



#### Contemporary Multilevel Machines



## Assembly versus C

- Q: Why use assembly if programmers thing in abstract ways similar to problem oriented languages like C, and further programmers may not know the a structure of processors to take most advantage from assembly and machine languages?
- A: Assembly languages provide:
  - Efficiency of compiled code
  - Source code portability
  - Program maintainability
  - Typical bug rates (say, per thousand lines of code)
  - Availability and cost of compilers and other development tools
  - Your personal experience (or that of the developers on your team) with specific languages or tools
- Don't rule out Java or C++ if you have the memory to play with



# Problems with Low-level Languages

- Programs in low-level languages require detailed documentation, as otherwise they hard to read for people who were not involved in the process of the program creation
- Example: Company "Ostrich" has recently re-developed their embedded software for flagship products
  - Developed in assembly, 80 percent working, 2000 lines of code
- Suddenly it has been realized that the product is not shippable
- Bugs: system lock-ups indicative of major design flaws or implementation errors + major product performance issues
- Designer has left the company and provided few notes or comments
- You are hired as a consultant. Do you:
  - Fix existing code?
  - Perform complete software redesign and implementation? In this case, which language?




#### Problem-oriented Language layer

- Compiled to assembly or instruction set level
- You will be using embedded C
- How does this differ from usual use of C?
  - Directly write to registers to control the operation of the processor
  - All of the registers have been mapped to macros
  - Important bit combinations have macros use these, please!
  - Registers are 32 bits, so int type is 4 bytes
  - Register values may change without your specific instructions
  - Limited output system
  - Floating point operations very inefficient, divide + square-root to be avoided



#### Instruction Set Architecture

- Interface between HW and SW
  - Virtual Machine
    - Many possible implementations of ISA
- Given by
  - Resources
    - Processor Registers
    - Execution Units
  - Operations
    - Instruction Types
    - Data Types





## ARM Processor – Brief History

 ARM was developed as Acorn Computers Ltd., Cambridge, England (1983-1985)



- RISC processor concept was introduced in 1980s
- Advanced RISC Machines
- ARM Ltd. 1990




#### ARM Processor - Architecture

- A 32-bit Enhanced RISC processor with register-to-register, three operand instruction set
  - All operands are 32-bit wide
- Employs Load Store Architecture
  - Operations operate on registers and not in memory locations



#### ARM Cortex ISA: ARMv7-M

Implements Thumb2 specification




- Data movement: single and multiple word
- Data processing: arithmetic, logic, shift, rotate
- Branches: conditional, subroutine, table (case)
- State change: int. enable, spec. reg., ITE, SVC
- Semaphores, Barrier, Hint, Prefetch
- Coprocessor, floating-point, misc.



## ARM Registers

- Large register set
  - 16 general purpose registers
  - Program Counter (R15)
  - Link Register (R14)
  - Stack Pointer (R13)
- Registers R0-R3 hold first
   4 words of incoming
   argument





## Summary of ARM Register Set

- 16 accessible 32-bit registers (R0-R15) at any time
  - R15 acts as Program Counter (PC)
  - R14 (Link Register) stores subroutine return address
- You can write in ARM assembly language:
  - PC for R15,
  - Ir for R14,
  - sp for R13
- Current Program Status register (CPSR) that holds conditional codes
- Some registers are not unique as processor exceptions create new instances of R13 and R14
- As return address is not necessarily saved on the stack by a subroutine call, ARM is very fast at implementing subroutine return calls



#### Program Counter – R15

- Tells you where you are in the program
  - Next instruction address (pipelining blurs that)
- 32 bits, aligned to even addresses
  - LDR PC, =LABEL Branch to address in LABEL
  - MOV PC, R4
  - MOV RO, PC

Branch to address contained in R4

Not recommended, processor-dependent

31

**Program Counter Bits 31-1** 



#### Stack Pointer

- Used by CPU to store return addresses of calls and interrupts
- Don't push and pop the SP and PC!
- SP can also be used by software.
- Initialized into RAM by user, aligned to even addresses

15 1 0
Stack Pointer Bits 15-1 0




# Current Program Status Register (CPSR)

- CPSR stores the status of current execution
- ARM has more than one CPSR
- In normal mode of operation CPSR contains current values of conditional code bits N, Z, C, and V, and 8 system status bits
- When interrupt occurs, the ARM saves preexception values of CPSR in a stored Saved Program Status Register (SPSR)
  - There is one SPSR register for each of the interrupt mode
- SPSR keeps the status of program and processor




#### **CPSR**



- CPSR contains number of flags that report and control operation of CPU
- Condition code flags:
  - N Negative Result from ALU
  - Z Zero result from ALU
  - C ALU operation carried out (carry from ALU operation)
  - V ALU operation overflown
- 8 lower bits I, F, T anf M[4:0]
  - Interrupt Enable Bits
    - I = 1 IRQ, interrupt prohibition
    - $\circ$  F = 1 FIQ interrupt prohibition
- T flag reflects the processor running
  - If T = 0 then processor in ARM Mode
  - If T = 1 then processor in THUMB Mode
- M[4:0] operating mode bits
  - Determine the processor operating mode
- Bits 27-8 are reserved and when conditions change in the code PSR flag or control bits reserve bits do not change

# Program Status Register - Summary




- Condition code flags
  - N = Negative result from ALU
  - Z = Zero result from ALU
  - C = ALU operation Carried out
  - V = ALU operation oVerflowed
- Sticky Overflow flag Q flag
  - Architecture 5TE and later only
  - Indicates if saturation has occurred
- J bit
  - Architecture 5TEJ and later only
  - J = 1: Processor in Jazelle state
- Interrupt Disable bits
  - I = 1: Disables IRQ
  - F = 1: Disables FIQ

- T Bit
  - T = 0: Processor in ARM state
  - T = 1: Processor in Thumb state
  - Introduced in Architecture 4T
- Mode bits
  - Specify the processor mode
- New bits in V6
  - GE[3:0] used by some SIMD instructions
  - E bit controls load/store endianness
  - A bit disables imprecise data aborts
  - IT [abcde] IF THEN conditional execution of Thumb2 instruction groups




## ARM – Core Datapath

- Separate control and datapath
- In datapath operands are not fetched directly from memory locations
  - Data is placed in register files
  - No data processing takes place in memory
- Instructions typically use 3 registers
  - 2 source registers and 1 destination register
- Barrel shifter preprocesses data before it enters ALU



## **ARM Organization**

- In order to be processed data has to be moved from memory location to central set of registers
  - After processing data is stored back in memory
- Register bank connected to ALU via two datapath busses A and B
  - Bus B goes through Barrel shifter
    - It pre-processes data from source register by shl, shr or rotation
  - PC is part of register bank responsible for generating addresses for next operation
  - Registers can handle both data and address
- Address Incrementer block increments or decrements register values independent of ALU



#### ARM Cortex M Address Space

- 4 GB address space (ROM/Flash for Code)
- Built-in and external RAM
- Built-in and external IO
  - Memory-mappedIO
  - Special Function Registers (SFRs) accessed by processor


0xFFFFFFFF 0xE0000000	System level	Private peripherals including build-in interrupt controller (NVIC), MPU control registers, and debug components
0xDFFFFFFF		
	External device	Mainly used as external peripherals
0xA0000000		
0x9FFFFFF		
	External RAM	Mainly used as external memory
0x60000000		
0x5FFFFFFF	Peripherals	Mainly used as peripherals
0x40000000		,
0x3FFFFFFF	SRAM	Mainly used as static RAM
0x20000000		
0x1FFFFFFF	CODE	Mainly used for program
0x00000000	CODE	code. Also provides exception vector table after power up



# Map -More

Fixed memory map

18-Sep-13



## Memory Regions

- Program code located in code, SRAM or external RAM regions
  - Best to put program code in code region as then the instruction fetches and data accesses are carried out simultaneously on two separate bus interfaces
- SRAM memory (0x20000000 0x3FFFFFFF) is for connecting internal SRAM
  - Regions is executable, hence a program can be copied here and executed from this part of memory
  - Access through system interface bus
- On-chip peripherals (0x40000000 0x5FFFFFFF) is a 0.5 GB block intended for peripherals
  - Code cannot be executed from this region



#### Memory Regions


- Two slots of 1 GB memory space are allocated for external RAM and external devices
  - External RAM regions (0x60000000 0x7FFFFFFF) and (0x80000000 – 0x9FFFFFFF) intended for either on-chip or offchip memory. Code can be executed in this region
  - External devices (0xA0000000 0xBFFFFFFF) and (0xC00000000 0xDFFFFFFF) intended for external devices and/or shared memory. This is a non-executable region
- System region (0xE0000000 0xFFFFFFFF) a 0.5 GB memory for system-level components, internal peripheral buses, external peripheral bus and vendor-specific system peripherals
  - It is a non-executable region



#### ISA – Machine Code

- Machine code vs. assembly
  - Machine code is a string of bits that processors "read". It is practically unreadable for humans
  - Assembly is intended for human reading
- In assembler the following instruction formatting is commonly used:

label opcode operand1, operand2, ... comments



## Assembly Language

label opcode operand1, operand2, ... comments

- Label is optional
- Opcode is the actual instruction
- Depending on the instruction there can be two or mode operands
  - Usually, the first operand is the destination of the operation



#### ARM Cortex ISA: ARMv7-M

#### Instructions:

- Data movement: single and multiple word
- Data processing: arithmetic, logic, shift, rotate
- Branches: conditional, subroutine, table (case)
- State change: int. enable, spec. reg., ITE, SVC
- Semaphores, Barrier, Hint, Prefetch
- Coprocessor, floating-point, misc.



## Addressing Modes

- Addressing mode describes manner in which data in CPU registers and memory is accessed
  - During program execution data can reside either in:
    - Machine instruction itself
      - Displacement
    - CPU registers
    - Main memory
    - Secondary storage
      - Access to this type of data not direct
- Three addressing modes are generally supported by assembly language:
  - Data register direct addressing
  - Address register direct addressing
  - Address register indirect with displacement addressing
- Accessing data
  - When data *is* part of instruction then it can be accessed immediately
    - Immediate data (addressing scheme)
  - When data is not part of instruction then we have three classes of data access:
    - Register addressing scheme
    - Memory addressing scheme



#### Instruction Operands

- Instruction operand can be:
  - ARM register
  - Constant
  - Instruction-specific parameter
- Many instructions are two-operand
  - Many data-processing instructions have flexible second operand Operand2, which can be
    - Constant
    - Register



#### Operand2 as a Constant

- Constant Operand2 is specified in form:
  - #constant
  - Where #constant can be
    - Any constant that can be produced by shifting 8-bit value left by any number of bits within a 32-bit word
    - Any constant of the form 0x00XY00XY
    - Any constant of the form 0xXY00XY00
    - Any constant of the form OxXYXYXYXY
      - X and Y are hex numbers



## Load (LDR) and Store (STR)

- LDR instruction loads register with value from memory
- STR instruction store register value into memory
- Memory address to load from or to store to is an offset from register Rn
  - Offset is specified by register Rm
- Value to load or store can be a byte, halfword or word



#### ISA: Data Movement Instructions

#### Load, Store and Move to register

```
LDR Rd, EA; EA=effective address
```

STR Rd, EA

MOV Rd, Rm

#### Major Variations:

MVN: Move negative

LDM, STM: Load and Store multiple

PUSH, POP: stack (shortcut for LDM, STM via SP)

Conditional; doubleword; exclusive



## EA: Basic Addressing Mode

- Pre-indexed effective address (EA) of operand: sum of base register and signed offset
  - Operator "[]" denotes indirection in reference (to memory)
- Example:

```
LDR Rd, [Rn, #offset]
```

```
Effect: Rd <-[[Rn]+offset]</pre>
```

LDR Rd, [Rn, Rm]

```
Effect: Rd<-[[Rn]+[Rm]]</pre>
```



## Store Timing

STR Rd, [Rn, #offset] Effect: Rd <-[[Rn]+offset]

- Execution takes always one cycle
  - Address generation is performed in the initial cycle, and data store is performed at the same time as the next instruction is executing



# Rationale for Addressing Modes

- Instructions have fixed length, and they have to accommodate different addressing modes with different length of addresses
- EA derived from register Rn and offset offs
- Offset: register Rm or immediate value #imm
- Indexed:
  - Pre: offset added to index reg. before op [Rn, offs]
  - Post: after op, reg. augmented for offset [Rn], offs
  - Pre with writeback: pre-ind. and update register [Rn, offs]!
- Relative to PC: EA=[PC]+#imm
- Also: inline shifting offset register barrel shifter
- Example (ARM, no Thumb/Thumb2): LDR R4, [R2, -R3, LSL #4]!


```
Result: R4 <- [[R2]-16x[R3]]; main operation
```

R2 <- R2-16xR3 ; index reg. update


Summary of [HVZM11] textbook




# Example: LDR Instruction Relative to PC



# Example: STR Instruction with Offset Addressing Mode



# Example: STR Instruction with Post-decrement Addressing





### Arithmetic & Conditional Execution

Mostly 3-operand (two inputs and output)

- Example:
  - ADD add
  - ADC add with carry
  - SUB subtract, etc.

#### Examples:

```
ADD R0, R1, R2; R0=R1+R2, no flag change

ADDS R0, R1, R2; as above, but CNZV affected

ADDCSS R0, R1, R2; if C flag then ADDS
```

#### **Branch Instructions**

- Branch can be conditional or unconditional
- Syntax

```
B [cond] label
```

- Example
  - B brach
  - BL branch with link
  - BEQ conditional branch
- Exampl

```
B loopA; branch to loopA
```

BEQ target; conditional branch to target

BX LR ; return from function call

# Conditional Execution Example

```
int gcd(int a, int b){
  while (a != b)
  if(a>b) a= a-b
  else b = b-a;
  return a;}
```

```
gcd CMP RO, R;
BEQ end
BLT less
SUB RO, RO, R1
B gcd
less SUB R1, R1, R0
B gcd
end ...
```

```
gcd CMP R0, R1;
SUBGT R0, R0, R1; SUB if R1 > R0
SUBLT R1, R1, R0; SUB if R1 < R0
BNE gcd;
```

# **ARM Instruction Set - Summary**

- All instructions are 32 bit long, many execute in one cycle
- Instructions can be conditionally executed
- Example: data processing instruction

```
SUB r0,r1,#5
ADD r2,r3,r3,LSL #2
ADDEQ r5,r5,r6
```

```
r0 = r1 - 5
r2 = r3 + (r3 * 4)
IF EQ condition true r5 = r5 + r6
```



# **ARM Instruction Set - Summary**

Example: branching instruction

```
B <Label>
```

```
r0 = r1 - 5
r2 = r3 + (r3 * 4)
IF EQ condition true r5 = r5 + r6
```

Example: memory access instructions

```
LDR r0,[r1]

STRNEB r2,[r3,r4]

STMFD sp!,{r4-r8,lr}
```

```
Load word at address rl into r0

IF NE condition true, store bottom byte of r2 to address r3+r4

Store registers r4 to r8 and lr on stack. Then update stack pointer
```




### Thumb Instruction Set

- Thumb is a 16-bit instruction set
  - Optimized for code density from C code (~65% of ARM code size)
  - Improved performance from narrow memory
  - Subset of functionality of ARM instruction set
- Thumb is not a "regular" instruction set
  - Constraints are not generally consistent
  - Targeted at compiler generation, not hard



# Thumb Performance vs. Density





#### Assembler

- Assembler is a utility program used to translate assembly language into machine code
  - Translation is nearly isomorphic (one-to-one) from assembly mnemonic statements into machine instructions and data
    - Note that the translation of a single high-level language instruction into machine code generally results in many machine instructions
    - In some cases assembler may provide pseudoinstructions expanding into several machine language instructions upon translation
      - Example: If assembly language is not supporting "branch if greater or equal" instruction then assembler can provide a pseudoinstrution expanding to "set if les than" and "branch id zero"



## Assembler - Pass 1

```
public static void pass_one() {
                                                                                      // This procedure is an outline of pass one of a simple assembler
boolean more input = true;
                                                                                      // flag that stops pass one
String line, symbol, literal, opcode:
                                                                                      // fields of the instruction
int location counter, length, value, type;
                                                                                      // misc. variables
final int END STATEMENT = -2;
                                                                                      // signals end of input
                                                                                      // assemble first instruction at 0
location counter = 0:
initialize tables();
                                                                                      // general initialization
while (more_input)
                                                                                      // more_input set to false by END
      line = read next line();
                                                                                      // get a line of input
      length = 0;
                                                                                      // # bytes in the instruction
      type = 0:
                                                                                      // which type (format) is the instruction
      if (line_is_not_comment(line)) { symbol = check_for_symbol(line);
                                                                                     // is this line labeled?
                 if (symbol != null) enter_new_symbol(symbol, location_counter); // if it is, record symbol and value
                 literal = check for literal(line);
                                                                                     // does line contain a literal?
                 if (literal != null) enter_new_literal(literal);
                                                                                     // if it does, enter it in table
                // Now determine the opcode type. -1 means illegal opcode.
                 opcode = extract opcode(line);
                                                                                     // locate opcode mnemonic
                                                                                    // find format, e.g. OP REG1,REG2
                 type = search_opcode_table(opcode);
                                                                                    // if not an opcode, is it a pseudoinstruction?
                 if (type < 0) type = search_pseudo_table(opcode);</pre>
                                                                                    // determine the length of this instruction
                 switch(type) {
                              case 1: length = get_length_of_type1(line); break;
                              case 2: length = get length of type2(line); break; // other cases here
write temp file(type, opcode, length, line);
                                                                                   // useful info for pass two
location_counter = location_counter + length;// update loc_ctr
                                                                                   // are we done with input?
if (type == END STATEMENT) {
                                                                                   // if so, perform housekeeping tasks
      more input = false;
      rewind_temp_for_pass_two();
                                                                                   // like rewinding the temp file
                                                                                   // and sorting the literal table
      sort literal table();
      remove_redundant_literals();
                                                                                   // and removing duplicates from it
```

## Assembler - Pass 2

```
public static void pass_two()
                                                       // This is an outline of pass two of a simple assembler
boolean more_input = true;
                                                       // flag that stops pass one of assembler
String line, opcode;
                                                       // fields of the instruction
int location_counter, length, type;
                                                       // misc. variables
final int END STATEMENT = -2;
                                                       // signals end of input
final int MAX CODE = 16;
                                                       // max bytes of code per instruction
byte code[] = new byte[MAX_CODE];
                                                       // holds generated code per instruction
                                                       // assemble first instruction at 0
location counter = 0;
while (more_input) {
                                                       // more_input set to false by END
     type = read_type();
                                                       // get type field of next line
     opcode = read opcode();
                                                       // get opcode field of next line
     length = read_length();
                                                       // get length field of next line
     line = read line();
                                                       // get the actual line of input
     if (type != 0)
                                                       // type 0 is for comment lines
        switch(type) {
                                                       // generate the output code
             case 1: eval_type1(opcode, length, line, code); break;
             case 2: eval_type2(opcode, length, line, code); break;
                                                       // other cases here
write_output(code);
                                                       // write the binary code
write_listing(code, line);
                                                       // print one line on the listing
location counter = location counter + length;
                                                       // update loc_ctr
if (type == END_STATEMENT) {
                                                       // are we done with input?
     more_input = false;
                                                       // if so, perform housekeeping tasks
                                                       // odds and ends
     finish_up();
```

# ARM Assembly Language

- Assemblers: nearly as powerful as high-level languages
  - ARM Assembler "feels" somewhat differently
- One (machine) command per line, but with ARM, could expand
- Assembly code: commands or directives (which are commands to assembler tool, rather than processor)

#### Format:

```
{label}{instruction | directive | pseudo-instruction} {;
   comment}
```

#### Notes:

- Everything is optional
- Label must start the line (no spaces or tabs before)
- Spaces and tabs freely used otherwise
- Comments can't spread multiple lines

# Example: Assembly Directives

#### AREA PROGRAM, CODE

; subroutine that takes 2 7-digit BCD numbers and places results in the first one

; bcdadd(a, b)-> a' with a'=a+b for encoding below

; svxxD6 D5D4 D3D2 D1D0 where s=1 is negative, v=1 is overflow, and 7 4-bit BCD Di

; ARM Calling convention: arg1 and arg2 in R0 and R1, respectively. Result in R0

; other registers unchanged. Need to be pushed to stack if changed, and pop-ed before return

; no memory used

; return via LR register

; position-independent code, needs to be linked with C routine

**EXPORT** bcdadd

**ENTRY** 

bcdadd; label of the entry point to the subroutine, the rest of code comes after

. . .

**END** 

# Example: Assembly Directives, cont.

- AREA directive instructs the assembler to assembly a new code or data section
- Syntax

```
AREA sectionmane { , attr}{,attr}...
```

- ■sectionname name given to the section. Any can be chosen
- CODE is a keyword indicating that the section to follow is a code
- EXPORT is a keyword indicating functions, variables, etc. visible to external segment
- ENTRY is a keyword indicating the entry point of a segment



#### Assembler Directives

- Important directives are these for data definition and storage
  - Equivalent of high-level language
    - Symbolic constant (to be replaced throughout code): EQU
      - EQU directive gives symbolic name to a numeric constant, a register-relative value or a PC-relative value
    - Variable: DCD, DCB
      - DCD directive allocates one or more words of memory, aligned on four-byte boundaries
      - DCB directive allocated one or more bytes of memory, and defines the initial runtime contents of the memory
    - Register variable: RN
    - Debug support: INFO, ASSERT
- Examples:
  - Array DCD 1, 2, 3 ;array, not only 1 word
  - FailingGrade DCB "D, C-, C, or C+", 0
  - INFO 0, "Version 1.0" ;reserves 10 bytes
  - PerfectNumber EQU 10 ; Pythagora ~500 B.C
  - LF EQU 10 ; linefeed in ASCII
  - Area RN R5 ; R5 holds var Area



#### Assembler Directives

- Important directives are these for data definition and storage
  - Equivalent of high-level language
    - Symbolic constant (to be replaced throughout code): EQU
      - EQU directive gives symbolic name to a numeric constant, a register-relative value or a PC-relative value
    - Variable: DCD, DCB
      - DCD directive allocates one or more words of memory, aligned on four-byte boundaries
      - DCB directive allocated one or more bytes of memory, and defines the initial runtime contents of the memory
    - Register variable: RN
    - Debug support: INFO, ASSERT
- Examples:
  - Array DCD 1, 2, 3 ;array, not only 1 word
  - FailingGrade DCB "D, C-, C, or C+", 0
  - INFO 0, "Version 1.0" ; reserves 10 bytes
  - PerfectNumber EQU 10 ; Pythagora ~500 B.C
    - LF EQU 10 ; linefeed in ASCII
  - Area RN R5 ; R5 holds var Area



### Cortex ISA and Assembler: Hints

- Note that some ARM instructions dropped
   Example: no LDR Rt, [Rn, Rm, LSL #imm] + but LDR Rt, [Rn, #imm]! is OK
   no writeback with shift[ARMV7-M App. Level Ref. Manual, p. A7-291]
- Use conditional execution -> avoid branches
  - Simpler code
  - Full pipeline
- Useful instructions for bit-field operations:

BIC, BFC - sets some bits to zero

BFI - inserts bit fields to a word


STMDB, LDMIA - push & pop (decrement before, increment after)

AND, ORR, EOR- logical bit manipulations

- Rely on Keil tool and documentation posted on Web
  - Instruction Set Quick Reference Card




## Cortex M3 ISA at Glance



# Cortex-M4 processors







# Lab 1: Encryption/Decryption

 Tiny Encryption Algoritm (TEA): Cambridge U. from 1994.

- 64 rounds of "mixing" the plaintext with 128-bit key
- Simple key schedule, suitable for embedded systems
  - Reasonably strong encryption
- Operations used:
  - Addition
  - XOR
  - Shift (left, right)







## Lab 1: Tools

- Keil IDE: uVIsion
- Last version: Keil ARM MDK 4.7
- Procedure
  - Create project: assembler code only
  - When asked, include startup code
  - Edit startup code to branch to entry point
  - Add assembler code file, finish design
  - Compile/build and simulate

