🔒 ndm736 / **ME433_2016**   PRIVATE

Unwatch ▾ 60   ★ Star 1   ⑂ Fork 2

<> Code   ⓘ Issues 0   Pull requests 0   Wiki   Pulse   Graphs

HW3

Edit   New Page

Nick Marchuk edited this page 22 hours ago · 6 revisions

Due Thursday, April 14, at noon.

Make sure your M08 header pins are at the following locations:

0.05" x 0.65"   1.925" x 0.65"

so that another PCB, with lots of breadboard-like space, will fit on top:

3.3V traces
5V traces
0V traces
breadboard traces

Your final .sch should look something like:

Find a Page…

Home

DigitalCommunication

EAGLECAD

EAGLEerror

EAGLEgerber

EAGLElayouts

EAGLElibraries

EAGLEorder

EAGLEschematics

Github

HW1

HW2

HW3

HW4

I2C

Show 5 more pages…

✛ Add a custom sidebar

Clone this wiki locally

https://github.com/ndm736/M

⎘ Clone in Desktop

and your final .brd should look like:

Complete your PCB. Design the .brd file, run the error checker, make the Gerber files, and check the Gerber files on another website. Upload your .lbr, .sch, .brd, Gerber files (you don't have to zip them up, I'll do that).

When your board is complete, make a git commit with the description "Ready to be checked before order", and I'll double check it. If there are changes to be made, I'll let you know.

Back to the Schedule

+ Add a custom footer

Status　API　Training　Shop　Blog　About