

- 1 Injection nozzle
- 2 Union nut
- 3 Nozzle holder
- 4 Compression spring
- 5 Spring retainer
- 6 Nozzle needle
- 7 Pump connector
- 8 Fuel leakage line
- 9 Distance plate