RTI RapidPro Diagnostic Blockset (optional) dSPACE prototyping systems IIIIIIIII MicroAutoBox Host PC SPI signals for diagnostics feedback (optional; for MicroAutoBox only) Analog and digital signals Analog and digital signals RapidPro Power Unit RapidPro SC Unit Configuration Configuration Sensor Actuator via USB via USB