1) The ability to quantize an input signal (its samples), the application should ask the user for the needed levels or number of bits available (in case of number of bits the application should compute from it the appropriate number of levels). Thereafter, the application should display the quantized signal and quantization error besides the encoded signal. 1