Queen Mary
University of London

EBU5376
Digital Signal Processing

DSP Systems – Frequency-domain Responses

Module Organizer: Dr Yixuan Zou yixuan.zou@qmul.ac.uk

Outline

- Frequency Response
  - Amplitude Response
  - Phase Response
- Transfer Function

Outline

- Frequency Response
  - Amplitude Response
  - Phase Response
- Transfer Function

Frequency Response

- The frequency response of a LTI system describes how the system responds to sinusoidal input signals of different frequencies.

- Specifically, it describes how the system modifies the amplitude and phase of the input signal at each frequency

Frequency Response

- The frequency response of a LTI system is denoted by $H(\omega)$ where $x[n] = e^{j\omega n}$ denotes the complex exponential input signal
- The system preserves the input frequency and modifies only its amplitude and phase, as determined by $H(\omega)$.



Fig: Representation of a LTI system using the frequency response.

From $h[n]$ to $H(\omega)$

- Recall that a LTI system based on impulse response is given by

$$y[n] = \sum_{k=-\infty}^{\infty} x[k]h[n-k]$$

- Now, suppose the input is a complex exponential function $x[n] = e^{j\omega n}$
- The frequency response is computed as

$$y[n] = \sum_{k=-\infty}^{\infty} h[n-k]e^{j\omega k} = \cdots = e^{j\omega n} \sum_{k=-\infty}^{\infty} h[k]e^{-j\omega k}$$

- Hence, we define the **frequency response** as

$$H(\omega) = \sum_{k=-\infty}^{\infty} h[k]e^{-j\omega k}$$

What is the name of this transformation?

Frequency Response - DTFT

- The **frequency response** can be obtained by applying the Discrete time Fourier transform (DTFT) to the **impulse response**, formulated as

$$H(\omega) = \sum_{n=-\infty}^{\infty} h[n]e^{-j\omega n}$$

Discrete $\quad h[n] \xleftrightarrow{DTFT} H(\omega) \quad$ Continuous

Frequency Response – z-Transform

- DTFT is z-transform with $|z| = 1$
- The frequency response can also be obtained by applying the z-transform ($|z| = 1$) to the impulse response, given by

$$H(\omega) = \sum_{n=-\infty}^{\infty} h[n]z^{-n}, \qquad |z| = 1$$

Frequency Response

- Example: Derive the frequency response of

$$y[n] = 0.5x[n] + 0.25x[n-1]$$

Outline

- Frequency Response
  - Amplitude Response
  - Phase Response
- Transfer Function

Amplitude Response

- In the frequency domain, each point is characterized by its magnitude and phase, hence the frequency response can be written as

$$H(\omega) = |H(\omega)|e^{j\angle H(\omega)}$$

- The complex-valued frequency response may be decomposed into two <u>real-valued</u> functions:
  1. The amplitude response

$$|H(\omega)| = \sqrt{Re\big(H(\omega)\big)^2 + Im\big(H(\omega)\big)^2} = \sqrt{H(\omega)H^*(\omega)}$$

Amplitude Response

- Example: Derive the amplitude response of

$$H(\omega) = 0.5 + 0.25e^{-j\omega}$$

Amplitude Response

- Given that the amplitude response of a system is

$$|H(\omega)| = \sqrt{\frac{5}{16} + \frac{1}{4}\cos\omega}$$

- Can you describe the frequency domain behaviour of the system, based on this amplitude response?

Amplitude Response

- The amplitude response $|H(\omega)| = \sqrt{\frac{5}{16} + \frac{1}{4}\cos\omega}$ is plotted as

Frequency Response – Normalized Frequency

What is the meaning of ω in the frequency response?

- In analog systems, the frequency response describes how the system modifies the amplitude and the phase of the sinusoid input $e^{j\omega_a t}$
- For discrete systems, the sinusoid input is sampled as $e^{j\omega n}$:

$$e^{j\omega_a t} \rightarrow e^{j\omega n}$$

where $\omega = 2\pi \frac{f}{f_s}$ or equivalently $\omega = \frac{\omega_a}{f_s}$ is the **normalized frequency**

f denotes the signal frequency and f_s denotes the sampling frequency

- The concept of normalized frequency was introduced at the start of the discrete-time transformation chapter

Frequency Response – Normalized Frequency

What is the meaning of ω in the frequency response?

- From the previous slide, we know $\omega = 2\pi \frac{f}{f_s}$ is the **normalized frequency**
- To prevent aliasing, the sampling frequency must be more than twice the signal frequency, i.e., $f_s > 2f$
- When analyzing a discrete DSP system, we always assume that the system has an appropriate sampling rate, i.e., no aliasing
- Hence, when explaining/plotting the frequency response, the range for ω is typically $[0, \pi]$

Outline

- Frequency Response
  - Amplitude Response
  - Phase Response
- Transfer Function

Phase Response

- The **phase response** determine the amount of time delay that the system introduces to the different frequency components of the input signal.

- The frequency response can be written as

$$H(\omega) = |H(\omega)|e^{j\angle H(\omega)}$$

The phase response is defined as

$$\angle H(\omega) = \tan^{-1}\left(\frac{Im\big(H(\omega)\big)}{Re\big(H(\omega)\big)}\right)$$

Phase Response

- Example: Suppose a system has the following frequency response:

$$H(\omega) = e^{-j\omega n_0}$$

The phase response is

$$\angle H(\omega) = -\omega n_0$$

Q: What impact does it have on the output signal?

Phase Response

- Example: Suppose a system has the following frequency response:

$$H(\omega) = e^{-j\omega^2}$$

The phase response is

Phase Response

- These figures illustrate the impact of **linear** and **non-linear phase response** on the same input signal
- The black line is the signal, while the colored lines are the component frequencies



Phase Response - Linearity

- The phase response is always a function of the (normalized) frequency ω
  - If this function is a linear function, we say the phase response is linear, e.g. $\angle H(\omega) = -\omega n_0$
  - If this function is a non-linear function, we say the phase response is non-linear, e.g. $\angle H(\omega) = -\omega^2$
- If a DSP system has a linear phase response, it means all frequency components in the input are shifted/delayed by the same amount. Hence, the shape of the signal is unchanged
- Otherwise, the system will change the shape of the signal

Outline

- Frequency Response
  - Amplitude Response
  - Phase Response
- Transfer Function

Transfer Function – Discrete LTI System

- Recall, the LTI system output can be written as the discrete convolution between its input and the impulse response

$$y[n] = h[n] * x[n] = \sum_{k=-\infty}^{\infty} h[k]x[n-k]$$

- The convolution property of z-transform states that, convolution in time-domain is multiplication in z-domain. Hence,

$$Z(y[n]) = Z(h[n])Z(x[n])$$

$$\Rightarrow Z(h[n]) = \frac{Y(z)}{X(z)}$$

Transfer Function – Discrete LTI System

- For discrete LTI systems, transfer function is defined as the ratio between the system output and input in the z-domain

$$H(z) = \frac{Z(y[n])}{Z(x[n])} = \frac{Y(z)}{X(z)}$$

- Equivalently, the transfer function can be obtained as the z-transform of the impulse response, i.e.,

$$H(z) = Z(h[n])$$

Transfer Function – Continuous LTI System

- For continuous LTI systems, transfer function is defined as the ratio of the Laplace transform of the system's output to the Laplace transform of the system's input

$$H(s) = \frac{\mathcal{L}\big(y(t)\big)}{\mathcal{L}\big(x(t)\big)} = \frac{Y(s)}{X(s)}$$

Transfer Function – Relation to Difference Equation

Relationship between Difference Equation and Transfer Function:

Difference Equation: $$y[n] = -\sum_{i=1}^{N} a_i y[n-i] + \sum_{j=0}^{M} b_j x[n-j]$$

Transfer Function: $$H(z) = \frac{Y(z)}{X(z)} = \frac{\sum_{k=0}^{M} b_k z^{-k}}{\sum_{k=0}^{N} a_k z^{-k}}$$

Transfer Function – Relation to Frequency Response

- We now know that
  - ✓ Frequency response is DTFT of impulse response
  - ✓ Transfer function is z-transform of impulse response

- Recall that DTFT is a special case of z-transform with $|z| = 1$

- Hence frequency response is the transfer function evaluated on the unit circle

Transfer Function

- Example 1: Derive the transfer function of

$$y[n] = 0.5x[n] + 0.25x[n-1]$$

Transfer Function

- Example 2: Derive the difference equation of the system based on $H(z) = 0.5 + 0.25z^{-1}$

Transfer Function

- Example 3: Derive the difference equation from

$$H(z) = \frac{(z+1)^2}{\left(z - \frac{1}{2}\right)\left(z + \frac{3}{4}\right)}$$

Summary

- **Transfer function** $H(z)$ is the frequency-domain representation of a LTI system
  - Difference equation is the time-domain representation
  - Derived from the z-transform of the difference equation
  - Can also be derived as the z-transform of the impulse response

$$H(z) = \frac{Z(y[n])}{Z(x[n])} \qquad H(z) = Z(h[n])$$

Summary

- **Frequency response** $H(\omega)$ describes how the system reacts to a sinusoid input of unit amplitude, i.e., $e^{j\omega}$
  - Can be derived from the transfer function $H(z)$ by substituting $z = e^{j\omega}$
  - Can be derived as the DTFT of the impulse response
- Frequency response is complex-valued, which has an amplitude and a phase.

Summary

- When evaluating the frequency-domain characteristics of a system, we often look at two separate responses:
  1. **Amplitude response**
     - How system changes the amplitude of a sinusoid input
  2. **Phase response**
     - How system changes the phase of a sinusoid input

Summary

- The **transfer function** carries another important information of the LTI system – Stability
- Stable systems are easier to control, whereas unstable systems can lead to disasters, e.g., outputs with infinite amplitude
- The stability of a system can be analysed by looking at the poles of the transfer function.
- This is the topic of the next lecture

Queen Mary
University of London