## 移动通信网络概述

Telecom survey

## **ACTION**

## Objectives

After the course the trainees will be able to describe telecommunication

- \*Services
- \*Technologies
- \*Networks

and the relations between them

## Schedule

**Module 1: Introduction** 

Module 2: Network & Services

Module 3: Switching & Signalling


Module 4: Access
Module 5: Transport

Module 6: Network Management


Module 7: PSTN&ISDN&PLMN

## ACTION


## INTRODUCTION





NETWORK AND SERVICES














# SWITCHING













# \*General \*Circuit Switched Connections -CAS -CCS










## ACCESS NETWORK











# TRANSPORT NETWORKS
























# PSTN & ISDN & PLMN








# LET US TAKE A BREAK





## 载波 (Carrier)

- 承载特定信息的无线电磁波
  - 特定的幅度
  - 特定的频率
  - 特定的相位


## 载波的强度 (Carrier Strength)


- 载波强度的线性单位: W(瓦)
- 载波的强度也被称为功率
- 载波强度的对数单位: dBm (分贝毫瓦)
- 换算方法示例: 10W →? dBm
  - Step 1:  $10W = 10 \times 10^3 \text{mW}$
  - Step 2:  $10\log(10 \times 10^3 \text{mW/1mW}) = 40 \text{dBm}$
- 换算方法练习
  - $-1mW \rightarrow ? dBm$
  - 0.5mW → ? dBm


## **ACTION**


## 载波带宽 (Carrier Bandwidth)


- 无线电磁波在频率域的宽度
- 载波带宽的单位: Hz (赫兹)
- 用载波的"中心频率"来表示载波的频率
- 载波中心频率处的功率最高











## 核心网电路域 • 主要完成对呼叫、短信、传真等传统语音业务的控制,以及对移动用户的管理 • CS域采用了MSS移动软交换分层结构,分为: - 控制层,主要由MSC-S,HLR/AUC等组成 - 连接层,主要由MGW组成 HLR/AUC/EIR/FNR MSC-S Control Layer MGW Connectivity Layer

