

Jointing in Weather Conditions — Field Guide

Quality Team — TAQA Distribution

TAQA
DISTRIBUTION

REFERENCE NO.	REVISION	LAST UPDATED	CLASSIFICATION
QT-PTS-QA-003	1.1	12 Jul 2026	Internal

Heat, humidity, rain and dust all affect joint quality. The principle is simple: insulation surfaces must be clean, dry and at a controlled temperature at the moment the joint is closed. Use this go / no-go card on site — the manufacturer instruction and project specification always take precedence where stricter.

CONDITION	STATUS	CONTROL REQUIRED
Dry, within material temperature window	PROCEED	Standard enclosure & cleanliness controls
High humidity / condensation risk	CONTROL	Warm surfaces, dehumidify, re-check before closing
High ambient heat	CONTROL	Shade materials, manage cure, schedule cooler hours
Light airborne dust	CONTROL	Sealed enclosure, clean immediately before application
Active rain on an open joint	STOP	Full enclosure & dry surfaces before proceeding
Active sandstorm	STOP	Wait, clean down, verify before reopening
Standing water in the excavation	STOP	De-water and provide a dry platform

KEY CONTROLS

- Erect and seal a jointing enclosure before opening any joint.
- Keep surfaces clean and dry; warm or dehumidify where needed.
- Record temperature and humidity on the pre-work checklist.
- Stop and re-verify whenever the weather changes.

Remember: When in doubt, stop and ask the Quality Team before opening a joint. Related: Cable Joint Checklist (PP.PPS.PTS.QT.06).