

EEE337 Semiconductor Electronics EEE348 Electronics and Devices (Photodetectors)

Prof. Chee Hing Tan

c.h.tan@sheffield.ac.uk


Department of Electronic and Electrical Engineering, The University of Sheffield, UK




Detector applications


RGB Inside the Camera Incoming Visible light Visible Light passes through IR-Blocking Filter Color Filters control the color light reaching a sensor Color blind sensors convert light reaching each sensor into electricity






DNA analysis







Atmospheric transmission consideration




Common wavelength bands for detectors


>15.0µm, emitted radiation

Band 5 Far IR (FIR)



Detector materials





Optical communication is an important detector application. The 2nd and 3rd windows are used for high bit-rates above 2.5 Gb/s.




1 µm

Material	
Si	• Covers 0.4-1.0 μm detection. First optical window for communication.
	Although the absorption coefficient is not the highest, the material is
	high quality and low cost making them the preferred detector for visible
	wavelengths, CCD and solar cell too.
Ge	• Indirect bandgap material with lower absorption coefficient than InGaAs.
	• Covers up to 1.8μm (all 3 windows)
	 Used in multi-junction solar cell with GaAs and InGaP.
In _{0.53} Ga _{0.47} As	The preferred choice for optical communication at 1300 and 1550nm.
(lattice match to	Used for night vision camera.
InP)	
$In_{0.53}Ga_{0.47}As_{y}P_{1-y}$	Can be grown to be lattice matched to InP and InGaAs (for device)
	engineering).
	• Bandgap can be adjusted Eg = 1.35 - 0.72y + 0.12y ² .
InSb	• Excellent detectors for 3-5μm atmospheric transmission window. Usually
	cooled to reduce leakage current
HgCdTe	Excellent material for night vision and thermal imaging. Usually cooled.
	Bandgap can be tuned from metal to 1.6 eV.




Semiconductor photodetector



III-V: GaAs, InP, InAs, GaN etc...

IV: Si, Ge, SiGe, SiC, SnGe etc..

II-VI: HgCdTe, HgZnTe etc..



^{*} Numbering system recommended by the International Union of Pure and Applied Chemistry (IUPAC)

1μm C H Tan

^{**} Previous IUPAC numbering system


^{***} Numbering system recommended by the Chemical Abstracts Service

^{****} For the names of elements 104-112, see Table 27.

^{©1997} Encyclopaedia Britannica, Inc




Commonly used photodetectors









1 µm




Photoconductor
Easy to fabricate
Low cost






Avalanche Photodiodes (M=10-1000) and Single Photon Avalanche Diodes (M=10⁵-10⁶)




Phototransistor High gain, moderate speed



Quantum efficiency



When light is absorbed within the depletion region, the photogenerated electrons and holes are separated by the electric field and a photocurrent flows in the external circuit. The carriers drift within the depletion region, then diffuse in the neutral (p or n region) and eventually recombine (in the neutral region or with charges of opposite sign at the electrodes).



The number of electron-hole pairs generated per incident photon is known as the external quantum efficiency.

$$\eta = \frac{\left(\frac{I_{ph}}{q}\right)}{\left(\frac{P_{opt}}{hv}\right)} = \frac{\left(\frac{I_{ph}}{q}\right)}{\left(\frac{P_{opt}\lambda}{hc}\right)} = \frac{\left(\frac{I_{ph}}{P_{opt}}\right)}{\left(\frac{\lambda}{1.24}\right)}$$

$$R_{measured} = \frac{I_{ph}}{P_{opt}}$$

$$R_{max} = \frac{\lambda}{1.24}$$

$$R_{measured} = \frac{I_{ph}}{P_{opt}}$$


$$R_{max} = \frac{\lambda}{1.24}$$

 I_{ph} is the measured photocurrent, P_{opt} is the incident optical power, hv is the photon energy.

Therefore to maximise the quantum efficiency it is important to minimise carrier loss through recombination in the photodetector. We can achieve this by confining the absorption within the depletion region using wide bandgap materials in a p and n layers of a p-i-n structure.



Absorption coefficient and quantum efficiency




As mentioned before the intensity of light is given by $I = I_o \exp(-\alpha x)$

where α is the absorption coefficient which is a strong function of wavelength.

Within the depletion width, the generation rate is $G(x) = \alpha \Phi_o \exp(-\alpha x)$ where Φ_o is the photon flux per unit area. Including light reflected at the air-semiconductor interface we have $\Phi_o = P_{opt}(1-R)/Ahv$


Assuming that light is absorbed in the i-region only (for instance in p-i-n diode with wide bandgap transparent p and n regions) the photocurrent generated within the depletion region is



1 μm



Effect of depletion width on



The quantum efficiency is

$$\eta = \left(\frac{I_i}{q}\right) \left(\frac{P_{opt}}{hv}\right)^{-1} = \frac{qA\Phi_o[1 - \exp(-\alpha W)]}{q} \left(\frac{P_{opt}}{hv}\right)^{-1}$$

$$\eta = \frac{AP_{opt}(1-R)[1-\exp(-\alpha W)]}{Ahv} \left(\frac{P_{opt}}{hv}\right)^{-1} = (1-R)[1-\exp(-\alpha W)] \quad \boxed{\eta = (1-R)[1-\exp(-\alpha W)]}$$

The larger the depletion width, the higher the quantum efficiency. However the quantum efficiency is always less than unity. In practice the absorption region thickness should be at least $1/\alpha$ (i.e 63% of light is absorbed) for acceptable quantum efficiency.




In most photodetectors, the upper limit of the absorption layer thickness is likely to be controlled by the response speed requirement. In other cases (e.g quantum well and superlattice) the growth of very thick absorption layer is costly.


1 µm




Absorption coefficient and quantum

efficiency








The absorption coefficient at wavelengths $<< \lambda_c$ is usually very large (10⁵ cm⁻¹). Light is therefore absorbed very close to the surface and majority of the photogenerated carriers recombine due to high density of surface states. At wavelengths $\gg \lambda_c$ no appreciable carriers are generated. Therefore the photocurrent contributed by very long and very short wavelengths are negligible, leading to a well defined response wavelength band. Light should be absorbed within the depletion region to maximise the responsivity.

Responsivity is defined as

$$R_{res} = \frac{I_{ph}}{P_{opt}} = \frac{\eta q}{h v} = \frac{\eta q \lambda}{hc} = \frac{\eta \lambda}{1.24}$$

The maximum theoretical responsivity is therefore


$$R_{res_max} = \frac{\lambda}{1.24}$$
 A/W



Impurity doped semiconductors can cover wavelengths into THz. $^{Wavelength~(\mu m)}$



Response speed



The response speed depends on (1) time for carriers to diffuse, (2) time to transit the depletion region and (3) RC time constant.

Carriers generated outside the depletion region must diffuse. The time taken to diffuse a distance *x* is known to be

$$t_{diff} = \frac{4x^2}{\pi^2 D_p}$$

In Si, electron diffusion constant is 36 cm²/s. What is the diffusion time over a $1\mu m$? Compare this to the transit time across a depletion region of the same width assuming a drift velocity of 10^7 cm/s.



The transit time limited bandwidth is given by

$$f_{3dB_{-}tr} = \frac{0.4}{t_{r}} = \frac{0.4v_{s}}{W}$$

Since $t_r = W/v_s$ the depletion width W sets a trade-off between response speed and quantum efficiency. $\eta = (1-R)[1-\exp(-\alpha W)]$

See Sze and Ng, p.676 -679 for derivation.


CH Tan




Top and side injection


Side injection can be used when *W* is reduced. The lateral length of the diode can be easily fabricate to ensure sufficient light absorption. This is the preferred approach for very high speed photodiode working > 10 GHz.

This "waveguide photodiode" has much smaller RC and transit times. Waveguide photodetectors can achieve responses >100 GHz.




When injecting light from the top, W presents a trade-off between speed and quantum efficiency. In most cases the cross sectional area is also quite large (to ensure good optical signal coupling). Consequently in vertically illuminated diode RC time constant is also limiting the speed response.














 I_{ph} = photocurrent, I_{B} = background induced current, I_{D} = dark current. In semiconductors such as Si and GaAs, the SRH recombination is the dominant recombination process that contributes to dark current.

Since carriers are generated randomly, these current components contributed shot noise. $\langle i_s^2 \rangle = 2qI_TB$

where B is the system bandwidth. The thermal noise is given by

$$\langle i_{th}^2 \rangle = \frac{4kTB}{R_{eq}}$$

$$\frac{1}{R_{eq}} = \frac{1}{R_{j}} + \frac{1}{R_{L}} + \frac{1}{R_{i}}$$

 $\frac{1}{R_{eq}} = \frac{1}{R_i} + \frac{1}{R_i} + \frac{1}{R_i}$ R_i^- input resistance of the following amplifier


The series resistance is usually much smaller and is ignored. The signal to noise ratio can be written as

$$SNR = \frac{I_{ph}^{2}}{\langle i_{s}^{2} \rangle + \langle i_{th}^{2} \rangle} = \frac{(q \eta P_{opt} / h v)^{2}}{2qI_{T}B + 4kTB/R}_{eq}$$

CH Tan



Noise



For B = 1 Hz, the noise equivalent power (NEP) can be derived by setting SNR $=1(q\eta P_{ont}/hv)^2 = 2qI_T + 4kT/R_{eq}$


$$P_{opt, \min} = \frac{hv}{q\,\eta}\,\sqrt{2q\!\left(I_D + I_B + 2kT/qR_{eq}\right)} = \frac{hv}{\eta}\,\sqrt{\frac{2I_{eq}}{q}} \qquad \begin{array}{l} \text{I}_{\text{ph}} \text{ omitted from shot noise to derive the minimum optical power required to produce SNR =1} \end{array}$$


To improve the sensitivity of the photodiode, we should increase η and R_{eq} (if amplifier noise is larger than the photodiode noise) but minimise I_D and I_B.






PIN diode SNR optimisation







- 1) Minimise light reflection at the surface. Use antireflection coating and light scattering structure (such as those in solar cell).
- 2) Use thick absorption layer when possible
- 3) Reduce carrier loss through recombination. Surface should be passivated to reduce surface recombination. Wide bandgap p and n "window" layers should also be used when available.


To maximise I_{eq} we need to

- 1) Make sure R_{eq} is large.
- 2) Use the widest bandgap available to detect the wavelength of interest to reduce dark current I_D. It is also important to minimise defects and hence lattice matched materials should be used.
- 3) The background induced signal can be removed by using optical filters.
- 4) If acceptable, cool the diode as cooling will reduce the dark current generated and the thermal noise.

1 µm



PN and PIN diodes





- •Simple growth, such as a single implantation step.
- •Depletion width is controlled by doping in the p and n regions.
- •Usually a homojunction design.
- •Electric field is not uniform such that carriers may not drift at the saturated velocity throughout the depletion region.
- •Capacitance depends on bias voltage

PIN

- •An additional growth required to define the epilayer.
- •Depletion width is controlled by i-region thickness and doping.
- •Can include wide bandgap transparent p and n layers to reduce dark current.
- •Electric field is almost constant across the high field region such that carriers drift at their saturated velocities.
- •Capacitance is virtually constant independent of bias voltage.






Avalanche photodiodes (APDs)

 $\beta = \alpha$


C H Tan


electronhole




time

When operated close to the reverse breakdown voltage a high energy electron can collide with a lattice atom to promote an electron from VB to CB. Since a hole is also produced, we have a new electron-hole pair.





1 µm



 $^{\text{position}}\beta$ and α are the hole and electron ionisation coefficients, respectively.


For k = 0 there is large number of electrons present at a given time. If one of the electrons does not impact ionise, the effect on gain is small.

positionWhen k = 1, there are much fewer electrons in the high field region. Hence if one of them does not ionise, the gain is significantly reduced.

The randomness in impact ionisation is minimum when k = 0.



Multiplication factor



 α (or β), the electron (or hole) ionisation coefficient, represents the inverse of the mean distance between successive impact ionisation events. The ratio $k = \beta / \alpha$ is normally used to characterise the breakdown characteristics. Lets consider two special cases for a diode with a constant electric field in the avalanche region of width W.

1) Assuming that we have $\alpha = \beta$, we have k = 1. The multiplication factor is given by

$$M = \frac{1}{1 - \alpha W}$$

The diode breakdown condition is defined by $\alpha W=1$ that leads to $M=\infty$.

2) If hole ionisation, $\beta = 0$, we have k = 0 the so-called single carrier ionisation since only electron can produce new carriers via impact ionisation. In this case the multiplication factor is given by $M = \exp(\alpha W)$

Here the diode does not have a well defined breakdown. The multiplication factor increases exponentially with α .

For other values of k, we have
$$M(x) = \frac{\exp[-(\alpha - \beta)x]}{1 - \frac{\alpha}{(\alpha - \beta)}[1 - \exp(-(\alpha - \beta)w)]}$$


Where x is the carrier injection position. For example x=0, when electron is injected to initiate the multiplication process in the previous slide. It is also possible to express the multiplication factor as a function of voltage. $M = \frac{1}{1 - \left(\frac{V - IR}{V_h}\right)^{n_m}}$




Gain and excess noise for k=0 and k=1




Although impact ionisation can provide internal gain in the APD, the multiplication process has statistical fluctuation that introduce noise. The noise factor in an APD with a constant electric field is given by



Gain vs. Reverse bias is a reasonable indicator of $k = \beta/\alpha$ value






The excess noise is minimised when k = 0.




Excess noise




To understand the advantages of APDs, we need to revisit the SNR. Consider a gain or multiplication factor of M is provided by the APD.

$$SNR = \frac{(MI_{ph})^2}{M^2 < i_s^2 > + < i_{th}^2 >} = \frac{(q \eta P_{opt} M / hv)^2}{2qI_T M^2 FB + 4kTB / R_{eq}}$$

$$SNR = \frac{(q \eta P_{opt} / hv)^2}{2qI_T FB + 4kTB / (M^2 R_{eq})}$$
 Diode Amplifier noise noise




When $k \neq 0$ there is an optimum multiplication factor (avalanche gain), M_{opt} . If the APD is operated at $M > M_{opt}$, the excess noise from the APD becomes the dominant noise source and SNR degrades.





Avalanche photodiodes



$$SNR = \frac{(MI_{ph})^{2}}{M^{2} < i_{s}^{2} > + < i_{th}^{2} >} = \frac{(q\eta P_{opt}M / hv)^{2}}{2qI_{T}M^{2}FB + 4kTB/R_{eq}}$$
$$SNR = \frac{(q\eta P_{opt} / hv)^{2}}{2qI_{T}FB + 4kTB/(M^{2}R_{eq})}$$

APD offers improved SNR over a pin diode only when the noise is dominated by the amplifier. The amplifier noise is usually dominant when






Extremely high gain > 10⁸ is required for detection of very low optical signal. Such as in fluorescence measurement in DNA analysis, and in ranging application called LIDAR

(http://www.youtube.com/watch?v=WJoaksSKaOo).



Low noise APDs

)	Material	$k = \beta/\alpha$ value	Application
6	Si	0-0.1	Low light detection within 400-1000 nm, Widely available at affordable cost.
4	InP	0.2-0.4	Used with an InGaAs absorption region in the 1300 and 1550 nm optical fiber communication.
	CdHgTe	0	Can cover all low light detection from Near IR to Longwave IR ($10\mu m$). Need to be cooled to 77 K and hence it is expensive.
V	InAs	0	Currently developed at Sheffield for imaging and gas sensing applications at 1000 to 3600 nm.





In As APDs developed at Sheffield has excess noise factor below k = 0.



0.01

APD gain-bandwidth products





Multiplication region width, w (µm)

10


For $k \neq 0$, the multiplication process requires several transit times to build up the charge concentration required for high gain. Therefore the avalanche material is not instantaneous in most semiconductors. Consequently the bandwidth reduces as the gain increases leading to an approximately constant gain-bandwidth product.


Low multiplication region width and low value of k provide the highest gain-bandwidth product.

Consider an InGaAs/InP APD with a gain-bandwidth product of 140 GHz. Estimate the maximum gain that it can provide when used to detect signal at a bit rate of 10 Gb/s.




APD Design Issues





- Gain is sensitive to bias and temperature.
- For high speed APD with thin multiplication region, it is limited by onset of tunnelling current.






1 um



Bipolar Junction Transistor (BJT)




Fabrication steps:


Start with a p-substrate


Diffuse n dopant to form base

Diffuse p+ dopant to form emitter

Deposit metal contacts











1 µm

Modes of operation





Phototransistor



In a phototransistor the base is not electrically connected. Light is absorbed in the base-collector depletion region and the undepleted base region (if emitter is a wide bandgap material). Photogenerated holes are trapped at the base and raises the potential that allows more electrons to be injected from emitter to collector. Provided that the electron transit time is much smaller than the minority electron lifetime, a high amplification factor or gain is achieved.

Gain of up to 10³ can be obtained. Unfortunately the dark current is also amplified by the same factor. The response speed of phototransistor is also lower than PINs and APDs.


Phototransistors are used in optical isolator because of its high output to input current ratio, known as the current-transfer ratio. A value of 50% is typical which is much high than that achieved using a photodiode (0.2%). Phototransistors are cheaper than APDs. Can you list applications where optical isolator is particularly useful?

To protect an expensive equipment or circuit. To isolate two circuits with very different bias range.

To data communication.

To minimise interference between circuits and antenna.


To detect object/particle counting




1 µm



Photoconductor





This is simply a slab of semiconductor sandwiched between two metals. When light is absorbed the photogenerated electron-hole pairs modify the conductivity

$$\sigma = q(\mu_e n + \mu_h p)$$

Consider a steady flow of photon flux illuminated on the area W_dL and $D >> 1/\alpha$. The generation rate is therefore

$$G = \frac{\eta(P_{opt}/hv)}{W_d LD} = \frac{n}{\tau}$$

$$I_{ph} = \sigma E W_d D = q \mu_e n E W_d D$$

$$I_{ph} = q \frac{\eta P_{opt}}{h v} \left(\frac{\mu_e \tau E}{L} \right)$$

For high gain, the lifetime should be long, while the spacing between electrodes should be short and mobility should be high.

Gain: 1-10⁶


Response time: 10^{-8} - 10^{-3} s

$$I_{pr} = q \frac{\eta P_{opt}}{hv}$$
 Recombination lifetime
$$Gain = \frac{\mu_e \tau E}{L} = \frac{\tau}{t_r}$$
 Transit time



1 µm






Infrared photodetectors





1μm C H Tan




Photoconductor














1 µm

CdHgTe Dual band detection



Lattice match system enables MWIR/LWIR dual band detection.





Image is sharper in MWIR due to lower leakage current but LWIR detects lower temperature objects.

Smith et al., Proc. SPIE 6127




CMT: High performance IR

detectors

 $Cd_xHg_{1-x}Te$ (CMT)

- Difficult growth
- Low temperature operation to avoid Auger recombination
- Fabrication is complicated
- Smaller array
- Poor stability due to weak Hg-Te bond
- Not bias tuneable




Cutoff wavelength for x variations of 0.1%, and the corresponding cutoff wavelength shift for Hq_{1-x}Cd_xTe

and the control of th				
x-value	Cutoff wavelength (μm)	Temperature (K)	Uncertainty (μm)	
0.395	3	77	0.012	
0.295	5	77	0.032	
0.210	10	77	0.131	
0.196	14	77	0.257	
0.187	20	77	0.527	

Rogalski et al. Narrow-Gap Semiconductor Photodiodes



Quantum well Photodetector



When a bulk narrow bandgap material is not available, nanostructures can be used. Quantum well and superlattice are important heterostructrures that provide further energy band engineering.


What is a quantum well?

Consider a GaAs/AlGaAs system. The quantum well is formed when the width of GaAs layer is reduced to **10-20 nm**. This width is comparable to the de Broglie wavelength $\lambda_{\text{Broglie}} = h/p$ where h is the Planck constant and p is the carrier momentum.



Assuming an infinite barrier height, the quantised energy level is constant and is given by

$$E_n = \frac{1}{2m^*} \left(\frac{\pi \hbar n}{L} \right)^2$$





Electrons and holes are confined in the z-direction. This leads sub-bands (E_1,E_2,E_3) in a 2-D system. Since the energy levels are very similar in each sub-band, it is usually represented as individual discrete levels. We can see that the width of the well is very important in controlling the energy levels. A larger value of L produces a lower E_n . The number of allowed energy levels will depend on the barrier height.

1 µm



Quantum well IR Photodetector (QWIP)






When the wells are separated by thick barriers, the electron wavefunctions are decoupled. However if the barrier thickness is reduced, the wavefunctions start to overlap in the superlattice. Due to the wavefunction overlap, the energy is now continuous in space and energy minibands are formed.



Since the energy levels are easily adjusted by changing the quantum well design, it offers the freedom to "ENGINEER" the energy separation to match the energy of photon, $E_2 - E_1 = E_{photon}$. The quantum well infrared photodetector (QWIP) is an important technology for detection of wavelengths in the LWIR. GaAs/AlGaAs and InGaAs/InAlAs are two important material systems for QWIP technology that offers high resolution thermal imaging.




Large 2D QWIPs array




Wavelength tuned by adjusting layer thicknesses and hence better control of uniformity than CMT



QWIPs






4 colour QWIPs, Gunapala et al., IEEE TED, 50, 2353, 2004

Detection wavelength can be easily adjusted by the well width and hence multi-band detection can be realised for gas sensing, imaging and material characterisation applications.

[after S.D. Gunapala *at el.*, Semicond. Sci. Technol. **20**, 473–480 (2005)]



Photodetector comparison





1 μm

Photodetector	Gain	Response Time (s)
Photoconductor	1-10 ⁶	10 ⁻⁸ -10 ⁻³
Photodiodes (pn)	1	10 ⁻¹¹
Photodiodes (pin)	1	10 ⁻¹⁰ -10 ⁻⁸
Phototransistors	10 ² -10 ³	10 ⁻⁶
Avalanche Photodiodes	10 ² -10 ⁴	10 ⁻¹⁰



Photodetector selection

	Wavelength	Response time	Signal intensity	Photodetector	Material
16	Visible	μs	Low		
	Visible	≤µs	Very Low		
	SWIR	<ns< td=""><td>Very low</td><td></td><td></td></ns<>	Very low		
	MWIR	ms-µs	Moderate		
	MWIR	≤µs	Low/moderate		
	LWIR	ms-µs	Low/moderate		
	VLWIR	ms-µs	Low/moderate		
	т дата		e		