
Topic 19

- 19. Photo-detectors (1)
 - 19.1 Introduction
 - 19.2 Basic concepts
 - 19.3 Type of photo-detectors
 - 19.4.1 Photoconductors and their characteristics
 - 19.4.2 Photodiodes and their characteristics

Introduction





- Convert an optical signal into an electrical signal
 Photo-detector absorbs photons and then generates electrons
 Under applied electric fields, an electrical current is produced
- Photodetector requires
- (1) high sensitivity and low noise; (2) high efficient conversion; (3) Fast response; (4) high reliability

Basic concepts

Quantum efficiency

$$\eta = \frac{\textit{Number of } e-\textit{h generated and collected}}{\textit{Number of incidnet photons}} = \frac{I_{\textit{ph}}/\textit{q}}{P_{\textit{0}}/\textit{hv}}$$

 I_{ph} : photocurrent; P_0 : incident optical power


Responsivity:

$$\Re = \frac{Photocurrent (A)}{Incident Optical Power (W)} = \frac{I_{ph}}{P_0} = \frac{\eta q}{h v} = \frac{\eta \lambda}{1.24} (A/W)$$

Quantum efficiency is determined by optical absorption, surface reflectivity and internal quantum efficiency

IQE: the number of e-h pairs divided by the number of photons absorbed (normally IQE is very high)

Absorption Coefficient




- •External quantum efficiency is determined by absorption coefficient and the thickness of the absorption region
- •Optical power absorbed in terms of incident optical power P₀

$$P(x) = P_0(1 - e^{-\alpha L})$$

α: Absorption coefficient, strongly depending on wavelength. The upper wavelength cutoff is determined by its energy gap

•For high efficiency need $\alpha L > 1$

Reflection and External Quantum Efficiency




•Reflectivity: $R = \left(\frac{n_1 - n_2}{n_1 + n_2}\right)^2$ ~30% of light lost by reflection at the air/semiconductor interface

• The optical power entering the photo-detector:

$$P = P_0(1-R)(1-e^{-\alpha L})$$

Photo-conductors (i)

- 1. Structure:
- 2. Characteristics



Gain Γ : Recombination rate (τ) and transit time (t_{tr})

Bandwidth: shortest response time

Noise: Johnson and generation-recombination

NEP: Noise equivalent power (minimum detectable signal)

Detectivity: 1/NEP

S/N ratio: ratio of signal to noise

Photo-conductors (ii)

Photocurrent Gain Γ : $\Gamma_G = \frac{\tau}{\Gamma}$

$$\Gamma_G = \frac{ au}{t_{tr}}$$

Bandwidth: determined by transit time

Transit time:

$$t_{tr} = \frac{L}{\upsilon} = \frac{L}{\mu E} = \frac{L}{\mu \frac{V}{L}} = \frac{L^2}{\mu V}$$

Photocurrent:

$$I_{ph} = qp_{inc} \frac{\eta}{h v} \Gamma_G = \frac{qp \eta}{h v} \frac{\tau}{t_{tr}}$$


For ac, extra factor:


Photocurrent: (1) Transit time < recombination time

(2) Modulated time< response time

ullet Considering electrons and holes, the total gain Γ_{total} :

$$\Gamma = \frac{\tau}{t_{tr}} = \frac{\tau}{\frac{L^2}{\mu_o V} + \frac{L^2}{\mu_b V}} = \frac{\tau(\mu_e + \mu_h)V}{L^2}$$





Noise in photo-conductors


Major limit: large dark current and the associated noise


- Johnson (thermal) noise: random motion of carriers (due to k_BT) contributing to the dark current $\overline{i_j^2} = \frac{4k_BTB}{R}$
- 2. Generation—recombination noise: fluctuation in the rates of generation and recombination of electron-holes

$$\overline{i_{GR}^2} = \frac{4q\Gamma_G I_0 B}{(1+\omega^2 \tau^2)}$$

- •Noise equivalent power (NEP): minimum detectable signal, where signal is equal to noise at a band width of 1 Hz
- Detectivity: 1/NEP
- •S/N ratio: $\frac{S}{N} = \frac{\overline{i_{ph}^2}}{\overline{i_I^2} + \overline{i_{GR}^2}}$

Photodiodes





It would be easy to understand if you understand the difference between a photoconductor and a photodiode

•Photoconductors: single layer, and does not involve p-n


junction

• Junction diodes: p and n doped layers

(1) PIN diode

(2) Avalanche diode

PIN photodiode



Un-doped i region sandwiched by n and p-doped regions

- (1) i region: low carrier density and high resistivity
- (2) Any applied bias almost across the iregion
- Operation mechanism: like LED in reverse!
- •PIN diode with large forward bias is an LED

• i region: Determine the transit time, which actually determines


response and thus bandwidth

• Reverse bias: high enough in order to make electron and hole drift at saturation velocity (V_{sat}) ~10⁵m/s


• You can reduce i-region thickness in order to reduce transit time.

PIN is used for the application of a large bandwidth.

Photocurrent



- Further reduce response time and then increase bandwidth:
- (1) Minority carriers in doped regions: diffuse into intrinsic region (slow), and needs to be minimised
- (2) Minimise minority diffusion in three ways: (1) junction should be close surface (2) use of different materials; (3) wide i region (also leads to long transit time, not ideal);



• Transit Time for carriers across reverse biased diode


$$t_c = L/V_{sat}$$
; $V_{sat} \sim 10^5 \text{m/s}$; $L \sim \mu \text{ms}$

• Maximum bandwidth:

determined by the transit time, giving ~GHz operation (~1/t_{tr})

Need to consider junction capacitance:

determined by the capacitor characteristic time, if it is longer than the transit time, giving ($^{\sim}1/t_{RC}$)



- Need to consider junction capacitance
- Have a reverse bias, separated by a distance L; A is the PIN area

C ~εε₀A/L

• In order to obtain a short RC time, you need to have small A and long L

But: A small area A leads to reduced absorption A long L leads to long transit time

Response Time Example

Estimate maximum bandwidth:


Considering InGaAs (ε = 12) photodiode; (1) 10um thick i-region; (2) optical window in a 200um diameter; (3) Saturation velocity = 10^5 m/s; (4) Driving a preamplifier of 50 impedance

- Transit time = $L/v = 10 \times 10^{-6} / 10^{5} = 1 \times 10^{-10} \text{ s} = 0.1 \text{ns}$
- C = $\varepsilon \varepsilon_0 A/L$ = 12 x 8.85 x 10^{-12} x π x $(100 \text{ x} 10^{-6})^2/10 \text{ x} 10^{-6}$ = 0.33pF

Therefore, RC = 0.017ns

However, response time of photodiode is limited by carrier capture (transit time) to 0.1ns. f~ 10GHz

Noise Performance



• The noise level (dark current)t is very small (operated under reverse bias)

PIN is used for the application of a low noise

- •Shot-noise (generation-recombination): small compared with photoconductors
- •Johnson noise: dominate, but can be minimised through optimising circuit parameters

Noise - Quantum and Thermal (i)

Quantum Noise (Shot Noise)

- (1) Photo-induced carriers are produced randomly when photons are absorbed
- (2) Motion of these carriers is also random –

$$\overline{i_{sn}^2} = 2q\overline{I}B_{bw} \Longrightarrow \overline{i_{sn}^2} = 2q(I_{ph} + I_d + I_{bg})B_{bw}$$

Thermal Noise (Johnson Noise)

Random motion of carriers with a distribution of thermal energy produces a noise in the current and hence a noise voltage over a resistor

$$\overline{i_{jn}^2} = \frac{4k_B T B_{bw}}{R_{eq}}$$

White noise


At low frequencies, 1/f noise is important but ignored here

Signal to Noise (Power) Ratio

$$\frac{S_{rms}^{pp}}{N_{rms}} = \frac{i_{ph}^{2}}{(i_{sn}^{2} + i_{jn}^{2})}$$

- •Noise Equivalent Power (NEP): minimum detectable signal, often used to characterize responsivity.
- •NEP: the input rms optical power per unit Bandwidth at which the photocurrent is equal to the noise current and corresponds to the minimum optical power detectable.

Examples of Device Structure



Top entry

- Diffused thin p doped region (avoids diffusion effects)
- •Mesa etched to small size limit C

$$\alpha$$
= 10⁶/m

$$\alpha$$
L = 5 , η_{int} = 99%

$$T_{tr} = 4x10^{-6} / 10^{5} = 40ps \sim 25GHz$$

Summary – Topic 19

- A diode in reverse bias
- Efficiency of a photodiode is a function of the external (reflectivity of device) and internal efficiency (thickness of absorption region)
- Frequency response has two limits transit time needs to be short (small absorption/i-region thickness), and low C (high i-region thickness)
- Noise (NEP) determines the SNR and hence minimum receiver power is required in a lightwave system

Tutorial Questions

- T19.1 Calculate the current gain of a photoconductor
- T19.2 Sketch the construction of a pin photodiode and the shape of its band-edge structure when the diode is reverse biased. Describe the principles of photocurrent production and the factors which determine efficiency and speed. Explain how the length of the depletion region must be chosen as a compromise for these important device parameters.
- T19.3 What is the effect of elevated temperature on a p-i-n photodetector? What effect will this have on system performance?