## **CLRWDT**

< Previous instruction: <u>CLRF</u> | Instruction index | Next instruction: <u>COMF</u> >

CLRWD1 Clear Watchdog IIII	CLRWDT	Clear Watchdog Timer
----------------------------	--------	----------------------

Syntax: [label] CLRWDT

Operands: None

Operation:  $000h \rightarrow WDT$ ,

000h → WDT postscaler,

 $1 \rightarrow \overline{10}$ ,  $1 \rightarrow \overline{PD}$ 

Status Affected: TO, PD

Encoding: 0000 0000 0000 0100

Description: CLRWDT instruction resets the

Watchdog Timer. It also resets the postscaler of the WDT. Status bits

TO and PD are set.

Words: 1

Cycles: 1

Q Cycle Activity:

Q1	Q2	Q3	Q4
Decode	No	Process	No
	operation	Data	operation

Example: CLRWDT

Before Instruction

WDT Counter = ?

After Instruction

 WDT Counter
 =
 0x00

 WDT Postscaler
 =
 0

 TO
 =
 1

 PD
 =
 1