USER MANUAL

GCU-R5 v1.0

IMPORTANT NOTES

Please read this manual thoroughly before using the equipment to ensure safe and correct usage.

Operating Instructions

Basic Operation

Hold the *Power* button to turn the device on or off. When the device is connected via USB-C connection, the device will automatically power on without wireless capability.

When the device is powered on while *Holding Sync Buttons*, the device will power on and allow sync mode (Bluetooth).

Controller Diagram

See all of the various available buttons and input devices for use during gameplay.



Charging and Power

This device allows charging using USB-PD compliant chargers and cables. **Ensure that the cable and/or charger that you are using are USB-IF or USB-PD compliant.** See the diagram below for where to locate the USB-C connection.



FCC Information

FCC ID Label Location

The FCC ID Label can be located on the rear side of the device.

FCC Compliance Statement and E-Labeling

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note on Labeling: Due to the ergonomic design and complex surface texture of the gamepad, it is impracticable to place the full compliance statement on the device housing. Per FCC Rule 15.19(a)(5), the full statement is provided here in the user manual and via the electronic label.

How to Access E-Label: > Regulatory information, including the FCC ID and Part 15 statement, can be accessed at any time through the configuration software:

1. Connect the gamepad to the gamepad configuration app (Chrome/Opera Browser Required: https://handheldlegend.github.io/hoja2/
2. Navigate to the **'Wireless'** tab.



3. View the **'Regulatory Information'** section.



FCC notice "Declaration of Conformity Information"

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning

the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

FCC Conditions

This equipment has been tested and found to comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference

(2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Notice "Equipment Authorization" Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

NOTE : Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Important Safety Information

Throughout these instructions, you will see this symbol followed by **WARNING** or **CAUTION**, or you may see the term **NOTICE**.

These terms have different levels of meaning as outlined below.

Please read and understand these terms and the information that appears after them before using your device.

WARNING Warns you about incorrect use of this system that could result in serious personal injury.

CAUTION Cautions you about incorrect use of this system that could result in personal injury or damage to the system, components, games, or accessories.

NOTICE Informs you about incorrect use of the system that could result in damage to the system, components, or accessories.

Some people (about 1 in 4,000) may have seizures or blackouts triggered by light flashes or patterns, and this may occur while they are watching TV or playing video games, even if they have never had a seizure before. **This device features LED indicator lights which may be configured to flash at a high interval rate.**

Anyone who has had a seizure, loss of awareness, or other symptom linked to an epileptic condition should consult a doctor before playing a video game. Playing video games can make your muscles, joints, skin, or eyes hurt. Follow these instructions to avoid problems such as tendinitis, carpal tunnel syndrome, skin irritation or eye strain:

Avoid excessive play. Parents should monitor their children for appropriate play. Take a 10 to 15 minute break every hour, even if you don't think you need it.

If your hands, wrists, arms, or eyes become tired or sore while playing, or if you feel symptoms such as tingling, numbness, burning, or stiffness, stop and rest for several hours before playing again. If you continue to have any of the above symptoms or other discomfort during or after play, stop playing and see a doctor.

Do not use an AC adapter if it has damaged, split, or broken cords or wires.

ELECTRIC SHOCK Make sure that the AC adapter cord is fully inserted into the wall outlet or extension cord. Always carefully disconnect all plugs by pulling on the plug and not on the cord.

DANGER - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS For connection to a supply not in the U.S.A., use an attachment plug adapter of the proper configuration for the power outlet, if needed. The GC Ultimate controllers may contain a rechargeable lithium ion battery. Leakage of ingredients contained within the battery, or the combustion products of the ingredients, can cause personal injury as well as damage to other components. If battery leakage occurs, avoid contact with skin. If contact occurs, immediately wash thoroughly with soap and water. If liquid leaking from a battery comes into contact with your eyes, immediately flush thoroughly with water and see a doctor. To avoid battery leakage: Do not expose battery to excessive physical shock, vibration, or liquids. Do not disassemble, attempt to repair, or deform the battery. Do not dispose of battery in a fire. Do not touch the terminals of the battery or cause a short between the terminals with a metal object.

The GC Ultimate controller can emit radio waves that can affect the operation of nearby electronics, including cardiac pacemakers.

Do not operate the GC Ultimate controller within 9 inches of a pacemaker.

If you have a pacemaker or other implanted medical device, do not use the GC Ultimate controller without first consulting your doctor or the manufacturer of your medical device.