3CH_C1

History = Fb bad=1 Startx1k=48264
CS bad=14 strokesx1k=86
Direction=5
Stall=69

Stallx1k=48264 Fb bad=1
strokesx1k=86 CS bad=14
last Error=None Direction=5
Stall=69

CALIBRATE → CONTROL → SPEED/ACCEL → INPUTS → DRIVES → OUTPUTS → CURRENT STATS → HISTORIC STATS

CALIBRATE	CONTROL	SPEED/ACCEL	INPUTS	DRIVES	OUTPUTS	CURRENT STATS	HISTORIC STATS
Position Lo: 69.7%	Deadband: 0.30%	Max Hi Spd: 100%	Signal Type: 4-Analog	Drive Type: Step	Relay #1: 1%		
Position Hi: 42.9%	Min Mod: off (NA if Signal Type = 1 Cont)	Max UP Spd (If 2-Speed = Up/Dn)	Pulse Dur (If Signal Type = Pulse)	Stall Time: 5 sec	Relay #2: 50%		
Signal Lo: 4 mA (If Signal Type = Analog)	Bumpless: off (Multiple requirements)	Gain: 75	Pulse Inc (If Signal Type = Pulse)	Boost Pump (Multiple requirements)	Pos Xmitter: Rev		
Signal Hi: 20 mA (If Signal Type = Analog)	Seat Ld Cyl: No	Hi Accel: 50	Failsafe: InPlac (Multiple requirements)	Main Valves (If Signal Type = Commun)	Open Pres		
Sol. Seat	Flow Char: No (Multiple requirements)	Accel Bkpt: 0.5%	Shed Time (If Signal Type = Commun)	Surge Bkpt: off (Multiple requirements)	Close Pres		
		Lo Accel: 5	Trip: off	Accumulator: No (If Surge Bkpt = Off)	Version		
		2-Speed: off	Power on last				
		Max Dn Spd (If 2-Speed = Up/Dn) / Max Lo Spd (If 2-Speed = Bkpt)					
		Speed Bkpt					
		Max Man Spd: 50					

Requires special construction

Only if Accumulator = Yes: Rechrg Pres; Warn Pres; Rechrg Time; Accum Dir; Accum Pres

Xmitter low = 00176
Hi 64044

CURRENT STATS can be reset by accessing the parameter and pressing [Enter]

Last CURRENT STATS reset: Date

HISTORIC STATS can not be reset

Notes:

PASSWORD=0000

Error Codes:

- **FB bad:** *Actuator Main Feedback <2.0mA*
- **CS bad:** *Control Signal < 2.6mA*
- **Mot stall:** *Actuator did not move 1% in time specified by parameter "Stall Time"*
- **Dir error:** *Actuator detected moving in the wrong direction*
- **Drv fault:** *Motor Driver has detected problem*
- **+/-15 fail:** *The + or - 15vdc power supply is out of range by +/-10%*
- **Pres bad:** *(Accumulator units only) Accumulator Press. Trans. signal <3mA or >21mA*
- **Pres low:** *(Accumulator units only) Accumulator pressure is below value set in parameter "Warn Pres"*
- **SLCfb bad:** *(Seat Load Cylinder units only) Feedback signal from the Seat Load Cylinder is <2mA*
- **Slc stop:** *(Seat Load Cylinder units only) "Seated" position detected but main cylinder is >0.2% from the seat*

Koso America, Inc.

Control Parameters Record

Date Parameters Written:	By:
Serial No.	
Build No.	