EE3011 MODELLING & CONTROL Tutorial 1 (Solutions) Open-Loop and Closed-Loop Systems

1. Open-loop control systems found in homes:


- (a) Washer/dryer for clothes (some new and modern ones have closed-loop control!)
 - (b) Dish washer
 - (c) Electric fan

Closed-loop control systems found in homes:

- (a) **Room temperature control system.** Room temperature is kept constant regardless of the number of people in the room or the outside temperature.
- (b) **Refrigerator.** Keeps the temperature in the refrigerator constant regardless of the amount of food in it or the outside temperature.
- (c) **Oven temperature control.** The oven temperature is controlled at the setpoint regardless of the amount of food in the oven or the outside temperature.

2. Driving a car

Suppose that the desired output is a certain speed, 80 km/hr say. The input is the driver's foot on the accelerator (which translates into a desired speed), and the human driver is the controller. To maintain the speed, he/she monitors the speedometer and either accelerates or lift foot off the accelerator to slow down.



Disturbance?

Well, the sighting of a police officer will cause the controller to react by touching the brake.


Humps, child rushing across the road etc are other forms of disturbance..

3. With a flexible shaft, the assembly of R/W head will be smaller and lighter and can give a faster response. However, it will give rise to higher order dynamics. Further, the actual displacement θ_2 will be different from the displacement of the motor, θ_1 . Thus, some form of estimation is required.

Performance specifications:


- Fast response to give fast access time.
- Steady-state error of less than 1/2 the track width to give correct tracking.
- Very small overshoot to prevent R/W head hitting the casing.
- Ability to reject disturbance torque.

4. To get $\frac{\theta_R(s)}{R(s)}$, set $D(s) \equiv 0$, then



$$\frac{\theta_R(s)}{R(s)} = \frac{\frac{K}{s+6} \cdot \frac{2}{s(s+1)}}{1 + \frac{K}{s+6} \cdot \frac{2}{s(s+1)} \cdot \frac{10}{s+10}} = \frac{2K(s+10)}{s(s+1)(s+6)(s+10) + 20K} \ (:= T_1(s))$$

To get $\frac{\theta_D(s)}{D(s)}$, set $R(s) \equiv 0$, then



$$\frac{\theta_D(s)}{D(s)} = \frac{\frac{2}{s(s+1)}}{1 + \frac{2}{s(s+1)} \cdot \frac{K}{s+6} \cdot \frac{10}{s+10}} = \frac{2(s+6)(s+10)}{s(s+1)(s+6)(s+10) + 20K} \ (:= T_2(s))$$

With both R(s) and D(s) acting, $\theta(s) = T_1(s)R(s) + T_2(s)D(s)$, i.e.

$$\theta(s) = \frac{2K(s+10)}{s(s+1)(s+6)(s+10) + 20K} R(s) + \frac{2(s+6)(s+10)}{s(s+1)(s+6)(s+10) + 20K} D(s)$$

5

5. <u>Case (a)</u>

Let $Y_d(s)$ denote the output due to disturbance (i.e. $R(s) \equiv 0$)


For the open loop system,
$$Y_d(s) = \frac{1}{s+a} \cdot T_L(s)$$
 ----- (1)

For the closed-loop system,
$$Y_d(s) = \frac{1}{s+a} (T_L(s) - KY_d(s))$$

$$\Rightarrow Y_d(s) = \frac{1}{s+a+K} T_L(s) \qquad ----- (2)$$

If the disturbance is a unit-step, then

From (1),
$$Y_d(s) = \frac{1}{s+a} \cdot \frac{1}{s}$$
 $\Rightarrow y_d(t) = \frac{1}{a} \left(1 - e^{-at} \right)$
From (2), $Y_d(s) = \frac{1}{s+a+K} \cdot \frac{1}{s}$ $\Rightarrow y_d(t) = \frac{1}{a+K} \left(1 - e^{-(a+K)t} \right)$



<u>Case (b)</u> Again, let $Y_d(s)$ denote the output due to the disturbance.

For the open-loop system,
$$Y_d(s) = T_L(s)$$
 ----- (3)

For the closed-loop system,
$$Y_d(s) = T_L(s) - \frac{K}{s+a} Y_d(s)$$

$$\Rightarrow (s+a+K)Y_d(s) = (s+a)T_L(s)$$

$$\Rightarrow Y_d(s) = \frac{s+a}{s+a+K} T_L(s) \qquad ----- (4)$$

Suppose that $T_L(s)$ is a unit-step disturbance.

From (3), we have $y_d(t) = 1$.

From (4), we have
$$Y_d(s) = \frac{\frac{a}{a+K}}{s} + \frac{\frac{K}{a+K}}{s+a+K} \implies y_d(t) = \frac{a}{a+K} + \frac{K}{a+K}e^{-(a+K)t}$$

