

ECEN 260 Lab Report

Lab #5: Switch-Controlled LEDs with Assembly

Name:	Brodric Young	
-ab Fartiler.	<u>Karl Richards</u>	
Date:	2/5/2025	
Instructor:	Brother Allred	_
Semester:	Winter 2025	

Lab Overview

Replace this text with a paragraph that provides the reader with a clear and brief introduction to the lab. It should also effectively communicate the objectives/goals of the lab and set the appropriate context for the report

This lab focused on using GPIO registers to read inputs from buttons and control LEDs using assembly language on a microcontroller board. The objectives of the lab were to configure GPIO ports for input and output, wire a circuit on a breadboard, and write assembly code to make button controlled LEDs. It required configuring another button and LED and adding some more code to turn on which LED for which button combination was pressed.

Code

```
// **** Configure button 3 (PA1) as input with pull up resistor ****
// MODER
MOV R1, #0xC // 0000 0000 0000 0000 0000 0000 1100
LDR RO, [R4] // load in Port A MODER
AND R0, R1 // bit mask to reset bits 3 and 4
STR RO, [R4] // store PA MODER
// PUPDR
LDR RO, [R4, #0xC] // load in PA PUPDR
MOV R1, #0x4 // 0000 0000 0000 0000 0000 0000 0100
ORR R0, R1 // set bit 2
STR RO, [R4, #0xC] // store PA PUPDR
// ****** Configure LED4 (PA0) as output ********
// Create bitmask to reset bit 1 of PA MODER (bit 0 initializes to 1)
MOV R1, #0x2 // 0000 0000 0000 0010
MVN R1, R1 // 1111 1111 1111 1101
// read PA MODER value, reset bit 1 and write back to PA MODER
LDR RO, [R4] // load PA MODER
AND R0, R1 // bitmask to reset bit 1
STR RO, [R4] // store PA MODER
```

```
// ****** Read status of button 1 (PC13) ********
     MOV R1, #0x2000 // create bitmask to read bit 13 pf PC IDR
     // read PC IDR value, reset all bits except bit 13
     LDRH R0, [R5, \#0x10] // load PC IDR
     AND RO, R1 // bitmask to reset all bits exceet bit 13
     CMP R0, #0 // Zero = button pushed. NonZero = button not pushed
     BNE elseLED2 //if not pushed, go to "elseLED2", if not continue to "if"
if:
     // ******* Read status of button 3 ********
     MOV R1, \#0x2 // bitmask to reset all bits but bit 1
     LDRH R0, [R4, #0x10] // load PA IDR
     AND R0, R1 // reset all bits but bit 1
     CMP R0, \#0 // 0 = button pushed, nonzero = not pushed
     BNE ifLED2andelseLED4 // if not pushed, branch to turn on LED4 and off
LED2
     BL turnonLED2 // both button 1 and 3 pushed
     BL turnoffLED4
     B loop
// this function is called if button 1 is not pressed.
// It reads the status on button 3 and if it is pressed, turns on LED4
// and LED2 off. otherwise branches to turn off both
elseLED2:
     // ******* Read status of button 3 ********
     MOV R1, \#0x2 // bitmask to reset all bits but bit 1
     LDRH R0, [R4, #0x10] // load PA IDR
     AND R0, R1 // reset all bits but bit 1
     CMP R0, \#0 // 0 = button pushed, nonzero = not pushed
     BNE elseLED2and4
          This lab report was created from a template by a student in ECEN 260 during the Winter 2025 semester.
```

Use of this report by students in other semesters is not allowed and is academic dishonesty.

loop:

```
BL turnoffLED2
B loop

// this function turns of both LEDs called when no button is pressed
elseLED2and4:
BL turnoffLED2
BL turnoffLED4
B loop

// this function turns on LED4 and turns off LED2 called when exactly one
// button is pressed
ifLED2andelseLED4:
BL turnoffLED2
BL turnoffLED2
BL turnonLED4
B loop
```

Conclusion

In this lab, I configured GPIO registers to read button inputs and control LEDs based on button presses using assembly language. I wired the circuit, adding another button and LED then enabled an internal pull-up resistor in assembly, and made conditional branching in assembly to create the desired LED behavior for both buttons and LEDs. I learned more about how to use functions in assembly, using bit masks, and the GPIO registers.

In class we had learned about branching and functions in assembly which was crucial to implement the logic we needed for the desired LED behavior. We also learned about the pull-up/down resistors and active low/high inputs which we used in this lab. In another class I saw how bit masks could be used to preform different functions which connected to this lab where we used them to manipulate specific parts of a GPIO register. After doing this coding in assembly language, it will be much easier to program in C later on and it will make much more sense why we do certain things in C.