

TechMart Electronics - User Manual

Navigating the TechMart Companion App:

Home Dashboard: Displays a summary of all connected devices, battery levels, and quick toggles.

Devices Tab: Tap on any specific device to access its detailed settings (e.g., equalizer settings for earbuds, alarm settings for SmartHub).

Analytics Tab: View your usage history, fitness tracking data, and smart home energy reports.

Daily Usage Tips:

To trigger the AI Voice Assistant on the SmartHub, simply say "Hey TechMart".

To reset your Fitness Band, go to Settings -> Device Info -> Factory Reset.

To switch between Noise Cancellation and Transparency mode on the X1 Earbuds, pinch the left earbud sensor twice.

Troubleshooting Common User Errors:

App Freezing: Close the app completely from your phone's multitasking menu and reopen.

Device Not Syncing: Ensure both your phone and the TechMart device have Bluetooth enabled and are within 10 feet of each other.

Incorrect Time on Fitness Band: The band syncs time automatically from your phone. Check that your phone's time zone is set correctly.