

Experiment 1


(i)



(ii)



(iii)


HOME
PLOTS
APPS
FIGURE
FORMAT
TOOLS
Search (Ctrl+Shift+Space)
Hariram
Save As
Copy Figure
Print
Show Code
FILE
Title
Subtitle
X-Label
Y-Label
Z-Label
Legend
Colorbar
Grid
X-Grid
Y-Grid
LABELS AND ANNOTATIONS
MATLAB Drive
I5G6GE1.m
I5G6GE2.m
I5G6GE3.m
/MATLAB Drive/I5G6GE3.m
clc; clear; close all;
Ps = 1; % Signal Power (W)
Pn = [0.1 0.05 0.01]; % Noise Power (W)
Users = 1:3;
SNR = 10*log10(Ps./Pn); % SNR in dB
disp('User Noise Power(W) SNR(dB)')
disp([Users' Pn' SNR'])
figure
bar(Users,SNR)
xlabel('Users')
ylabel('SNR (dB)')
title('Signal-to-Noise Ratio of FDMA Users')
grid on
Figure 1
Signal-to-Noise Ratio of FDMA Users
SNR (dB)
Users
0
5
10
15
20
1
2
3
Debugger
Breakpoints
Pause on Errors
Pause on Warnings
Pause on NaN or Inf
Pause on Output
Function call stack
Not paused in debugger
Command Window
2.0000 0.0500 13.0103
3.0000 0.0100 20.0000
>>