# Report: Configuring Keysight A34461 Multimeter as a Voltmeter Using Python

#### Introduction

This report outlines the process of configuring a Keysight A34461 digital multimeter (DMM) as a voltmeter for precise DC voltage measurements using a Python interface. The configuration is performed via the SCPI commands wrapped in a Python class A34461, which communicates with the instrument over USB.

The goal is to set up the instrument to measure DC voltage within a specific range and resolution, enable autozero for noise reduction, configure triggering for immediate measurement, and acquire a single sample.

## Instrument and Communication Setup

```
resource = "USB0::0x2A8D::0x1401::MY57200246::INSTR"

dmm = A34461(resource)
```

- **Resource String:** Specifies the USB address of the instrument, uniquely identifying the connected Keysight A34461.
- **Instantiation:** The A34461 class is instantiated with the resource string, establishing communication with the instrument using VISA or a similar protocol.

# **Configuration Steps**

1. Configure DC Voltage Measurement

```
dmm.configure_voltmeter(10, resolution=50e-6, autozero='ON', impedance='AUTO')
```

- **Range:** Set to 10 volts, which defines the maximum expected DC voltage to measure. This fixed range improves measurement stability and accuracy compared to autoranging.
- **Resolution:** Set to 50 microvolts (50  $\mu$ V), indicating the smallest voltage increment the instrument will resolve.
- Autozero: Enabled ('ON'), which reduces offset errors by periodically zeroing the input.
- **Impedance:** Set to 'AUTO', allowing the instrument to select the appropriate input impedance automatically for the measurement.

This configuration ensures that the instrument is optimized for precise DC voltage measurement within the specified parameters.

#### 2. Set Sample Count

```
dmm.set_sample_count(1)
```

- Configures the instrument to acquire a single measurement sample per trigger event.
- This is useful for applications where a single instantaneous measurement is sufficient.

#### 3. Configure Trigger Source

```
dmm.set_trigger_source('IMM')
```

- Sets the trigger source to **immediate** ('IMM'), meaning the instrument will start measurement as soon as the command is received.
- This simplifies measurement timing and control in scripts that do not require external or delayed triggering.

#### 4. Set Trigger Delay

```
dmm.set_trigger_delay(0)
```

- Specifies zero delay after the trigger before starting the measurement.
- Ensures the measurement is taken immediately upon triggering, minimizing latency.

## Measurement Acquisition

```
print(dmm.measure())
```

- Executes the measurement command, triggering the instrument to perform the configured DC voltage measurement.
- The result is read back and printed.
- Since the sample count is set to 1 and trigger source is immediate, this returns a single voltage reading.

## Cleanup

```
dmm.close()
```

- Closes the instrument connection gracefully.
- Releases resources and ensures the instrument is ready for future communication.

# Summary

The Python script demonstrates a clear and efficient method to configure a Keysight A34461 multimeter as a precision DC voltmeter. By specifying a fixed voltage range, high resolution, enabling autozero, and configuring immediate triggering with a single sample, the setup is optimized for fast and accurate voltage measurements.

This approach is suitable for automated test environments, laboratory measurements, and any application requiring precise and repeatable DC voltage readings.

### **Potential Extensions**

- Adding error handling for communication failures.
- Configuring additional parameters such as aperture time or NPLC for noise rejection.
- Implementing averaging over multiple samples for improved measurement stability.
- Extending the script to support AC voltage or current measurements.