

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-10-1 Communication Systems Transmitters and Receivers****23-10-1-1 VHF Communication System**

Interval	Installed	Required	Procedure
	2	2	NIL

Both VHF Communication Systems must be operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative VHF/HF Communications Systems must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the Audio Remote Control Display Unit or other radio control with applicable "COMM INOP".
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-10-1. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

COMMUNICATIONS

ATA 23

23-10-1 Communication Systems Transmitters and Receivers

23-10-1-2 HF Communication System

NOT APPLICABLE

— — — —

23-10-1 Communication Systems Transmitters and Receivers

23-10-1-3 HF Antenna coupler (KHF 1050HF System)

NOT APPLICABLE

— — — —

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-10-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-30-1 Alerting System (CHIME/LIGHT)****23-30-1-1 Flight Deck Call Light**

Interval	Installed	Required	Procedure
B	2	0	NIL

May be inoperative provided the flight deck chime is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Chimes and/or Call, PA, EMER Light function must be placarded in the flight compartment and the passenger compartment.

Operating Procedures

None required

Maintenance Procedures

1. Placard the ARCDUs and/or Flight Attendant's Handsets with "CHIMES INOP" and/or "CALL LIGHT INOP", "EMER LIGHT INOP", "PA LIGHT INOP" in the flight compartment and/or the passenger compartment.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-30-1 Alerting System (CHIME/LIGHT)****23-30-1-2 Flight Deck EMER Light**

Interval	Installed	Required	Procedure
B	2	0	NIL

May be inoperative provided the flight deck chime is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Chimes and/or Call, PA, EMER Light function must be placarded in the flight compartment and the passenger compartment.

Operating Procedures

None required

Maintenance Procedures

1. Placard the ARCDUs and/or Flight Attendant's Handsets with "CHIMES INOP" and/or "CALL LIGHT INOP", "EMER LIGHT INOP", "PA LIGHT INOP" in the flight compartment and/or the passenger compartment.
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DAT 00 –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-30-1 Alerting System (CHIME/LIGHT)****23-30-1-3 Flight Deck PA Light**

Interval	Installed	Required	Procedure
B	2	0	NIL

May be inoperative provided the flight deck chime is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Chimes and/or Call, PA, EMER Light function must be placarded in the flight compartment and the passenger compartment.

Operating Procedures

None required

Maintenance Procedures

1. Placard the ARCDUs and/or Flight Attendant's Handsets with "CHIMES INOP" and/or "CALL LIGHT INOP", "EMER LIGHT INOP", "PA LIGHT INOP" in the flight compartment and/or the passenger compartment.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-1. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-30-1 Alerting System (CHIME/LIGHT)****23-30-1-4 Flight Attendant Call Light (At handset)**

Interval	Installed	Required	Procedure
B	2	0	NIL

May be inoperative provided the PA System is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Chimes and/or Call, PA, EMER Light function must be placarded in the flight compartment and the passenger compartment.

Operating Procedures

None required

Maintenance Procedures

1. Placard the ARCDUs and/or Flight Attendant's Handsets with "CHIMES INOP" and/or "CALL LIGHT INOP", "EMER LIGHT INOP", "PA LIGHT INOP" in the flight compartment and/or the passenger compartment.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-1. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-30-1 Alerting System (CHIME/LIGHT)****23-30-1-5 Flight Attendant EMER Light (At handset)**

Interval	Installed	Required	Procedure
B	2	0	NIL

May be inoperative provided the PA System is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Chimes and/or Call, PA, EMER Light function must be placarded in the flight compartment and the passenger compartment.

Operating Procedures

None required

Maintenance Procedures

1. Placard the ARCDUs and/or Flight Attendant's Handsets with "CHIMES INOP" and/or "CALL LIGHT INOP", "EMER LIGHT INOP", "PA LIGHT INOP" in the flight compartment and/or the passenger compartment.
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-1. 5

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-30-1 Alerting System (CHIME/LIGHT)****23-30-1-6 Flight Attendant PA Light (At handset)**

Interval	Installed	Required	Procedure
B	2	0	NIL

May be inoperative provided the PA System is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Chimes and/or Call, PA, EMER Light function must be placarded in the flight compartment and the passenger compartment.

Operating Procedures

None required

Maintenance Procedures

1. Placard the ARCDUs and/or Flight Attendant's Handsets with "CHIMES INOP" and/or "CALL LIGHT INOP", "EMER LIGHT INOP", "PA LIGHT INOP" in the flight compartment and/or the passenger compartment.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-1. 6

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-30-1 Alerting System (CHIME/LIGHT)****23-30-1-7 Flight Attendant ATT Light (At handset)**

Interval	Installed	Required	Procedure
B	2	0	NIL

May be inoperative provided the PA System is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Chimes and/or Call, PA, EMER Light function must be placarded in the flight compartment and the passenger compartment.

Operating Procedures

None required

Maintenance Procedures

1. Placard the ARCDUs and/or Flight Attendant's Handsets with "CHIMES INOP" and/or "CALL LIGHT INOP", "EMER LIGHT INOP", "PA LIGHT INOP" in the flight compartment and/or the passenger compartment.
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-1. 7

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-30-1 Alerting System (CHIME/LIGHT)****23-30-1-8 Flight Attendant Advisory Lights Panels (ALPs)
Lights/Indicators**

Interval	Installed	Required	Procedure
B	-	0	NIL

May be inoperative provided:

- The PA System is operative, and
- Affected alert is not used for lavatory smoke detector alerting.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Chimes and/or Call, PA, EMER Light function must be placarded in the flight compartment and the passenger compartment.

Operating Procedures

None required

Maintenance Procedures

- Placard the ARCDUs and/or Flight Attendant's Handsets with "CHIMES INOP" and/or "CALL LIGHT INOP", "EMER LIGHT INOP", "PA LIGHT INOP" in the flight compartment and/or the passenger compartment.
- Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATE -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-1. 8

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-30-1 Alerting System (CHIME/LIGHT)****23-30-1-9 Flight Attendant Chime**

Interval	Installed	Required	Procedure
B	1	0	NIL

May be inoperative provided:

- The PA system is operative, and
- Affected alert is not used for lavatory smoke detector alerting.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Chimes and/or Call, PA, EMER Light function must be placarded in the flight compartment and the passenger compartment.

Operating Procedures

None required

Maintenance Procedures

- Placard the ARCDUs and/or Flight Attendant's Handsets with "CHIMES INOP" and/or "CALL LIGHT INOP", "EMER LIGHT INOP", "PA LIGHT INOP" in the flight compartment and/or the passenger compartment.
- Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DAT 00 -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-1. 9

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-30-2 Pre-Recorded Announcement (Passenger Briefing) System****23-30-2-1**

Interval	Installed	Required	Procedure
C	1	0	(O)

May be inoperative provided alternate procedures are established and used.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Passenger Briefing/Entertainment System must be placarded in the passenger compartment.

Operating Procedures

Flight Attendant will make appropriate announcement in standard language.

Maintenance Procedures

1. Placard the PES (PASS ENT SYS) with "INOP".
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DAT 00 -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-30-3 Passenger Address and Cabin Interphone System (PACIS)****23-30-3-1 Passenger Address System****23-30-3-1A Passenger Configuration**

Interval	Installed	Required	Procedure
B	1	0	(O)

May be inoperative provided:

- Alternate, normal and emergency procedures and/or operating restrictions are established and used,
- Flight deck to cabin (two way) interphone (including chime alerting system) is verified operative prior to each flight,
- Megaphone(s) is/are readily available and operative, and
- Operations are conducted with at least one flight attendant for 40 passengers or less, or two flight attendants for more than 40 passengers.

NOTE: Any station functions that operate normally may be used.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Passenger Address System (PAS) must be placarded in the flight compartment and the passenger compartment.

Operating Procedures

1. Communication from flight deck crew to cabin crew.

Emergency signal for SCC from flight deck - emergency exit lights flash on & off
Alternate brace and evacuate signals - More than 4 times flashing of seat belt sign.
Food trays should be always stowed and seat upright.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-3. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-30-3 Passenger Address and Cabin Interphone System (PACIS)****23-30-3-1 Passenger Address System****23-30-3-1A Passenger Configuration****2. Communication from cabin crew to passengers**

For passenger safety briefing and demonstration: SCC and L2 will stand on the first row. The SCC will use megaphone to make announcement and L2 will demonstrate. For safety related announcement, megaphone will be used. In emergency situations, shouted commands will be used i.e. brace commands, evacuation commands etc Same procedure is provided in Cabin Attendant Manual Bombardier - Q400 para 10.3.8.2 Sub Point - 2.

NOTE: Megaphone to be replaced at base depending on strength of battery.

3. Verify that two-way communication between the flight compartment and passenger compartment using the cabin interphone system is operative prior to each flight.**Maintenance Procedures**

1. Placard all Flight Attendant PA switchlights and both pilot's ARCDUs with "PA INOP" in the passenger and flight compartment respectively.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-3. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST****COMMUNICATIONS****ATA 23****23-30-3 Passenger Address and Cabin Interphone System (PACIS)****23-30-3-1 Passenger Address System****23-30-3-1B Non-Passenger Configuration**

Interval	Installed	Required	Procedure
A	1	0	(O)

May be inoperative for non-passenger carrying operations for one flight day provided:

- Crew members are the only occupants of the aircraft, and
- Alternate procedures are established and used.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Passenger Address System (PAS) must be placarded in the flight compartment and the passenger compartment.

Operating Procedures

Communication from flight deck crew to cabin crew. Emergency signal from SCC from flight deck – emergency exit light flash on & off. Alternative brace and evacuate signals – More than 4 times flashing of seat belt sign. Food trays should be always stowed and seat upright.

Maintenance Procedures

- Placard all Flight Attendant PA switchlights and both pilot's ARCDUs with "PA INOP" in the passenger and flight compartment respectively.
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-3. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST****COMMUNICATIONS****ATA 23****23-30-3 Passenger Address and Cabin Interphone System (PACIS)****23-30-3-2 Cabin Interphone System (Flight Deck to Cabin, and Cabin to Cabin)****23-30-3-2A Passenger Configuration**

Interval	Installed	Required	Procedure
B	-	1	(O)

May be inoperative provided:

- An operative flight deck to cabin (two way) interphone is at an operative flight attendant seat,
- The Passenger Address System is verified operative prior to each flight, and
- Alternate communications procedures are established and used.

NOTE: Any station functions that operate normally may be used.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Cabin Interphone System (CIS) must be placarded in the flight compartment and the passenger compartment.

Operating Procedures

- All announcements to be made by the crew at the operative station.
- Cabin and Galley Secure Check to be passed to the PIC from the crew at the operative station. [Appropriate hand signals (a thumbs up sign) to be used to pass the Cabin and Galley Secure Check from the crew at inoperative station to the crew at operative station. The crew at the operative station must acknowledge and reciprocate to the check by the said hand signals (a thumbs up sign)]
- In case of an emergency, the one who encounters the emergency first will call for back-up. It will be the responsibility of the back-up crew to inform the PIC.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-3. 5



DHC-8-402

MINIMUM EQUIPMENT LIST

COMMUNICATIONS

ATA 23

23-30-3 Passenger Address and Cabin Interphone System (PACIS)

23-30-3-2 Cabin Interphone System (Flight Deck to Cabin, and Cabin to Cabin)

23-30-3-2A Passenger Configuration

NOTE: Maintain a continuous communication with the PIC.

4. Verify that the passenger Address System is operative prior to each flight.

Maintenance Procedures

1. Placard the Audio Remote Control Display Units indicating which function of the Cabin Interphone System is inoperative.
2. Placard inoperative Flight Attendant's Interphone select button with "INPH. INOP".
3. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-3. 6

**DHC-8-402****MINIMUM EQUIPMENT LIST****COMMUNICATIONS****ATA 23****23-30-3 Passenger Address and Cabin Interphone System (PACIS)****23-30-3-2 Cabin Interphone System (Flight Deck to Cabin, and Cabin to Cabin)****23-30-3-2B Non-Passenger Configuration**

Interval	Installed	Required	Procedure
A	1	0	(O)

May be inoperative for non- passenger carrying operations for one flight day provided:

- Crew members are the only occupants of the aircraft, and
- Alternate procedures are established and used.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Cabin Interphone System (CIS) must be placarded in the flight compartment and the passenger compartment.

Operating Procedures

Following communication procedures are to be used:

- All announcements to be made by the crew at the operative station.
- Cabin and Galley Secure Check to be passed to the PIC from the crew at the operative stations. [Appropriate hand signals (a thumbs up sign,) to be used to pass the Cabin and Galley Secure Check from the crew at inoperative station to the crew at operative station. The crew at the operative station must acknowledge and reciprocate to the check by the said hand signals (a thumbs up sign)]
- In case of an emergency, the one who encounters the emergency first will call for back-up. It will be the responsibility of the back-up crew to inform the PIC.

NOTE: Maintain a continuous communication with the PIC.

Maintenance Procedures

- Placard the Audio Remote Control Display Units indicating which function of the Cabin Interphone System is inoperative.
- Placard inoperative Flight Attendant's Interphone select button with "INPH. INOP".
- Make appropriate entry in the aircraft journey log.

ISS III R00

APPROVED BY DAW DELHI, DATE -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-3. 7

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-30-4 Active Noise and Vibration Suppression System**

Interval	Installed	Required	Procedure
D	1	0	(M)

May be inoperative.

NOTE: Aircraft may be dispatched with system operative in the DEGRADED mode with ANVS SYS DEGRADED lamp illuminated on the Maintenance Panel.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Active Noise and Vibration Suppression (ANVS) System must be placarded on the Flight Attendant Control Panel.

Operating Procedures

None required

Maintenance Procedures

NOTE: It is recommended the controller remain installed/powered until a replacement is available

1. PAUSE button pressed rather than turning the system OFF.

NOTE: If symptoms of hammering noise from ATVAs (Active Tuned Vibration Attenuators) become noticeable, perform Step 2, otherwise go to Step 3.

2. Select ANVS OFF at the control panel or open and clip the associated ANVS circuit breakers on the right DC circuit breaker panel.

NOTE:

1. PBMS (Propeller Balancing Monitoring System) will not be available, if installed.
2. Prolonged periods with ANVS OFF or open ANVS circuit breakers may cause damage to the ATVAs.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-4. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

COMMUNICATIONS

ATA 23

23-30-4 Active Noise and Vibration Suppression System

3. Placard Forward Flight Attendant's Panel with "ANVS INOP".
4. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00

APPROVED BY DAW DELHI, DATED –

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-30-4. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-40-1 Service Interphone System (Flight
Compartment to Ground Crew)****23-40-1-1**

Interval	Installed	Required	Procedure
C	1	0	(O)

May be inoperative provided alternate procedures are established and used.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Service Interphone System must be placarded in the flight compartment.

Operating Procedures

- 1) Verify to ground crew personnel before main cabin door is closed that Nose-Wheel Steering is selected off. (If pushback required)
- 2) Use standard hand signals as required.

Maintenance Procedures

1. Placard the Audio and Radio Control Display Unit (ARCDU) with "GND INTERPHONE INOP".
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-40-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-40-1 Service Interphone System (Flight
Compartment to Ground Crew)****23-40-1-2**

Interval	Installed	Required	Procedure
D	1	0	NIL

May be inoperative provided procedures are not dependent on its use.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Service Interphone System must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the Audio and Radio Control Display Unit (ARCDU) with "GND INTERPHONE INOP".
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-40-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-50-1 Boom Microphone Push-To-Talk (PTT) Switches**

Interval	Installed	Required	Procedure
C	4	2	(M)

May be inoperative provided one switch at each pilot's position is verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Boom Microphone Push-To-Talk switches must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures**FOR FAILURE CONDITIONS OF THE PTT SWITCH(ES) FAILING TO TRANSMIT:**

1. No maintenance check is required.
2. Placard the respective PTT switch as INOP.
3. Make appropriate entry in the aircraft journey log.

FOR FAILURE CONDITIONS OF THE PTT SWITCH(ES) CAUSING CONTINUOUS TRANSMIT: Pilot and Co-pilot Control Column PTT Switch

1. Open the following circuit breakers:
 - a) PILOT (PLT) AUDIO - Left DC C/B Panel - 28V ESSENTIAL Bus
 - b) PILOT (PLT) AUDIO - Avionics C/B Panel - Right MAIN DC Bus
 - c) CO-PILOT (COPLT) AUDIO - Avionics C/B Panel - Right ESSENTIAL DC Bus
 - d) CO-PILOT (COPLT) AUDIO - Avionics C/B Panel - Left MAIN DC Bus
2. Ensure personnel and equipment are clear of aircraft elevator surfaces.
3. Pull back appropriate control column to access forward face of column.
4. Remove the appropriate retainer plate from forward face.
5. Disconnect the wires to the PTT switch at the appropriate terminal junction:

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DAT 00 -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-50-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST****COMMUNICATIONS****ATA 23****23-50-1****Boom Microphone Push-To-Talk (PTT)
Switches**

- a) Pilot's switch at terminal junction 9811-TB"A" pin B1 (Wire 2350-0668C-24-4).
- b) Co-pilot's switch at terminal junction 9811-TB"H" pin C1 (Wire 2350-0677A-24-4).
6. Tape and stow the disconnected wires.
7. Close the circuit breakers opened in step (1) above.
8. At the ARCDU respective of the PTT switch, move the MIC select knob to "INT" position. At the opposite ARCDU, select "SERV/INT VOL" and speaker "SPKR VOL" to on, adjusting both to about mid-listening level. Using the affected PTT switch and respective BOOM MIC, confirm that no voice communication is possible over opposite cockpit speaker.
9. Install retainer plate.
10. Placard the control column with "PTT INOP".
11. Make appropriate entry in the aircraft journey log.

PTT Switch on Nose Wheel Steering Tiller

1. Open the following circuit breakers:
 - a) "PLT AUDIO" - on L ESSENTIAL dc bus
 - b) "NLG STEER CONT 1" - L Main.
 - c) "NLG STEER CONT 2" - R Main.
2. Remove side panel from pilot's side console to gain access to 3251-P3.
3. Disconnect 3251-P3 and remove wire 2350-2514A-22N-4 from pin 5.
4. Tape and stow wire and reconnect 3251-P3.
5. Close the circuit breakers.
6. At the Pilot's audio control panel respective of the PTT switch, move the MIC select knob to "INT" position. At the Co-pilot's audio control panel, select "SERV/INT VOL" and speaker "SPKR VOL" to on, adjusting both to about mid-listening level. Using the nose wheel steering tiller PTT switch and respective BOOM MIC, confirm that no voice communication is possible over opposite cockpit speaker.

CAUTION: Ensure gear ground locks are engaged and control surfaces clear of personnel.

7. Pressurize HYD SYS #2.
8. Switch on nose wheel steering using "STEERING" switch on pilot's side console.
9. Cycle steering tiller full travel in both direction and physically confirm nosewheel travel.
10. Confirm "NOSE STEERING" Caution Light is out.

*(...Continued)***ISS III R00****APPROVED BY DAW DELHI, DATE -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-50-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-50-1 Boom Microphone Push-To-Talk (PTT)
Switches**

11. Depressurize #2 HYD system.
12. Install retainer plate.
13. Placard the pilot's side of console with "PTT INOP".
14. Make appropriate entry in the journey log.

XMIT Switch on the Co-pilot Side Console

1. Open the following circuit breakers:
 - a) "CO-PILOT AUDIO" - on R ESSENTIAL dc bus.
 - b) "CO PLT CB PANEL LTS" - on R ESSENTIAL dc bus
 - c) "PANEL LTS CO PLT FLT" - on R MAIN dc bus.
2. Remove Co-pilot side console side panel to gain access to connector 9811-P168.
3. Disconnect 9811-P168. Remove XMIT switch wire at connector pin b.
4. Tape and stow disconnect wire.
5. Reconnect 9811-P168 and reinstall side panel.
6. Close the circuit breakers.
7. At the Co-pilot's audio control panel respective of the PTT switch, move the MIC select knob to "INT" position. At the Pilot audio control panel, select "SERV/INT VOL" and speaker "SPKR VOL" to on, adjusting both to about mid-listening level. Using the affected XMIT switch and Co-pilot's BOOM MIC, confirm that no voice communication is possible over opposite cockpit speaker.
8. Install the side panel.
9. Placard the switch with "XMIT INOP".
10. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-50-1. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-50-2 Headsets**

Interval	Installed	Required	Procedure
D	3	2	NIL

One required at each pilot's station.

Minimum Equipment List Procedures (MELP)**Placard**

Placard in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-50-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-50-3 Flight Compartment Speakers**

Interval	Installed	Required	Procedure
C	2	0	(O)

May be inoperative provided:

- Procedures are not dependent on their use,
- Headsets are installed and used by each person on flight deck duty,
- All aural alerts, messages and other communication which are normally routed through the flight deck speakers must be audible through headsets, and
- A spare headset must be readily available for crew use.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Flight Compartment Speakers in the flight compartment.

Operating Procedures

Confirm aural warnings are present in the headset respective to each of the failed speakers by selecting the ADC TEST 1/2 switch on the pilot's side console and listening for the Overspeed Warning.

Maintenance Procedures

- Placard pilot and/or co-pilot flight compartment speakers on the speaker covers.
- Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-50-3. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-50-4 Boom Microphones (incl. Headset mics)**

Interval	Installed	Required	Procedure
A	2	0	NIL

May be inoperative provided:

- The Flight Data Recorder (FDR) operates normally, and
- Repairs are made within three flight days.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Boom Microphone(s) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Placard the defective microphone "Boom Mic INOP".
- Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-50-4. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-50-5 Cockpit Handheld Microphones**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative provided associated boom microphones are operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Cockpit Handheld Microphones must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative Cockpit Handheld Microphones in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-50-5. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-50-6 Cabin Handsets**

Interval	Installed	Required	Procedure
B	-	1	(O)

May be inoperative provided:

- One cabin handset operates normally,
- Operative handset is located at an operative flight attendant seat, and
- Alternate communication procedures between the affected flight attendant station(s) are established and used.

NOTE: Any station that operates normally may be used.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Cabin Handsets must be placarded in the flight compartment.

Operating Procedures

Alternative communication procedures for all necessary internal communications are established and used.

Maintenance Procedures

- Placard the inoperative Cabin Handset "HANDSET INOP".
- Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-50-6. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-50-7 Observer's Audio Control Panel****23-50-7-1**

Interval	Installed	Required	Procedure
B	1	0	NIL

May be inoperative except when required by a person in an official capacity.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Audio Control Panel must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the inoperative ACP.
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-50-7. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-50-7 Observer's Audio Control Panel****23-50-7-2**

Interval	Installed	Required	Procedure
D	1	0	NIL

May be inoperative provided the seat is not required to be available in an official capacity for extended periods of time.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Audio Control Panel must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the inoperative ACP.
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-50-7. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-60-1 Static Dischargers**

Interval	Installed	Required	Procedure
D	25	19	NIL

May be missing provided no more than one is missing from each control surface cluster.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Static Dischargers must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative Static Dischargers on the glareshield.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-60-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-70-1****Cockpit Voice Recorder**

Interval	Installed	Required	Procedure
A	1	0	NIL

May be inoperative provided:

- The Flight Data Recorder is operative, and
- Aircraft may continue the flight or series of flights but does not depart from a station where rectification or replacement can be made.

NOTE: In case of Aircraft does not operate to a station where rectification or replacement can be made, it should be replaced within 24 hours elapsed time.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Cockpit Voice Recorder in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Placard the CVR Control Panel in flight compartment.
- Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-70-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****COMMUNICATIONS******ATA 23*****23-80-1 ARCDU Radio Tuning Function (Aircraft with at least one FMS installed)**

Interval	Installed	Required	Procedure
C	2	1	(O)

May be inoperative provided:

- FMS Radio Tuning Function of the inoperative ARCDU in “FMS” mode is verified operative.
- The operative ARCDU Radio Tuning Function is verified operative in “BOTH” or “FMS” mode.

NOTE: CAT II and RNAV 5 operations not permitted.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative ARCDU1 or ARCDU2 tuning function must be placarded in the flight compartment.

Operating Procedures

The Tune Page, on the FMS display, is used to tune the aircraft radios, select and store preselected frequencies for each radio, and view the selected frequencies (active and preset) for each radio. The Tune Page is accessed from any mode by pressing the TUNE key on the FMS front panel.

If previous flight has confirmed the tuning function of the operative ARCDU in “BOTH” mode the following procedure is not required.

- Set operative ARCDU MODE selector to “BOTH” or “FMS” mode.
- Confirm tuning of pilot and co-pilot communication and navigation frequencies.
- Establish audio communication with tower.

FMS Radio Tuning Function of the failed ARCDU in “FMS” mode is verified operative as follows:

- Set the failed ARCDU in “FMS” mode.
- Use the FMS Control Display Unit –TUNE key for tuning the pilot and co-pilot communication and navigation frequencies.
- Repeat item 2 for all applicable radio units.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-80-1. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

COMMUNICATIONS

ATA 23

23-80-1 ARCDU Radio Tuning Function (Aircraft with at least one FMS installed)

Maintenance Procedures

1. Placard inoperative ARCDU in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00

APPROVED BY DAW DELHI, DATED –

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

23-80-1. 2