

**DHC-8-402****MINIMUM EQUIPMENT LIST*****PROPELLERS******ATA 61*****61-20-1 Propeller Maintenance Unfeather Function**

Interval	Installed	Required	Procedure
D	2	0	(M#)

May be inoperative provided an alternate feather check is performed.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Propeller Maintenance Unfeather Function must be placarded on the Central Maintenance Panel in the wardrobe.

Operating Procedures

None required.

Maintenance Procedures

1. With the engine stationary, ensure the propeller is in the unfeather state, using blade bats if necessary.
2. For the associated engine, set the Condition Lever to FUEL OFF and PLA to DISC.
3. On the Propeller Control Panel, select ALT FEATHER for the associated propeller.

NOTE: If at any time during this procedure propeller stops moving when the Aux. Pump is running, a dry motoring cycle must be repeated to replenish the Aux. tank.

4. Visually determine that the propeller blades move to the feather position.
5. On the Central Maintenance Panel, placard the affected MAINTENANCE UNFEATHER switch "INOP".
6. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

61-20-1. 1



Interval	Installed	Required	Procedure
A	2	-	(M)

SN	EMU FAULT CODE	DESCRIPTION
1.	40	FADEC Tx-Wraparound error
2.	132	Beta tracking error
3.	158	Speed tracking error
4.	180	CLA sum out of range
5.	182	CLA Va out of range
6.	184	CLA Vb out of range
7.	186	CLA computed value out of range
8.	220	Last AUPC test failed
9.	336	WoW A invalid
10.	338	WoW B invalid
11.	360	28V PMA fault
12.	470	FADEC Torque invalid
13.	474	Invalid FADEC 28V Available bit

Minimum Equipment List Procedures (MELP)

1. Placard inoperative PEC System in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

61-20-2. 1