



DHC-8-402 (Q400) AIRCRAFT 'PRE-FLIGHT INSPECTION' SCHEDULE

THIS SCHEDULE IS TO BE PHYSICALLY CARRIED OUT AND REFERRED TO BY AUTHORISED PERSON WHILE PERFORMING THIS CHECK

1. ARRIVAL CHECKS:

- a. Place chocks, as required.
- b. Check documents on board, Review sector defects (any observation to be appropriately corrected as per AMM/Company Policy), Review Deferred Defects (Including MEL items), Cabin Defects, Notes to Crew and Engineers and take appropriate action as required.
Note: Ensure that Cabin defects with respect to Emergency equipment including life vests are attended appropriately before release of aircraft.
- c. Ensure that aircraft external surfaces, engines inlet/exhaust and propellers are free from damages, snow, ice, dust and sand etc.
- d. If halt is more than two hrs
 - (i) Install Main Landing gears ground lock pins and engage Nose gear ground lock.
 - (ii) Whenever any landing gear door is opened, install relevant landing gear door safety pins.
 - (iii) Install Pitot Static covers.

Note: Make an entry for Item "d" above in Technical Log.

WARNING: DO NOT INSTALL THE COVERS WHEN THE PITOT STATIC PROBES ARE HOT. THE COVER WILL MELT AND CAUSE A BLOCKAGE OF THE HOLES IN THE PITOT STATIC PROBE. THIS CAN CAUSE INJURY TO PERSONNEL AND/OR DAMAGE TO EQUIPMENT.

Carryout General Visual Inspection of following area (Para 2 to 10 below) for satisfactory condition and for wear, general appearance of airplane for indication of insecure installation, lighting strike, any leakage / damage / FOD / Bird Hit etc. :

2. FORWARD FUSELAGE

- a. Check Pitot – Static Probes, AOA vane, Ice detection Probe, TAT Probe, Antennas for satisfactory condition and any damage.
- b. Check Fwd Entry Door and Fuselage skin and all access panels for security.
- c. Check Radome, windshields, cockpit windows, Windshield wipers for satisfactory condition and security.
- d. Check Crew Oxygen bottle for overboard discharge indicator Green burst disc.
- e. Check Fwd baggage door, Nose Bay doors & cargo compartments for closure, any fluid spillage, security of lining & ceiling panels.
- f. Inspect outflow vent is clear.
- g. Inspect Nose Gear Wheel Well, components in the area and Nose Wheel Tires for general condition. Check tires and wheels for proper condition and inflation. Check Nose landing gear and it's area for leaks & ensure correct extension of the Oleo.
- h. Check all access panels for security
- i. Check Taxi Light, Forward Egress Light and Emergency Light for condition and security.

3. WING

- a. Visually inspect all areas of wings lower surface, Inboard and outboard De-icing Boot, flight control surfaces & tank vents for condition and obvious damage, FOD, leaks, missing fasteners & fairings etc.
- b. Check all under wing access panels for security. Sump drain valves, Inboard and Outboard tank water drains for leaks.
- c. Check static temperature probe for satisfactory condition and any damage.
- d. Check Static Dischargers for presence and damage.
- e. Check fuel tank ram air (NACA) Vents are clear.
- f. Check Wing inspection lights, Landing Lights, Wing tip and navigation lights for condition and security.

4. ENGINE AND NACELLE

- a. Check Propeller blade and spinner, Engine Intake and Exhaust for any FOD and any dents/damage.
- b. Check Engine Inboard and Outboard Panels and Cowls for security of installation, Inboard and Outboard Nacelle Drains
- c. Check Oil Cooler Door
- d. Check for any sign of fuel/oil/fluid leak.



5. MAIN LANDING GEARS AND WHEEL WELL:

- Check LH and RH landing gears for leaks & ensure correct extension of the Oleo.
- Check Tires and wheels for proper condition and inflation.
- Check Brakes, wear indicators.
- Check wheel well area for leaks, loose / missing fasteners & fairings, light etc.

6. AFT FUSELAGE & EMPENNAGE:

- Check aft fuselage general condition and Air Cond. Pack Ram Air Inlet (Dorsal Fin NACA Vent)
- Check APU Intake and exhaust.
- Check Vertical Stabilizer along with Deicing Boots, Rudder, Horizontal stabilizer along with Deicing Boots, elevators for proper condition and security.
- Check Accumulator Pressure (Min 1500 P.S.I. for first flight of the day and Min 1000 P.S.I. for subsequent flights)
- Check aft Cabin Service /Emergency Exit Egress Light/Emergency Exit and Aft Cabin Passenger/Emergency Exit Egress Light/Emergency Exit, Navigation Light and Strobe Light for proper condition and security.
- Check drain mast is clean.
- Check static dischargers (for presence and damage).
- Check Aft Baggage Door and cargo compartments for any fluid spillage, security of lining & ceiling panels.

7. COCKPIT:

- Scan cockpit instrument panels for any abnormal indication / configuration.
- Scan the CB panels in the cockpit for appropriate position.
- Check crew oxygen pressure is sufficient to satisfy dispatch requirement.
- Check Landing Gear Alternate Release Door (above the copilot's seat) and Landing Gear Alternate Extension Door (on the floor, left of the copilot's seat) are completely closed before flight.
- Check the landing Gear Extension Inhibit switch is set to NORMAL with the Red Guard closed.
- Check hydraulic reservoirs quantity on MFD, quantity indications should be at least 60%. If less on any of the three hydraulic reservoirs, consult MCC before release to service.

8. PASSENGER CABIN:

- Carryout General Visual Inspection for any obvious damage / abnormalities.
- Check serviceability of all interior Emergency Lights.

9. REFUELING:

Carry out fuel sampling check for water and other contaminants before refueling and refuel the aircraft observing all appropriate refueling precautions.

- Make a entry in Aircraft Technical Log Sector Record (i.e.TLP) for the arrival, uplift & departure Hydraulic, Oil and Fuel quantity before release of aircraft.
- If there is no uplift required then "NIL" should be recorded in TLP
- All relevant TLP column should be duly filled up as per current LMP.

10. DEPARTURE CHECKS:

Ensure following:

- Remove all landing gear lock pins and landing gear door safety pins (if installed) and stow them in designated location on forward passenger door.
- Nose Gear ground lock is fully flush with fuselage.
- Ensure all Pitot Static covers, any blanks are removed (if installed) before departure.

Note: Make an entry in regard of item "a,b,c" above in Technical Log to clear entry raised for Item d (i),(ii) and (iii) above of Arrival Checks.

- All panels are closed and latched.
- Cargo compartment nets are lashed properly.
- Ensure pax & Cargo door seals are not damaged prior to closing the doors.(Remove locks if installed)
- All doors closed properly prior to final departure and crew informed. (Remove locks if installed)
The cabin and cargo door handles are flush with the fuselage after closure.
- MEL items revoked / carried forward in an appropriate manner.
- Tech Log is duly filled up and signed.
- Toilet and potable water serviced. (as required).
- Ensure chocks are removed prior to departure

Prepared by

Shagun Sharma
Assistant Engineer

Checked by

Harish Nagarajan
AGM-Planning

Approved by

Utpalendu Sonar
Phca

Note: In case of any abnormal observation or doubt contact: Maintenance Control Cell (MCC): +91-9654027779
Form No. SJ/PPD/66/Q400 Issue 1 Rev 9 Dated 17 Jan 2025 +91-8588823850

Email: mcc@spicejet.com