

## MECHANICAL PROPERTIES

- Stress and strain: What are they and why are they used instead of <u>force and deformation</u>?
- Elastic behavior:
- Plastic behavior:
- Youngs Modulus, Yield Strength, and Tensile Strength
- Toughness and ductility:


#### **ELASTIC DEFORMATION**



### PLASTIC DEFORMATION (METALS)




#### Types of Loading




## **ENGINEERING STRESS**

• Tensile stress, σ:



• Shear stress, τ:




Stress unit?

### **ENGINEERING STRAIN**

• Tensile strain:


$$\epsilon = \frac{\delta}{L_o}$$



Lateral strain:


$$\varepsilon_{L} = \frac{-\delta_{L}}{W_{o}}$$

• Shear strain:




Strain unit?


#### STRESS-STRAIN TESTING




## Typical Stress-Strain Curve




## Engineering Strain vs True Strain



#### Ductile Vs Brittle Failure



#### Stress Strain Curve of Brittle Ductile Plastic materials



## Linear Elastic Properties

- Modulus of Elasticity, E: (also known as Young's modulus)
- Hooke's Law:

$$\sigma = \mathbf{E} \varepsilon$$


• Poisson's ratio, v:

$$v = -\frac{\varepsilon_L}{\varepsilon}$$

metals: *∨* ~ 0.33

ceramics: ~0.25

polymers: ~0.40



Unit of E?


## Other elastic properties


 Elastic Shear modulus, G:

$$\tau = \mathbf{G} \gamma$$

 Elastic Bulk modulus, K:

$$P = -K \frac{\Delta V}{V_O}$$






 $= \Delta V$ 

Special relations for isotropic materials:

$$G = \frac{E}{2(1+v)}$$
  $K = \frac{E}{3(1-2v)}$ 


## Comparison of Young's Modulus, E:



## **Eceramics**

- > Emetals
- >> Epolymers

### PLASTIC (PERMANENT) DEFORMATION




## Yield Strength

• Stress at which *noticeable* plastic deformation has occurred.

when  $\varepsilon_p = 0.002$ tensile stress, σ  $\sigma_{\mathbf{V}}$ engineering strain, ε

## Yield Strength: Comparison



#### <sup>o</sup>y(ceramics)

- >>σy(metals)
  >> σy(polymers)

#### **Room T values**

Based on data in Table B4, Callister 6e.

= annealed

= hot rolled

ag = aged


cd = cold drawn

cw = cold worked

qt = quenched & tempered

## Tensile Strength, TS


Maximum possible engineering stress in tension.



Adapted from Fig. 6.11, *Callister 6e.* 

- Metals: occurs when noticeable necking starts.
- Ceramics: occurs when crack propagation starts.
- Polymers: occurs when polymer backbones are aligned and about to break.


## Tensile Strength: Comparison



## Ductility, %EL


• Plastic tensile strain at failure: %EL = =

$$\%EL = \frac{L_f - L_o}{L_o} \times 100$$



• Another ductility measure:  ${}^{\text{A}}$ AR =  ${}^{\text{A}}$ 


$$\%AR = \frac{A_0 - A_f}{A_0} \times 100$$



Engineering stress—strain behavior for iron at three temperatures.


## STRAIN HARDENING

• An increase in  $\sigma_y$  due to plastic deformation.



## Toughness

- Energy to break a unit volume of material
- Approximate by the area under the stress-strain curve.




#### Resilience

Resilience is the capacity of a material to absorb energy when it is deformed elastically and then, upon unloading, to have this energy recovered. The associated property is the modulus of resilience,  $U_r$ , which is the strain energy per unit volume required to stress a material from an unloaded state up to the point of yield

$$U_r = \frac{1}{2}\sigma_y \varepsilon_y$$

 $\varepsilon_y$  is the strain at yielding.

$$U_r = \frac{1}{2}\sigma_y \,\varepsilon_y = \frac{1}{2}\sigma_y \left(\frac{\sigma_y}{E}\right) = \frac{\sigma_y^2}{2E}$$



#### Problem 1


#### Elongation (Elastic) Computation

A piece of copper originally 305 mm (12 in.) long is pulled in tension with a stress of 276 MPa (40,000 psi). If the deformation is entirely elastic, what will be the resultant elongation?

	Modulus of Elasticity		Shear	Modulus	
Metal Alloy	GPa	10 <sup>6</sup> psi	GPa	10 <sup>6</sup> psi	Poisson's Ratio
Aluminum	69	10	25	3.6	0.33
Brass	97	14	37	5.4	0.34
Copper	110	16	46	6.7	0.34
Magnesium	45	6.5	17	2.5	0.29
Nickel	207	30	76	11.0	0.31
Steel	207	30	83	12.0	0.30
Titanium	107	15.5	45	6.5	0.34
Tungsten	407	59	160	23.2	0.28

#### Computation of Load to Produce Specified Diameter Change

A tensile stress is to be applied along the long axis of a cylindrical brass rod that has a diameter of 10 mm (0.4 in.). Determine the magnitude of the load required to produce a  $2.5 \times 10^{-3}$ -mm ( $10^{-4}$ -in.) change in diameter if the deformation is entirely elastic.



	Modulus of Elasticity		Shear	Modulus	
Metal Alloy	GPa	10 <sup>6</sup> psi	GPa	10 <sup>6</sup> psi	Poisson's Ratio
Aluminum	69	10	25	3.6	0.33
Brass	97	14	37	5.4	0.34
Copper	110	16	46	6.7	0.34
Magnesium	45	6.5	17	2.5	0.29
Nickel	207	30	76	11.0	0.31
Steel	207	30	83	12.0	0.30
Titanium	107	15.5	45	6.5	0.34
Tungsten	407	59	160	23.2	0.28

#### **True Stress**

#### **True Strain**

$$\sigma_T = \frac{F}{A_i}$$

$$\varepsilon_T = \ln \frac{l_i}{l_0}$$

No Volume Change/ Incompressible

$$A_i l_i = A_0 l_0$$

# Relation between True & Engineering stress and strain

$$\sigma_T = \sigma(1 + \varepsilon)$$

$$\varepsilon_T = \ln\left(1 + \varepsilon\right)$$

#### Relation between True stress and True strain

$$\sigma_T = K\varepsilon_T^n$$

## *n* is often termed the *strain-hardening exponent*

		K		
Material	n	MPa	psi	
Low-carbon steel (annealed)	0.21	600	87,000	
4340 steel alloy (tempered @ 315°C)	0.12	2650	385,000	
304 stainless steel (annealed)	0.44	1400	205,000	
Copper (annealed)	0.44	530	76,500	
Naval brass (annealed)	0.21	585	85,000	
2024 aluminum alloy (heat-treated—T3)	0.17	780	113,000	
AZ-31B magnesium alloy (annealed)	0.16	450	66,000	

#### **Ductility and True-Stress-at-Fracture Computations**

A cylindrical specimen of steel having an original diameter of 12.8 mm (0.505 in.) is tensile-tested to fracture and found to have an engineering fracture strength  $\sigma_f$  of 460 MPa (67,000 psi). If its cross-sectional diameter at fracture is 10.7 mm (0.422 in.), determine

- (a) The ductility in terms of percentage reduction in area
- **(b)** The true stress at fracture


#### Calculation of Strain-Hardening Exponent

Compute the strain-hardening exponent n in Equation for an alloy in which a true stress of 415 MPa (60,000 psi) produces a true strain of 0.10; assume a value of 1035 MPa (150,000 psi) for K.

$$\sigma_T = K \varepsilon_T^n$$

#### **HARDNESS**

- Measure of a material's resistance to localized plastic deformation (e.g., a small dent or a scratch).
- Large hardness means:
  - --resistance to plastic deformation or cracking in compression.
  - --better wear properties.




#### Various Hardness Tests

		Shape of Indentation				Formula for
Test	Indenter	Side View	Top View	Load		Hardness Numbera
Brinell	10-mm sphere of steel or tungsten carbide		→ d ←	P		$HB = \frac{2P}{\pi D[D - \sqrt{D^2 - d^2}]}$
Vickers microhardness	Diamond pyramid	136°	$d_1$ $d_1$	P		$HV = 1.854P/d_1^2$
Knoop microhardness	Diamond pyramid	l/b = 7.11 b/t = 4.00	b	P		$HK = 14.2P/l^2$
Rockwell and superficial Rockwell	Diamond cone: $ \frac{1}{16}, \frac{1}{8}, \frac{1}{4}, \frac{1}{2} \text{-in.} $ diameter steel spheres	120°		150 kg )	Rockwell Superficial Rockwell	


<sup>&</sup>lt;sup>a</sup>For the hardness formulas given, P (the applied load) is in kg, and D, d,  $d_1$ , and l are all in millimeters.

## Comparison of Different hardness scales



**Correlation between Hardness** 

and Tensile Strength



Brinell hardness number

For Most Steels,

$$TS(MPa) = 3.45 \times HB$$

$$TS(psi) = 500 \times HB$$

#### VARIABILITY OF MATERIAL PROPERTIES

#### Average and Standard Deviation Computations

The following tensile strengths were measured for four specimens of the same steel alloy:

Sample Number	Tensile Strength (MPa)
1	520
2	512
3	515
4	522

- (a) Compute the average tensile strength.
- **(b)** Determine the standard deviation.

Average 
$$value \qquad \overline{x} = \frac{\sum_{i=1}^{n} x_i}{n}$$

Standard deviation 
$$s$$
 
$$s = \left[ \frac{\sum_{i=1}^{n} (x_i - \overline{x})^2}{n-1} \right]^{1/2}$$


n is the number of observations or measurements and  $x_i$  is the value of a discrete measurement.

### **Average and Standard Deviation Computations**

The following tensile strengths were measured for four specimens of the same steel alloy:


Sample Number	Tensile Strength (MPa)
1	520
2	512
3	515
4	522

- (a) Compute the average tensile strength.
- **(b)** Determine the standard deviation.



# **DESIGN OR SAFETY FACTORS**

Design uncertainties mean we do not push the limit.



### Specification of Support-Post Diameter

A tensile-testing apparatus is to be constructed that must withstand a maximum load of 220,000 N (50,000 lb<sub>f</sub>). The design calls for two cylindrical support posts, each of which is to support half of the maximum load. Furthermore, plain-carbon (1045) steel ground and polished shafting rounds are to be used; the minimum yield and tensile strengths of this alloy are 310 MPa (45,000 psi) and 565 MPa (82,000 psi), respectively. Specify a suitable diameter for these support posts.

#### Materials Specification for a Pressurized Cylindrical Tube

(a) Consider a thin-walled cylindrical tube having a radius of 50 mm and wall thickness 2 mm that is to be used to transport pressurized gas. If inside and outside tube pressures are 20 and 0.5 atm (2.027 and 0.057 MPa), respectively, which of the metals and alloys listed in Table 6.8 are suitable candidates? Assume a factor of safety of 4.0.

For a thin-walled cylinder, the circumferential (or "hoop") stress ( $\sigma$ ) depends on pressure difference ( $\Delta p$ ), cylinder radius ( $r_i$ ), and tube wall thickness (t) as follows:

$$\sigma = \frac{r_i \, \Delta p}{t}$$

These parameters are noted on the schematic sketch of a cylinder presented in Figure


(b) Determine which of the alloys that satisfy the criterion of part (a) can be used to produce a tube with the lowest cost.


Alloy	Yield Strength, $\sigma_y$ (MPa)	Density, ρ (g/cm³)	Unit mass cost, $\overline{c}$ (\$US/kg)
Steel	325	7.8	1.25
Aluminum	125	2.7	3.50
Copper	225	8.9	6.25
Brass	275	8.5	7.50
Magnesium	175	1.8	14.00
Titanium	700	4.5	40.00


# An Ashby plot –

is a scatter plot which displays classes of materials. Useful to

compare the ratio between different properties.













Table 5.5 Examples of Material Indices

Function, Objective, and Constraints	Index		
Tie, minimum weight, stiffness prescribed	<u>Ε</u> ρ		
Beam, minimum weight, stiffness prescribed	$\frac{E^{1/2}}{\rho}$		
Beam, minimum weight, strength prescribed	$\frac{\sigma_y^{2/3}}{\rho}$		
Beam, minimum cost, stiffness prescribed	$\frac{E^{1/2}}{C_m \rho}$		
Beam, minimum cost, strength prescribed	$\frac{\sigma_y^{2/3}}{C_m \rho}$		
Column, minimum cost, buckling load prescribed	$\frac{E^{1/2}}{C_m \rho}$		
Spring, minimum weight for given energy storage	$\frac{E^{1/2}}{C_m \rho}$ $\frac{\sigma_y^2}{E  \rho}$		
Thermal insulation, minimum cost, heat flux prescribed			
Electromagnet, maximum field, temperature rise prescribed	$\frac{1}{\lambda C_p \rho}$ $\frac{C_p \rho}{\rho_{\Theta}}$		
a - dansity; F - Vauna's modulus; alastic limit; C - aast/kg; 1 - thormal conductivity;			

ho = density; E = Young's modulus;  $\sigma_y =$  elastic limit;  $C_m =$  cost/kg;  $\lambda =$  thermal conductivity;  $\rho_e =$  electrical resistivity;  $C_p =$  specific heat








- (a) a tie, a tensile component;
- (b) a panel, loaded in bending;
- (c) and (d) beams, loaded in bending.


# Objective Function for Light-Strong Stiff Tie rod:

$$m = A L \rho \qquad \qquad \frac{F^*}{A} \leq \sigma_f$$
 
$$m \geq (F^*)(L) \left(\frac{\rho}{\sigma_f}\right) \longrightarrow \text{Material properties}$$
 Functional constraint 
$$\qquad \qquad \text{Geometric constraint}$$

Material Index:

$$M_{t1} = \frac{\sigma_f}{\rho}$$





## Table 5.2 Design Requirements for the Light, Strong Tie

Function Tie rod

Constraints Length L is specified (geometric constraint)

Tie must support axial tensile load  $F^*$  without failing

(functional constraint)

Objective Minimize the mass *m* of the tie

Free variables Cross-section area A

Choice of material