Table of Contents

Purpose/Policy:.....1

Scope:.....2

Definitions/Acronyms:.....2

Authorities/Responsibilities:.....2

Resources and Materials:.....2

PPE Required:.....3

Procedures:.....3

Starting Paktech Units - Preparation:.....3

Operation of the Paktech Units:.....3

Changeover Guide:.....4

Shutting Down the Paktech Units:.....5

Basic Cleaning of the Paktech Units:.....6

Deep Cleaning:.....6

Forms:.....6

Reference Documents:.....6

Common Issues:.....6

Document History and Approval:.....6

Purpose/Policy:

This “Paktech CCA120” standard operating procedure has been created to assist operators with setup, operations, changeover, cleaning, and troubleshooting.

Scope:

The “Paktech” requires “Can Carriers aka Paktech Rings”, air, control power, and line lube to run.

The purpose of the “Paktech” is to apply plastic “Can Carriers aka Paktech Rings” whether 4-cans or 6-cans to create one physical unit. The machine can be converted to run either 12oz or 16oz cans. The Can Line runs two Paktech units in unison to help achieve our efficiency output.

Definitions/Acronyms:

- SOP – Standard Operating Procedure
- PPE – Personal Protective Equipment
- E-Stop – Emergency Stop button
- Paktech – Machine that applies plastic can carriers (Paktech rings) to make 4 or 6 can units

Authorities/Responsibilities:

“This SOP can be completed by an entry level packaging operator after proper training from a senior member of the Can line packaging team. The objective of this SOP is to gain the knowledge needed to operate the “Paktech CCA120” and trouble shoot any issues that may arise.”

Resources and Materials:

Below you will find an example of how this should be completed. We want to include tools and resources used for operations, changeovers, basic cleaning, troubleshoot and links to deep cleaning guides.

Operations:

- Air.
- Paktech Rings.
- Line lube.

Changeovers:

- 12oz height setting blocks (reverse side of 16oz blocks).
- 16oz height setting blocks (reverse side of 12oz blocks).
- 2 – ½” wrenches.
- 1 – 7/16th wrench.

Basic Cleaning:

- Wet damp rag.
- Dry rag.
- Water spray hose.
- Air hose.

Deep Clean:

- Refer to SOP Document # CL###
    - Link to document goes here.

Troubleshooting:

- No Equipment required.

PPE Required:

- No formal PPE required, suggested nitrate gloves for cleaning.

Procedures:

Starting Paktech Units - Preparation:

1. Check the air pressure gauge for sufficient air pressure. 80psi or 6 Bar is the minimum required amount of pressure for the machine to operate at the correct manufacture's performance rating.
2. Turn the On/Off switch located on the Control Panel to the on position
3. Load the correct can carriers into the magazine ensuring that all are oriented the correct way for the proper application.
    3.1 *NOTE:* All Can Carriers will be outline in the packaging split. If you are running 4 Pak Can Carriers, ensure that the finger loop is pointed toward the outfeed side of the machine. If they are damaged or warped, they will not load or clip correctly.

Operation of the Paktech Units:

1. Check that the Application Carriage Cylinder is extended, and the carriage is in the load position.
2. Ensure you have the right size can carriers (Paktech rings) and the right size setting set on the CCA120.
3. Place the Jog/Run switch into "Jog "mode.
4. Place the Gate Open/Close switch in the "Close" position.
5. Place Grippers Open/Close in the "Open" position.

6. Place 2 cans against each Infeed Accumulation Gate to prime the “applicator”.
7. Place the Jog/Run switch in “Run”.
8. Push the green start button to start the conveyor and enable automatic operation.
9. When the sensors detect cans, the applicator will apply Can Carriers automatically.

Changeover Guide:

1. Changing from 12oz Cans to 16oz Cans
    - 1.1 Turn the machine power off.
    - 1.2 Use ½” wrench to loosen the two bolts on each of the machines four corners.
    - 1.3 Raise the unit via the adjustment wheels at the four corners of the machine. (black wheels on top). Raise up until the machine clears the height gauge blocks.
    - 1.4 There is 1 - 7/16” bolt attached to each of the height gauge blocks. These must be removed, and the blocks inverted. Once you invert the blocks, replace the bolt, and tighten down.
    - 1.5 Using the four adjustment wheels from step 1.3. Lower the applicator back down to rest firmly on the top of the height gauge blocks.
    - 1.6 Tighten down the ½” bolts or knobs from step 1.2.
2. Changing From 16oz Can to 12 oz Can.
    - 2.1 Follow steps listed above in section 1.1 – 1.6.
3. Changing between 4,6, and 8 Pak Can Carriers.
    - 3.1 Ensure power and air are turned off prior to changing.
    - 3.2 Open the top from doors (top of the machine)
    - 3.3 Reach into the machine and lift the spring-loaded detent knob to release the can stop assembly from the current position.
    - 3.4 Slide the can stop assembly to the required position for the next Pak Can Carrier size you are running then release knob. Ensure the pin is seated correctly and the assembly doesn’t move.
    - 3.5 When finished with adjustments, close the top and you are ready to run that specific Can Carrier size.

Paktech Troubleshooting Guide:

1. Handling Magazine Jams
    - 1.1 To clear a Can Carrier magazine jam, first stop the machine cycle by pressing the red off button.
    - 1.2 Check the magazine for warped or damaged Can Carriers and clear all Can Carriers from the magazine chute.
    - 1.3 Place the Run/Jog switch into “Jog”.

1.4 Use the Gripper Open/Close switch to turn the machine into Open and retract the grippers.
   1.4.1 *NOTE:* If there is too much back pressure from the line it may prevent these from opening. Clear cans from infeed area to relieve back pressure.
1.5 Use the Gate Open/Close Switch to Close (Extend) the gates.
1.6 Switch the In/Out switch to the “In” position to extend the Application Carriage to the Load position
1.7 Place the machine into Run mode by switching the Jog/Run switch into “Run”.
1.8 Press the Green start button to start the applicator in Auto.

2. Cans are damaged or burst during application.
   2.1 Check the application roller height.
   2.2 The roller will obstruct cans if the stop bolts are set to low. This will cause cans to tip and be punctured by the grippers.
   2.3 Check can gripper fit.
   2.4 The can grippers must hold the can securely. If they are not secure, this will cause damage when the applicator begins operation.
   2.5 Check the can hold-back gates for proper operation.
   2.6 The can-stop gates retract automatically as the application carriage moves forward.
   2.7 If the package does not move down the conveyor line after the grippers open, the Can-stop gates will extend and damage the cans.
   2.8 Ensure cans are moving freely on the conveyor after being released by grippers.
   2.9 Inspect for damage to Can-stop gates to ensure that they completely retract.
3. Can Carriers double feed.
   3.1 Check to see that Can Carrier index assemblies have no loose or missing parts.
   3.2 Check that guide bushings are not worn.
   3.3 Check the index shoes to ensure there is no sticking or binding.
   3.4 Check magazine feed mechanism and feed chute are clean and free of dirt and debris.
   3.5 Ensure Can Carriers are in good condition and not bent or disformed. Any that should be removed and documented.
   3.6 If can carriers are bent or damaged and need to be removed, 1st open ring stops (section the holds the can carriers in place) then remove can carriers. Do Not Forcefully Pull Them Out without doing this.

Shutting Down the Paktech Units:

1. Ensure all cans are cleared out of the unit.
2. Press the “red “stop button of the Paktech Unit.
3. Open the top doors.

4. Press the E-Stop on both units.

Basic Cleaning of the Paktech Units:

1. Clean the inside and outside using a hot damp rag or rinse out with a pump sprayer or carefully spray with hose.
    1.1 *NOTE:* Alpha 5 can be used to assist with cleaning by diluting 1/2oz-2oz per gallon of water for light soiled surface cleaning and 4-6oz per gallon of medium soiled surface cleaning. Spray down machine and wash off with pump sprayer or damp rag.
2. Wipe down all contact surfaces, ensuring all beer residue, dirt or debris is cleared.
3. Wipe down conveyor infeed and outfeed belts with a hot damp rag.
4. Dry machine with a dry rag.

Deep Cleaning:

1. Refer to SOP Document # CL###
    1.1 Link to document goes here.

Forms:

Not Applicable

Reference Documents:

Not Applicable

Common Issues:

Not Applicable

Document History and Approval:

Revise document history as described in the table and key below.

(Reference to following document: B1C.SOP.P001: Document Control and Approval Procedure Template)

VERSION NO.	VERSION DATE	DESCRIPTION OF CHANGE	AUTHOR NAME/PROJECT MANAGER
001	2024/03/25		Kyle Szymanski
002	2026/10/26	Updated SOP to Newest Layout Version	Kyle Szymanski

Version Approval Number: 002

Approved by: Kyle Szymanski

Position Title: OSCI Manager

Date: 10/26/26