Table of Contents

Purpose/Policy:.....1

Scope:.....2

Definitions/Acronyms:.....2

Authorities/Responsibilities:.....2

Resources and Materials:.....2

PPE Required:.....3

Procedures:.....3

Getting the dump keg ready to be dumped:.....3

Hooking up the dump keg:.....3

Dumping Kegs:.....4

Forms:.....5

Reference Documents:.....6

Common Issues:.....6

Document History and Approval:.....6

Purpose/Policy:

“This “Dump Keg Operations” standard operating procedure has been created to assist operators with setup, operations, changeover, cleaning, and troubleshooting.

Scope:

We use the “Dump Keg Operations” to dump any beer inside of a keg when the beer is out of code or when a keg has not been filled correctly by the MM’s.

Once a keg has been dumped, these kegs can be recleaned and used for production unless it has been determined the keg is damaged. “

Definitions/Acronyms:

- SOP – Standard Operating Procedure
- PPE – Personal Protective Equipment
- MM – Minomats
- Dump Keg – Station used to empty beer from kegs that are out of code or filled incorrectly

Authorities/Responsibilities:

“This SOP can be completed by an entry level packaging operator after proper training from a senior member of the Keg line packaging team. The objective of this SOP is to gain the knowledge needed to perform “Dump Keg Operations” and trouble shoot any issues that may arise.”

Resources and Materials:

Operations:

- Dump line.
- Air.
- Nitrile gloves.

Changeovers:

- N/A

Basic Cleaning:

- Trash Barrel for old keg caps or collars.

Troubleshooting:

- Inspection of dump kegs for leaking.
- Inspection of dump line for leaks.

PPE Required:

- Safety Glasses are required when dumping kegs.

Procedures:

Getting the dump keg ready to be dumped:

1. Whether dumping kegs from old stock or dumping kegs from issues with the filling unit/test kegs, bring them to the reject area of the keg line.

Figure 1: Keg in Dump Area



2. Ensure the dump line air is turned on.
   2.1 The air control is located on the side of the “Full Keg Elevator.”

Hooking up the dump keg:

1. Underneath the Rejector of the keg line (within the dump area) are two Sankey’s that can be used for dumping kegs. Each Sankey is attached to an air line and a dump line.
2. Attach the Sankey to the top of the keg and turn “clockwise” until it locks in place.

Figure2: Sankey hook up to dump keg.



3. Once the Sankey is locked in place, the dump procedure can begin.

Dumping Kegs:

1. Press down on the Sankey handle like in Figure 3.

Figure 3: Sankey engaged.



2. When the handle is locked in the down position, the air will push the beer out of the keg to the dump line. This line leads to the floor drain.

Figure 4: Dump line to drain.



3. Once all the beer has be dumped from the keg, release the handle and pull it up.

Figure 5: Lever back in up position.



4. Turn the Sankey “Counterclockwise” to unhook the Sankey.
5. The Dump operation has now been completed and can be continued as needed for any remaining kegs.
6. Once all kegs have been dumped, hang the dump lines back up underneath the rejector lane and turn the air off.

Forms:

Not Applicable

Reference Documents:

Not Applicable

Common Issues:

1. No liquid is draining from the kegs:
    1.1 Ensure the air is on.
    1.2 Unhook and inspect Sankey for any damage or loose parts.
2. Beer spraying when engaging Sankey.
    2.1 The Sankey has not been locked in place properly and needs to be reset.

Document History and Approval:

Revise document history as described in the table and key below.

(Reference to following document: B1C.SOP.P001: Document Control and Approval Procedure Template)

VERSION NO.	VERSION DATE	DESCRIPTION OF CHANGE	AUTHOR NAME/PROJECT MANAGER
001	2024/07/18		Kyle Szymanski
002	2026/10/26	Updated SOP to Newest Layout Version	Kyle Szymanski

Version Approval Number: 002

Approved by: Kyle Szymanski

Position Title: OSCI Manager

Date: 10/26/26