

Rectangular





	Dims	Options	Conn's
A=Width C=Length	B=Depth	Straight Type=1 Part Straight Female Allow=Shortest Side 1xU,1xl=Shortest Side Connector Fold Notch=Use Default Vee Notch Depth=Auto Vee Notch Angle=30.000 Maximum Sheet Size=None Maximum Fold Length=None Minimum Fold Length=None Oversize Check=Yes	C1=None C2=None
		Connector Fold Notch=Use Default Vee Notch Depth=Auto Vee Notch Angle=30.000 Beading=No Insulation Parts=Same Insulation UI=Shortest Side	Seams S1=None Damper:


Pattern: 2 Rectangular/Fabrication




Dims	Opt	ions	Conn's
A=Width In	2 Parts=No	Fixing Holes on Tur	C1=None
B=Depth In	3 Parts=No	Seam Cut Back=0.0	C2=None
C=Width Out	Vee Depth Male=A		
D=Depth Out	Vee Depth Female=		
E=Length	Vee Notch Angle=2		
F=Extension In	Taper Notch If Strai		
G=Extension Out	Female Allow=Shor		
H=Offset Width	2-Sided Part Allowa		
I=Offset Depth	Offset Width=Left In		
J=Angle	Offset Depth=Botto		
	Taper Notch If Strai		Seams
	Use Taper Notch F		S1=None
	Connector Fold Not		
	Vee Notch Depth=		
	Vee Notch Angle=3		
	Input=Length		Damper:
	Vee Notch Depth If		24pc
	Maximum Angle=1		
	Splitter Turnover=0		
	Splitter Extension=		
	Splitter Adjust=0.000		
	Connector Fold Not		
	Vee Notch Depth=		
	Vee Notch Angle=3		
	Splitter Hole Diame		
	Number Of Holes=		
	Splitters=Half		
	Hole Inset=0.000		

4/18/2016 courtesy of software 1

Rectangular







Dims	Options	Conn's
A=Top Width	Length Adjust For Part 4=0.000	C1=None
B=Depth	Length Adjust For Part 3=0.000	C2=None
C=Btm Width	Vee Depth Male=Auto	
D=Top Extension	Vee Depth Female=Auto	
E=Bottom Extension	Vee Angle Male=30	
	Vee Angle Female=30	
	3 Parts=No	
	Seam Number For Throat=	
	2 Part Wrapper=No	
	Attenuator=No	
	Leg Lengths=No	Seams
	Allow Central Tie Rods=Yes	S1=None
	Riser Bend=No	S2=None
	Insulation Parts=Same	

Damper:

Pattern: 4

Rectangular







Dims	Options	Conn's
A=Width	Throat Type=Radius	C1=None
B=Depth	Length Adjust For Part 4=0.000	C2=None
C=Angle	Length Adjust For Part 3=0.000	
D=Top Extension	Vee Depth Male=Auto	
E=Bottom Extension	Vee Depth Female=Auto	
F=Inner Radius	Vee Angle Male=30	
	Vee Angle Female=30	
	Auto Oversize=Normal	
	Seam Number For Throat=	
	Leg Lengths=No	
	Allow Central Tie Rods=Yes	Seams
	Riser Bend=No	S1=None
	Mark Splitter Sides=No	
	Insulation Parts=Same	

Damper:

Rectangular



Dims	Options	Conn's
A=Btm Width	Throat Type=Radius	C1=None
B=Depth	3 Parts=No	C2=None
C=Left Width	Vee Depth Male=Auto	C3=None
D=Right Width	Vee Depth Female=Auto	
E=Right Radius	Vee Notch Angle=30.000	
F=Left Radius	Hole Diameter=0.500	
G=Btm Right Extension	Hole Spacing=2.000	
H=Btm Left Extension	Splitters=No	
I=Right Extension	Inlet=1	
J=Left Extension	Outlet=2	
K=Splitter Distance	Insulation Parts=Same	Seams S1=None



Pattern: 6 Rectangular



Dims	Options	Conn's
A=Left Width	Vee Depth Male=Auto	C1=None
B=Depth	Vee Depth Female=Auto	C2=None
C=Right Width	Vee Notch Angle=30.000	
D=Length	Seam Cut Back=0.000	
E=Left Extension	Allow Central Tie Rods=No	
F=Right Extension	Insulation Parts=Same	
G=Offset Width	Split Mitre=No	
H=Angle		
I=Left Extension		
J=Right Extension		
K=Right Width		Seams
		S1=None

Damper: None None


Damper:

Rectangular





Dims	Options	Conn's
A=Top Width	Throat Type=Mitred	C1=None
B=Depth	2 Parts=Yes	C2=None
C=Height	Vee Depth Male=Auto	
D=Top Extension	Vee Depth Female=Auto	
E=Bottom Extension	Vee Notch Angle=30.000	
F=Btm Width	Connector Fold Notch=Use Default	
	Vee Notch Depth=Auto	
	Vee Notch Angle=30.000	
	Connector Fold Notch=Use Default	
	Vee Notch Depth=Auto	
	Vee Notch Angle=30.000	Seams
	Dynamic Hole Adjust=Auto	S1=None

Damper: None None



Pattern: 8 Rectangular/Round





Dims	Options	Conn's
A=Width	Cross Break=2	C1=None
B=Depth	Length Break=1	C2=None
C=Diameter	Diameter Type=Nominal	
D=Length	Seam Position=Width	
E=Offset Width	Marker Type=Notch	
F=Offset Depth	Input=Length	
G=Extension	Offset Width=Left In	
H=Collar	Offset Depth=Bottom Up	
I=Corner Radius	Inlet=1	
J=Slope Angle	Outlet=2	
	Maximum Angle=180.000	Seams
	Fold Notch Depth=Full Allowance	S1=None
	Hide Internal Lines=No	
	Show Center Line=No	
	V Notch Rectangular Extension=No	
	Seam Cut Back=None	Damper: None
	Cut Back Allowance (%)=50.000	bumper wone
	2 Parts 90 Degrees Seam=No	

Rectangular


Dims	Options	Conn's
A=Width In	Vee Depth Male=Auto	C1=None
B=Depth	Vee Depth Female=Auto	C2=None
C=Width Out	Vee Angle Male=30	
D=Length	Vee Angle Female=30	
E=Extension In	Offset Width=Left In	
F=Extension Out	Restricted Flow=Warning	
G=Offset Width	Seam Cut Back=0.000	
H=Radius Out	Wraps V Notch If Zero Radius=No	
I=Radius In		


Seams S1=None

Damper:

Pattern: 10

Rectangular





Dims	Options	Conn's
A=Btm Width	Right Throat Type=Radius	C1=None
B=Depth	Left Throat Type=Radius	C2=None
C=Top Width	Vee Depth Male=Auto	C3=None
D=Right Width	Vee Depth Female=Auto	C4=None
E=Left Width	Vee Angle Male=30	
F=Height	Vee Angle Female=30	
G=Right Height	Right Heel Type=Radius	
H=Left Height	Left Heel Type=Radius	
I=Right Radius	Junction Notch=Use Default	
J=Left Radius	Vee Notch Angle=20.000	
K=Right Angle	2 Part Wrapper=No	Seams
L=Left Angle	Top Right=Straight	S1=None
M=Btm Right Extension	Top Left=Straight	S2=None
N=Btm Left Extension	Outlet=2	
O=Right Extension	Insulation Parts=Same	
P=Left Extension		Damper:
Q=Top Extension		bumper.

Rectangular




Dims	Options	Conn's
A=Left Width	Vee Depth Male=Auto	C1=None
B=Depth	Vee Depth Female=Auto	C2=None
C=Right Width	Vee Notch Angle=20.000	
D=Length	Insulation Parts=Same	
E=Left Extension		
F=Right Extension		
G=Offset Width		


Seams

S1=None

Damper:

Pattern: 12





Seams S1=None

Damper:

4/18/2016 courtesy of software 6


Rectangular



Dims	Options	Conn's
A=Btm Width	3 Parts=No	C1=None
B=Depth	Vee Depth Male=Auto	C2=None
C=Left Width	Vee Depth Female=Auto	C3=None
D=Right Width	Vee Notch Angle=30.000	
E=Bottom Extension	Hole Diameter=0.500	
F=Right Extension	Hole Spacing=2.000	
G=Left Extension	Splitters=No	
H=Splitter Distance	Inlet=1	
	Outlet=2	
	Insulation Parts=Same	
		Seams

S1=None

Damper:




Pattern: 14

Rectangular




Dims	Options	Conn's
A=Btm Width	Right Throat Type=Radius	C1=None
B=Depth	Left Throat Type=Radius	C2=None
C=Right Width	Vee Depth Male=Auto	C3=None
D=Left Width	Vee Depth Female=Auto	
E=Height	Vee Angle Male=30	
F=Right Radius	Vee Angle Female=30	
G=Left Radius	Right Heel Type=Radius	
H=Right Angle	Left Heel Type=Radius	
I=Left Angle	2 Part Wrapper=No	
J=Btm Right Extension	Back Wrapper=Marker Notch	
K=Btm Left Extension	Outlet=2	Seams
L=Right Extension	Insulation Parts=Same	S1=None
M=Left Extension		S2=None

Damper:




Pattern: 15 Rectangular/Fabrication







Dims	Options	Conn's
A=Width	Branch Parts=1	C1=None
B=Depth	Plate Parts=1	C2=None
C=Length	Seam Position=Corner	
D=Angle	Hole Adjust=0.000	
E=Plate Width		
F=Plate Depth		
G=Offset Depth		
H=Offset Width		
I=Btm Width		
J=Plate Width Adjust		
K=Plate Depth Adjust		Seams
		S1=None
		S2=None

Damper:



Pattern: 17 Rectangular/Fabrication






Dims	Options	Conn's
A=Top Width	Throat Type=Radius	C1=None
B=Depth	Length Adjust For Part 4=0.000	C2=None
C=Btm Width	Length Adjust For Part 3=0.000	
D=Angle	Vee Depth Male=Auto	
E=Top Extension	Vee Depth Female=Auto	
F=Bottom Extension	Vee Angle Male=30	
G=Inner Radius	Vee Angle Female=30	
	Auto Oversize=Normal	
	Seam Number For Throat=	
	Leg Lengths=No	
	Allow Central Tie Rods=Yes	Seams
	Riser Bend=No	S1=None
	Mark Splitter Sides=No	
	Insulation Parts=Same	

Damper:


Rectangular




Dims	Options	Conn's
A=Btm Width	Right Throat Type=Radius	C1=None
B=Depth	Vee Depth Male=Auto	C2=None
C=Top Width	Vee Depth Female=Auto	C3=None
D=Right Width	Vee Angle Male=30	
E=Height	Vee Angle Female=30	
F=Right Height	Right Heel Type=Radius	
G=Right Radius	Junction Notch=Use Default	
H=Right Angle	2 Part Wrapper=No	
I=Bottom Extension	Top Right=Straight	
J=Right Extension	Outlet=2	
K=Top Extension	Insulation Parts=Same	Seams
•		S1=None
		S2=None

Pattern: 19

Rectangular







Dims	Options	Conn's
A=Width	Straight Type=1 Part Straight	C1=None
B=Depth	Notch Angle For Lid=45.000	C2=None
C=Length	Collar Allowance=0.000	
D=Hole Width #1	Lid Adjust=0.000	
E=Hole Depth #1	Diameter Type=Nominal	
F=Hole Radius #1	Hole Adjust=0.000	
G=Hole Inset #1	Notch Angle For Seam=Default	
H=Hole Offset #1	Position From=Centre	
I=Hole Collar #1		
J=Hole Rotation #1		
		Seams
		S1=None
		S2=None
		S3=None

Damper: None

Damper:

Rectangular







Dims	Options	Conn's
A=Top Width	Length Adjust For Part 4=0.000	C1=None
B=Depth	Length Adjust For Part 3=0.000	C2=None
C=Btm Width	Vee Depth Male=Auto	
D=Angle	Vee Depth Female=Auto	
E=Top Extension	Vee Angle Male=30	
F=Bottom Extension	Vee Angle Female=30	
	3 Parts=No	
	Seam Number For Throat=	
	Attenuator=No	
	Leg Lengths=No	
	Allow Central Tie Rods=Yes	Seams
	Riser Bend=No	S1=None
	Insulation Parts=Same	

Damper:

Pattern: 21

Rectangular






Dims	Options	Conn's
A=Width	Notch Angle For Lid=45.000	C1=None
B=Depth	Collar Allowance=0.000	C2=None
C=Length	Lid Adjust=0.000	C3=None
D=Hole Width #1	1 Part Straight=Yes	
E=Hole Depth #1	Diameter Type=Nominal	
F=Hole Radius #1	Hole Adjust=0.000	
G=Hole Inset #1	Vee Notch Angle=0.000	
H=Hole Offset #1		
I=Hole Collar #1		
J=Hole Rotation #1		
K=Hole Width #2		Seams
L=Hole Depth #2		S1=None
M=Hole Radius #2		S2=None
N=Hole Inset #2		S3=None
O=Hole Offset #2		S4=None
P=Hole Collar #2		Damper: None
Q=Hole Rotation #2		

Rectangular







Dims	Options	Conn's
A=Width	Throat Type=Radius	C1=None
B=Depth	Length Adjust For Part 4=0.000	C2=None
C=Angle	Length Adjust For Part 3=0.000	
D=Top Extension	Vee Depth Male=Auto	
E=Bottom Extension	Vee Depth Female=Auto	
F=Inner Radius	Vee Angle Male=30	
G=Outer Radius	Vee Angle Female=30	
	3 Parts=No	
	Auto Oversize=Normal	
	Seam Number For Throat=	
	Leg Lengths=No	Seams
	Allow Central Tie Rods=Yes	S1=None
	Riser Bend=No	
	Mark Splitter Sides=No	
	Insulation Parts=Same	

Damper:

Pattern: 23


Rectangular






Dims	Options	Conn's
A=Top Width	Throat Type=Radius	C1=None
B=Depth	Length Adjust For Part 4=0.000	C2=None
C=Btm Width	Length Adjust For Part 3=0.000	
D=Angle	Vee Depth Male=Auto	
E=Top Extension	Vee Depth Female=Auto	
F=Bottom Extension	Vee Angle Male=30	
G=Inner Radius	Vee Angle Female=30	
H=Outer Radius	3 Parts=No	
	Auto Oversize=Normal	
	Seam Number For Throat=	
	Leg Lengths=No	Seams
	Allow Central Tie Rods=Yes	S1=None
	Riser Bend=No	
	Mark Splitter Sides=No	
	Insulation Parts=Same	
		Damper:

Rectangular/Fabrication







Dims		Options	Conn's
A=Width C=Length	B=Depth	Straight Type=1 Part Straight Female Allow=Shortest Side 1xU,1xI=Shortest Side Connector Fold Notch=Use Default Vee Notch Depth=Auto Vee Notch Angle=30.000 Connector Fold Notch=Use Default Vee Notch Depth=Auto Vee Notch Angle=30.000	Conn's C1=None C2=None
		Beading=No Insulation UI=Shortest Side	Seams S1=None


Damper:

Pattern: 26

Rectangular









Dims	Options	Conn's
A=Width	Straight Type=1 Part Straight	C1=None
B=Depth	Notch Angle For Lid=45.000	C2=None
C=Length	Lid Adjust=0.000	C3=None
D=Hole Width #1	Diameter Type=Nominal	C4=None
E=Hole Depth #1	Hole Adjust=0.000	C5=None
F=Hole Radius #1	Straight=Yes	C6=None
G=Hole Inset #1		
H=Hole Offset #1		
I=Hole Collar #1		
J=Hole Rotation #1		
K=Hole Width #2		Seams
L=Hole Depth #2		S1=None S6=None
M=Hole Radius #2		S2=None S7=None
N=Hole Inset #2		S3=None
O=Hole Offset #2		S4=None
P=Hole Collar #2		S5=None Damper: None
Q=Hole Rotation #2		Bumperritone
R=Hole Width #3		
S=Hole Depth #3		
T=Hole Radius #3		
U=Hole Inset #3		
V=Hole Offset #3		
W=Hole Collar #3		
X=Hole Rotation #3		
Y=Hole Width #4		
Z=Hole Depth #4		
a=Hole Radius #4		
b=Hole Inset #4		

Rectangular






Dims	Options	Conn's
A=Width In	2 Parts=No	C1=None
B=Depth In	3 Parts=No	C1=None
C=Width Out	Vee Depth Male=Auto	CZ-NOHE
D=Depth Out	Vee Depth Female=Auto	
E=Length	•	
F=Extension In	Vee Notch Angle=20.000	
	Female Allow=Shortest Slope 2-Sided Part Allowance=Auto	
G=Extension Out		
H=Offset Width	Offset Width=Left In	
I=Offset Depth	Offset Depth=Bottom Up	
J=Angle	Connector Fold Notch=Use Default	Seams
	Vee Notch Depth=Auto	S1=None
	Vee Notch Angle=30.000	31-NOILE
	Input=Length	
	Vee Notch Depth If Straight Edge (Female)	
	Maximum Angle=180.000	
	Splitter Turnover=0.000	Damper:
	Splitter Extension=0.000	
	Splitter Adjust=0.000	
	Connector Fold Notch=Use Default	
	Vee Notch Depth=Auto	
	Vee Notch Angle=30.000	
	Splitter Hole Diameter=0.000	
	Number Of Holes=0.000	
	Splitters=Half	
	Hole Inset=0.000	
	Fixing Holes on Turnover=No	
	Seam Cut Back=0.000	

Pattern: 28 Rectangular/Round






Dims	Options	Conn's
A=Width	Cross Break=2	C1=None
B=Depth	Length Break=1	C2=None
C=Diameter	Diameter Type=Nominal	
D=Length	Seam Position=Width	
E=Rectangular Angle	Marker Type=Notch	
F=Offset Width	Offset Width=Left In	
G=Offset Depth	Offset Depth=Bottom Up	
H=Extension	Inlet=1	
I=Collar	Outlet=2	
J=Round Angle	Fold Notch Depth=Full Allowance	
K=Corner Radius	V Notch Rectangular Extension=No	Seams
	Seam Cut Back=None	S1=None
	Cut Back Allowance (%)=50.000	
	2 Parts 90 Degrees Seam=No	

Damper: None


4/18/2016 13

Rectangular/Round



		,
Dims	Options	Conn's
A=Width	Cross Break=2	C1=None
B=Depth	Length Break=1	C2=None
C=Diameter	Diameter Type=Nominal	
D=Length	Seam Position=Width	
E=Extension	Marker Type=Notch	
F=Collar	Input=Length	
G=Corner Radius	Offset Width=Left In	
H=Slope Angle	Offset Depth=Bottom Up	
	Inlet=1	
	Outlet=2	
	Maximum Angle=180.000	Seams
	Fold Notch Depth=Full Allowance	S1=None
	V Notch Rectangular Extension=No	
	Seam Cut Back=None	
	Cut Back Allowance (%)=50.000	
	2 Parts 90 Degrees Seam=No	Damper: None

Pattern: 30 Rectangular




A-WIUIII	vee Deptii Male-Auto	C1-NOILE
B=Depth	Vee Depth Female=Auto	C2=None
C=Length	Vee Notch Angle=30.000	
D=Left Extension	Input=Length	
E=Right Extension	Maximum Angle=180.000	
F=Offset Width	Seam Cut Back=0.000	
G=Angle	Insulation Parts=Same	
H=Left Extension	Split Mitre=No	
I=Right Extension	Inlet=1	
J=Right Width	Outlet=2	
		Seams
		S1=None
		Damper: None
		None

Options

Vee Depth Male=Auto

Conn's

C1=None




courtesy of Applied Software 4/18/2016 14

Dims

A=Width

Rectangular




Dims	Options	Conn's
A=Width	Collar Allowance=0.000	C1=None
B=Depth	Diameter Type=Nominal	C2=None
C=Length	Hole Adjust=0.000	
D=Hole Width #1	Position From=Centre	
E=Hole Depth #1	Use Vee Notch=No	
F=Hole Radius #1	Vee Notch Angle=0.000	
G=Hole Inset #1	Cost Supports=No	
H=Hole Offset #1		
I=Hole Collar #1		
J=Hole Rotation #1		
		Seams
		S1=None
		S2=None

Damper: None

Pattern: 32

Rectangular






Dims	Options	Conn's
A=Width	Straight Type=1 Part Straight	C1=None
B=Depth	Throat Type=Mitred	C2=None
C=Length	2 Part Branch=Yes	C3=None
D=Branch Width #1	Vee Depth Male=Auto	C4=None
E=Branch Depth #1	Vee Depth Female=Auto	C5=None
F=Height #1	Vee Notch Angle=30.000	C6=None
G=Extension #1	Female Allow=Shortest Side	C7=None
H=Inset #1	1xU,1xI=Shortest Side	C8=None
I=Offset #1	Connector Fold Notch=Use Default	
J=Branch Width #2	Vee Notch Depth=Auto	
K=Branch Depth #2	Vee Notch Angle=30.000	Seams
L=Height #2	Branch Connector Fold Notch=Use Default	S1=None
M=Extension #2	Vee Notch Depth=Auto	S2=None
N=Inset #2	Vee Notch Angle=30.000	S3=None
O=Offset #2	Hole Adjust=0.000	S4=None
P=Branch Width #3	Connector Fold Notch=Use Default	Damper:
Q=Branch Depth #3	Vee Notch Depth=Auto	bamper.
R=Height #3	Vee Notch Angle=30.000	
S=Extension #3		
T=Inset #3		
U=Offset #3		

Rectangular





Dims	Options	Conn's
A=Width	Straight Type=1 Part Straight	C1=None
B=Depth	Branch Diameter Type=Nominal	C2=None
C=Length	Branch Diameter Type=Nominal	C3=None
D=Branch Diameter #1	Branch Diameter Type=Nominal	C4=None
E=Height #1	Hole Adjust=0.000	C5=None
F=Extension #1	Branch Allowance To Pipe=0.000	
G=Inset #1	Female Allow=Shortest Side	
H=Offset #1	1xU,1xl=Shortest Side	
I=Branch Diameter #2	Branch Parts=1	
J=Height #2	Branch Seam Position=Default	
K=Extension #2	Branch Insets=From C1 To Branch Center	Seams
L=Inset #2		S1=None
M=Offset #2		S2=None
N=Branch Diameter #3		S3=None
O=Height #3		S4=None
P=Extension #3		Damper:
Q=Inset #3		Daniper.
R=Offset #3		






Pattern: 34 Rectangular/Round/Fabrication






Dims	Options	Conn's
A=Width	Cross Break=2	C1=None
B=Depth	Length Break=1	C2=None
C=Diameter	Diameter Type=Nominal	
D=Length	Seam Position=Corner	
E=Offset Width	Marker Type=Notch	
F=Offset Depth	Input=Length	
G=Extension	Offset Width=Left In	
H=Collar	Offset Depth=Bottom Up	
I=Corner Radius	Inlet=1	
J=Slope Angle	Outlet=2	
	Maximum Angle=180.000	Seams
	Fold Notch Depth=Full Allowance	S1=None
	V Notch Rectangular Extension=No	
	Seam Cut Back=None	
	Cut Back Allowance (%)=50.000	
	2 Parts 90 Degrees Seam=No	Damper: None


Rectangular





	Dims	Options	Conn's
A=Width C=Length	B=Depth	Straight Type=1 Part Straight Duct Length=(inch) Allow Multiple Straights=Yes Connector Fold Notch=Use Default Vee Notch Depth=Auto Vee Notch Angle=30.000 Maximum Sheet Size=None Allow Split Sides=No Maximum Fold Length=None Minimum Fold Length=None STD Straight=No Connector Fold Notch=Use Default Vee Notch Depth=Auto Vee Notch Angle=30.000 Beading=No Insulation Parts=Same Insulation UI=Shortest Side	C1=None C2=None Seams S1=None S2=None

Pattern: 36 Rectangular




Dims		Options	Conn's
A=Width C=Length	A=Width B=Depth Straight Type=1 Part Straight C=Length Female Allow=Shortest Side 1xU,1xl=Shortest Side Connector Fold Notch=Use Default		C1=None C2=None
		Vee Notch Depth=Auto Vee Notch Angle=30.000 Connector Fold Notch=Use Default Vee Notch Depth=Auto Vee Notch Angle=30.000 Beading=No Insulation Parts=Same Insulation UI=Shortest Side	Seams S1=None

Damper:

4/18/2016 17

Rectangular






Dims	Options	Conn's
A=Btm Width	Right Throat Type=Radius	C1=None
B=Btm Depth	Left Throat Type=Radius	C2=None
C=Right Width	Vee Depth Male=Auto	C3=None
D=Right Depth	Vee Depth Female=Auto	
E=Left Width	Vee Angle Male=30	
F=Left Depth	Vee Angle Female=30	
G=Right Offset	Junction Notch=Use Default	
H=Left Offset	Vee Notch Angle=20.000	
I=Height	2 Part Wrapper=No	
J=Right Radius	Right Folds=End Point	
K=Left Radius	Left Folds=End Point	Seams
L=Right Angle	Inlet=1	S1=None
M=Left Angle	Outlet=2	S2=None
N=Btm Right Extension		
O=Btm Left Extension		
P=Right Extension		Damper:
Q=Left Extension		bumper.

Pattern: 38 Rectangular

Dims		Options	Conn's
A=Width	B=Depth		C1=None
C=Length	D=Angle		C2=None
F=Flange			



Seams S1=None

Damper:

Rectangular




Dims	Options	Conn's
A=Width	Branch Parts=1	C1=None
B=Depth	Seam Position=Corner	C2=None
C=Length	Hole Adjust=0.000	
D=Angle		
E=Top Extension		
F=Bottom Extension		

Seams

S1=None

Damper:



Pattern: 85 Rectangular/Round




Dims		Options	Conn's
A=Width	B=Depth	Diameter Type=Nominal	C1=None
C=Diameter	D=Extension	Top Offset=0.000	C2=None
E=Collar			

Seams


S1=None

Damper:





Rectangular/Flat Oval




Dims	Options	Conn's		
A=Width	Cross Break=2	C1=None		
B=Depth	Diameter Type=Nominal	C2=None		
C=Oval Width	Marker Type=Notch			
D=Oval Depth	Offset Width=Left In			
E=Length	Offset Depth=Bottom Up			
F=Offset Width	Seam Position=Corner			
G=Offset Depth	Inlet=1			
H=Rect Extension	Outlet=2			
I=Collar	Same Seams On Each Part=No			

Seams


S1=None

Damper:



Pattern: 124

Rectangular






Seams

S1=None


Damper:


4/18/2016 20

Rectangular/Flat Oval



Dims	Options	Conn's
A=Width	Cross Break=2	C1=None
B=Depth	Diameter Type=Nominal	C2=None
C=Oval Width	Marker Type=Notch	
D=Oval Depth	Offset Width=Left In	
E=Length	Offset Depth=Bottom Up	
F=Offset Width	Seam Position=Corner	
G=Offset Depth	Collar Arcs - Lap=0.000	
H=Rect Extension	Collar Arcs - Allowance=0.000	
I=Oval Extension	Inlet=1	
J=Collar	Outlet=2	
	Same Seams On Each Part=No	Seams
Oval Half Collar=Yes		S1=None










Pattern: 137

Rectangular/Flat Oval




Dims	Options	Conn's		
A=Width	Cross Break=2	C1=None		
B=Depth	Diameter Type=Nominal C2=None			
C=Oval Width	Marker Type=Notch			
D=Oval Depth	D=Oval Depth Offset Width=Left In			
E=Length	Offset Depth=Bottom Up			
F=Offset Width	Seam Position=Depth			
G=Offset Depth	Inlet=1			
H=Rect Extension	Outlet=2			
I=Collar	Same Seams On Each Part=No			


Seams S1=None


Damper:

Damper:



Rectangular






Dims	Options	Conn's
A=Width	Throat Type=Mitred	C1=None
B=Depth	2 Parts=Yes	C2=None
C=Length	Vee Depth Male=Auto	C3=None
D=Branch Width #1	Vee Depth Female=Auto	
E=Height #1	Vee Notch Angle=30.000	
F=Extension #1	Connector Fold Notch=Use Default	
G=Inset #1	Vee Notch Depth=Auto	
	Vee Notch Angle=30.000	
	Hole Adjust=0.000	
	Connector Fold Notch=Use Default	
	Vee Notch Depth=Auto	Seams
	Vee Notch Angle=30.000	S1=None

Damper:

Pattern: 151 Rectangular



Dims	Options	Conn's
A=Width In	Folds=Out	C1=None
B=Depth In	Offset Width=Right In	C2=None
C=Width Out	Offset Depth=Bottom Up	
D=Depth Out	New Pattern=No	
E=Length		
F=Angle		
G=Extension In		
H=Extension Out		
I=Offset Width		
J=Offset Depth		
K=Twist Angle		Seams
		S1=None



Damper:

4/18/2016 22


Rectangular



Dims	Options	Conn's
A=Btm Width	Hole Length=4.000	C1=None
B=Btm Depth	Hole Width=2.000	C2=None
C=Top Width	X-Offset=0.000	
D=Top Depth	Y-Offset=2.000	
E=Height	Break=40.000	
F=Flange	Opposite Hole=No	
G=Turnover		
H=Flange		
I=Turnover		

Seams

Damper:



Pattern: 153

Rectangular




Dims	Options	Conn's
A=Btm Width	Hole Length=4.000	C1=None
B=Btm Depth	Hole Width=2.000	C2=None
C=Top Width	X-Offset=0.000	
D=Top Depth	Y-Offset=2.000	
E=Height	Break=40.000	
F=Turnover	Opposite Hole=No	
G=Turnover		
H=Base Width		
I=Base Depth		
J=Base Height		
K=Extension		Seams
L=Angle		

Damper:

Rectangular/Equipment






Seams

Damper:

Pattern: 185

Rectangular






Dims	Options	Conn's
A=Btm Width	Right Throat Type=Radius	C1=None
B=Btm Depth	Left Throat Type=Radius	C2=None
C=Top Width	Vee Depth Male=Auto	C3=None
D=Top Depth	Vee Depth Female=Auto	C4=None
E=Right Width	Vee Angle Male=30	
F=Right Depth	Vee Angle Female=30	
G=Left Width	Right Heel Type=Radius	
H=Left Depth	Left Heel Type=Radius	
I=Top Offset	Junction Notch=Use Default	
J=Right Offset	Vee Notch Angle=20.000	
K=Left Offset	Right Folds=End Point	Seams
L=Height	Left Folds=End Point	S1=None
M=Right Height	Inlet=1	
N=Left Height	Outlet=2	
O=Right Radius	Top Right=Straight	
P=Left Radius	Top Left=Straight	Damper:
Q=Right Angle		Bumpen
R=Left Angle		
S=Btm Right Extension		
T=Btm Left Extension		
U=Right Extension		
V=Left Extension		
W=Top Inset		
X=Top Extension		

4/18/2016 courtesy of software 24

Rectangular



Dims	Options	Conn's
A=Left Width	Six Parts Left Lap=None	C1=None
B=Right Width	Six Parts Right Lap=None	C2=None
C=Depth	Clip Holes=No	C3=None
D=Length	Alternate Weathering=No	
E=Angle F=Six Parts Left Height G=Six Parts Right Height	Ensure Center Closed=No	

Seams S1=None

S2=None

Damper:

	ı			1		
	l .				l .	
	l .				l .	
	l .				l .	
	l .				l .	
	l .				l .	
			1			
	I		1			

Pattern: 222

Rectangular

4/18/2016

	Dims	Options	Conn's
A=Width	B=Depth	Notch=	
		Use First For All=No	




Seams


Damper:



25

Rectangular







Dims	Options	Conn's
A=Top Width	Throat Type=Radius	C1=None
B=Depth	Length Adjust For Part 4=0.000	C2=None
C=Btm Width	Length Adjust For Part 3=0.000	
D=Angle	Vee Depth Male=Auto	
E=Top Inner Extension	Vee Depth Female=Auto	
F=Bottom Extension	Vee Angle Male=30	
G=Inner Radius	Vee Angle Female=30	
	Auto Oversize=Normal	
	Seam Number For Throat=	
	Leg Lengths=No	
	Allow Central Tie Rods=Yes	Seams
	Riser Bend=No	S1=None
	Mark Splitter Sides=No	

Damper:

Pattern: 251

Rectangular





Dims	Options	Conn's
A=Top Width	Throat Type=Radius	C1=None
B=Depth	Length Adjust For Part 4=0.000	C2=None
C=Btm Width	Length Adjust For Part 3=0.000	
D=Top Inner Extension	Vee Depth Male=Auto	
E=Bottom Extension	Vee Depth Female=Auto	
F=Inner Radius	Vee Angle Male=30	
	Vee Angle Female=30	
	3 Parts=No	
	Auto Oversize=Normal	
	Seam Number For Throat=	
	Leg Lengths=No	Seams
	Allow Central Tie Rods=Yes	S1=None
	Riser Bend=No	
	Mark Splitter Sides=No	

Damper:


4/18/2016 26

Rectangular




2.	o ::	
Dims	Options	Conn's
A=Width	Vee Depth Male=Auto	C1=None
B=Depth	Vee Depth Female=Auto	C2=None
C=Length	Vee Notch Angle=30.000	
D=Left Extension	Split Mitre=No	
E=Right Extension		
F=Offset Width		
G=Angle		
H=Left Extension		
I=Right Extension		
J=Right Width		
•		Seams
		S1=None

Damper: None None




Pattern: 253


Rectangular



Dims	Opt	ions	Conn's
A=Width In	2 Parts=No	Fixing Holes on Tur	
B=Depth In	3 Parts=No	Seam Cut Back=0.0	
C=Width Out	Vee Depth Male=A		
D=Depth Out	Vee Depth Female=		
E=Length	Vee Notch Angle=2		
F=Extension In	Taper Notch If Strai		
G=Extension Out	Female Allow=Shor		
H=Offset Width	2-Sided Part Allowa		
I=Offset Depth	Offset Width=Left		
J=Angle	Offset Depth=Top Up		
	Taper Notch If Strai		Seams
	Use Taper Notch F		S1=None
	Connector Fold Not		
	Vee Notch Depth=		
	Vee Notch Angle=3		
	Input=Length		Damper:
	Vee Notch Depth If		24po
	Maximum Angle=1		
	Splitter Turnover=0		
	Splitter Extension=		
	Splitter Adjust=0.000		
	Connector Fold Not		
	Vee Notch Depth=		
	Vee Notch Angle=3		
	Splitter Hole Diame		
	Number Of Holes=		
	Splitters=Half		
	Hole Inset=0.000		

Rectangular/Round







Dims	Options	Conn's
A=Width	Cross Break=2	C1=None
B=Depth	Length Break=1	C2=None
C=Diameter	Diameter Type=Nominal	
D=Length	Seam Position=Width	
E=Offset Width	Marker Type=Notch	
F=Offset Depth	Input=Length	
G=Extension	Offset Width=Left In	
H=Collar	Offset Depth=Bottom Up	
I=Corner Radius	Inlet=1	
J=Slope Angle	Outlet=2	
	Maximum Angle=180.000	Seams
	Fold Notch Depth=Full Allowance	S1=None
	V Notch Rectangular Extension=No	
	Seam Cut Back=None	
	Cut Back Allowance (%)=50.000	
	2 Parts 90 Degrees Seam=No	Damper: None

Pattern: 255

Rectangular




Dims	Options	Conn's
A=Btm Width	Throat Type=Radius	C1=None
B=Depth	3 Parts=No	C2=None
C=Left Width	Vee Depth Male=Auto	C3=None
D=Right Width	Vee Depth Female=Auto	
E=Right Radius	Vee Notch Angle=30.000	
F=Left Radius	Hole Diameter=0.500	
G=Bottom Extension	Hole Spacing=2.000	
H=Right Extension	Splitters=No	
I=Left Extension	Inlet=1	
J=Splitter Distance	Outlet=2	
		Seams
		S1=None



Damper:

Rectangular



Dims	Options	Conn's
A=Radius	Six Parts Left Lap=None	C1=None
B=Depth	Six Parts Right Lap=None	C2=None
C=Angle	Vee Depth Female=0.000	C3=None
D=Length	Vee Angle Female=30.000	
E=Front Hole Diameter	Allowance=Left	
F=Back Hole Diameter		
G=Six Parts Left Height		
H=Six Parts Right Height		

Seams S1=None

S2=None

Damper:

Pattern: 314


Rectangular




Dims	Options	Conn's
A=Radius	Six Parts Left Lap=None	C1=None
B=Angle	Six Parts Right Lap=None	C2=None
C=Length	Vee Depth Male=0.000	C3=None
D=Front Hole Diameter	Vee Angle Male=180.000	
E=Back Hole Diameter	Vee Depth Female=0.000	
F=Six Parts Left Height	Vee Angle Female=30.000	
G=Six Parts Right Height	Allowance=Left	


Seams S1=None S2=None

Damper:




Rectangular






Dims	Options	Conn's
A=Radius	Six Parts Left Lap=None	C1=None
B=Depth	Six Parts Right Lap=None	C2=None
C=Length	Clip Holes=No	C3=None
D=Angle	Vee Depth Male=0.000	
E=Hole Diameter	Vee Angle Male=180.000	
F=Hole Diameter	Vee Depth Female=0.000	
G=Six Parts Left Height	Vee Angle Female=30.000	
H=Six Parts Right Height	Alternate Weathering=No	
	Holes CAD Nodes=No	
	Ensure Center Closed=No	
		Seams
		S1=None
		S2=None

Pattern: 320 Rectangular






Dims	Options	Conn's
A=Btm Width	Throat Type=Radius	C1=None
B=Btm Depth	Vee Depth Male=Auto	C2=None
C=Top Depth	Vee Depth Female=Auto	
D=Angle	Vee Angle Male=30	
E=Top Extension	Vee Angle Female=30	
F=Bottom Extension	Allow Central Tie Rods=Yes	
G=Inner Radius	Splitter Slit Angle=10.000	
	Intersect Splitter Holes=No	


Seams S1=None

Damper:

Damper:

Rectangular





Dims	Options	Conn's
A=Width	Rotation=0.000	C1=None
B=Depth		C2=None
C=Height		C3=None
D=Base Height		C4=None
E=Base Angle		C5=None
F=Flange		C6=None
G=Turnover		
H=Turnover		
I=Straight		


Seams S1=None


Damper:

Pattern: 322










Dims	Options	Conn's
A=Width	X Pitch=Slope Angle	C1=None
B=Depth	Rotation=0.000	C2=None
C=Height		C3=None
D=Angle		C4=None
E=Base Height		C5=None
F=Base Angle		C6=None
G=Flange		
H=Turnover		
I=Turnover		

Seams S1=None

Damper:

Rectangular/Round





Dims	Options	Conn's
A=Width	Cross Break=2	C1=None
B=Depth	Length Break=1	C2=None
C=Diameter	Diameter Type=Nominal	
D=Offset Width	Seam Position=Width	
E=Offset Depth	Marker Type=Notch	
F=Extension	Offset Width=Left In	
G=Collar	Offset Depth=Bottom Up	
H=Round Angle	Inlet=1	
I=Twist Angle	Outlet=2	
J=Inner Radius	Fold Notch Depth=Full Allowance	
K=Corner Radius	V Notch Rectangular Extension=No	Seams
	Seam Cut Back=None	S1=None
	Cut Back Allowance (%)=50.000	
	2 Parts 90 Degrees Seam=No	

Damper: None

Pattern: 328


Rectangular



Dims	Options	Conn's
A=Btm Width	Vee Depth Male=Auto	C1=None
B=Btm Depth	Vee Depth Female=Auto	C2=None
C=Left Width	Vee Angle Male=30	C3=None
D=Right Width	Vee Angle Female=30	
E=Top Depth	Offset Depth=Bottom Up	
F=Height	Offset Width=Left In	
G=Offset		
H=Offset Width		
I=Offset Depth		
J=Bottom Extension		
K=Top Extension		Seams
L=Branch Height		S1=None
M=Left Mitre Length		S2=None
N=Right Mitre Length		

Damper:

Rectangular




Dims	Options	Conn's
A=Btm Width	Wrapper Length Adjust=0.000	C1=None
B=Btm Depth	Turnover Allowance=0.000	C2=None
C=Height	Vee Notch Angle=5.000	
D=Hole Width	Develop Parts=2	
E=Hole Length		
F=Offset		
G=Bottom Extension		
H=Hole Offset		

Seams

S1=None

Damper:



Pattern: 330

Rectangular




Dims	Options	Conn's
A=Width In	Vee Depth Male=Auto	C1=None
B=Depth In	Vee Depth Female=Auto	C2=None
C=Width Out	Vee Angle Male=30	
D=Depth Out	Vee Angle Female=30	
E=Length	Offset Width=Left In	
F=Extension In	Offset Depth=Top Down	
G=Extension Out	Restricted Flow=Warning	
H=Offset Width	Seam Cut Back=0.000	
I=Offset Depth	Allow Central Tie Rods=No	
J=Left Radius		
K=Right Radius		Seams
-		S1=None

Damper:

4/18/2016 33

Rectangular/Round







Dime	Outions	Cample
Dims A=Width	Options Diameter Type=Nominal	Conn's
	"	C2=None
B=Depth	Marker Type=Notch	CZ=NOTIE
C=Diameter		
D=Length		
E=Extension		
F=End Height		
G=Offset		
H=Collar		
I=Bottom Chamfer		
J=Back Chamfer		
J Back channer		Seams
		S1=None
		S2=None

Damper:


Pattern: 340
Rectangular





Dims	Options	Conn's
A=Width	Straight Type=1 Part Straight	C1=None
B=Depth	Hole Type=Right	C2=None
C=Length	Hole Type=Right	
D=Hole Inset #1	Hole Type=Right	
E=Hole Offset #1	Female Allow=Shortest Side	
F=Hole Length #1	1xU,1xl=Shortest Side	
G=Hole Width #1	Connector Fold Notch=Use Default	
H=Hole Radius #1	Vee Notch Depth=Auto	
I=Hole Inset #2	Vee Notch Angle=30.000	
J=Hole Offset #2	Connector Fold Notch=Use Default	
K=Hole Length #2	Vee Notch Depth=Auto	Seams
L=Hole Width #2	Vee Notch Angle=30.000	S1=None
M=Hole Radius #2	Beading=No	
N=Hole Inset #3	Insulation UI=Shortest Side	
O=Hole Offset #3		
P=Hole Length #3		Damper:
Q=Hole Width #3		bamper.
R=Hole Radius #3		

Rectangular




	_		
Dims	Opt	tions	Conn's
A=Width In	2 Parts=No	Fixing Holes on Tur	C1=None
B=Depth In	3 Parts=No	Seam Cut Back=0.0	C2=None
C=Width Out	Vee Depth Male=A		
D=Depth Out	Vee Depth Female=		
E=Length	Vee Notch Angle=2		
F=Extension In	Taper Notch If Strai		
G=Extension Out	Female Allow=Shor		
H=Offset Width	2-Sided Part Allowa		
I=Offset Depth	Offset Width=Left In		
J=Angle	Offset Depth=Botto		
	Taper Notch If Strai		Seams
	Use Taper Notch F		S1=None
	Connector Fold Not		
	Vee Notch Depth=		
	Vee Notch Angle=3		
	Input=Length		Damper:
	Vee Notch Depth If		Dampen
	Maximum Angle=1		
	Splitter Turnover=0		
	Splitter Extension=		
	Splitter Adjust=0.000		
	Connector Fold Not		
	Vee Notch Depth=		
	Vee Notch Angle=3		
	Splitter Hole Diame		
	Number Of Holes=		
	Splitters=Half		
	Hole Inset=0.000		

Pattern: 343

Rectangular





Dims	Options	Conn's
A=Btm Width	Turnover Allowance=0.000	C1=None
B=Btm Depth	Body Allowance=0.000	C2=None
C=Centre Width	Plate Allowance=0.000	
D=Centre Depth	Number Of Struts=0	
E=Top Width	4 Parts=No	
F=Top Depth		
G=Height		
H=Height		
I=Width		
J=Depth		
K=Width		Seams
L=Height		S1=None
M=Bottom Extension		S2=None
N=Top Extension		S3=None
O=Plate Depth		
		Damper:

Rectangular



Dims	Options	Conn's
A=Right Width	Six Parts Left Lap=None	C1=None
B=Depth	Six Parts Right Lap=None	C2=None
C=Length	Clip Holes=No	C3=None
D=Six Parts Left Height	Vee Depth Male=0.000	
E=Six Parts Right Height	Vee Angle Male=180.000	
	Vee Depth Female=0.000	
	Vee Angle Female=30.000	
	Alternate Weathering=No	
	Ensure Center Closed=No	

S1=None S2=None

Damper:

Pattern: 347

Rectangular





Dims	Options	Conn's
A=Right Width	Six Parts Left Lap=None	C1=None
B=Depth	Six Parts Right Lap=None	C2=None
C=Length	Clip Holes=No	C3=None
D=Six Parts Left Height	Vee Depth Male=0.000	
E=Six Parts Right Height	Vee Angle Male=180.000	
	Vee Depth Female=0.000	
	Vee Angle Female=30.000	
	Alternate Weathering=No	
	Ensure Center Closed=No	
		Seams

S1=None S2=None

Damper:

Rectangular






Dims	Options	Conn's
A=Radius	Six Parts Left Lap=None	C1=None
B=Height	Six Parts Right Lap=None	C2=None
C=Length	Clip Holes=No	C3=None
D=Six Parts Left Height	Vee Depth Male=0.000	
E=Six Parts Right Height	Vee Angle Male=180.000	
	Vee Depth Female=0.000	
	Vee Angle Female=30.000	
	Alternate Weathering=No	
	Ensure Center Closed=No	

Seams S1=None S2=None

Damper:

Pattern: 349

Rectangular





Dims	Options	Conn's
A=Radius	Six Parts Left Lap=None	C1=None
B=Length	Six Parts Right Lap=None	C2=None
C=Six Parts Left Height	Clip Holes=No	C3=None
D=Six Parts Right Height	Alternate Weathering=No	
	Ensure Center Closed=No	

Seams S1=None S2=None

Damper:

Rectangular






	Dims	Options	Conn's
A=Radius	B=Height	Six Parts Left Lap=None	C1=None
C=Length		Six Parts Right Lap=None	C2=None
		Clip Holes=No	C3=None
		Vee Depth Male=0.000	
		Vee Angle Male=180.000	
		Vee Depth Female=0.000	
		Vee Angle Female=30.000	
		Alternate Weathering=No	
		Ensure Center Closed=No	
			Seams


Damper:

S1=None S2=None

Pattern: 351

Rectangular







	Dims	Options	Conn's
A=Radius	B=Length	Six Parts Left Lap=None	C1=None
		Six Parts Right Lap=None	C2=None
		Clip Holes=No	C3=None
		Alternate Weathering=No	
		Ensure Center Closed=No	

Seams S1=None S2=None

Damper:

Rectangular





Dims	Options	Conn's
A=Radius	Six Parts Left Lap=None	C1=None
B=Height	Six Parts Right Lap=None	C2=None
C=Length	Clip Holes=No	C3=None
D=Six Parts Left Height	Vee Depth Male=0.000	
E=Six Parts Right Height	Vee Angle Male=180.000	
	Vee Depth Female=0.000	
	Vee Angle Female=30.000	
	Alternate Weathering=No	
	Ensure Center Closed=No	

Seams S1=None S2=None

Damper:

Pattern: 353 Rectangular




Dims	Options	Conn's
A=Radius	Six Parts Left Lap=None	C1=None
B=Length	Six Parts Right Lap=None	C2=None
C=Six Parts Left Height	Clip Holes=No	C3=None
D=Six Parts Right Height	Alternate Weathering=No	
	Ensure Center Closed=No	

Seams S1=None S2=None


Damper:

Rectangular



Dims	Options	Conn's
A=Top Width	Length Adjust For Part 4=0.000	C1=None
B=Depth	Length Adjust For Part 3=0.000	C2=None
C=Top Extension	Vee Depth Male=Auto	
D=Bottom Extension	Vee Depth Female=Auto	
	Vee Angle Male=30	
	Vee Angle Female=30	
	Seam Number For Throat=	
	Leg Lengths=No	
	Allow Central Tie Rods=Yes	
	Riser Bend=No	
	Folding Lines=No	Seams
	0	S1=None
		S2=None

Pattern: 366 Rectangular




Dims	Options	Conn's
A=Left Width	Vee Depth Male=Auto	C1=None
B=Depth	Vee Depth Female=Auto	C2=None
C=Right Width	Vee Notch Angle=20.000	
D=Length		
E=Left Extension		
F=Right Extension		
G=Offset Width		
H=Top Radius		
I=Left Radius		
J=Bottom Radius		
K=Right Radius		Seams
		S1=None

Damper:

Damper:


Rectangular



Dims	Options	Conn's
A=Width In	Vee Depth Male=Auto	C1=None
B=Depth In	Vee Depth Female=Auto	C2=None
C=Width Out	Vee Angle Male=30	
D=Depth Out	Vee Angle Female=30	
E=Length	Offset Width=Left In	
F=Extension In	Offset Depth=Top Down	
G=Extension Out	Restricted Flow=Warning	
H=Offset Width	•	
I=Offset Depth		
J=Corner Radius		
		Seams
		C4 No.


S1=None

Damper:



Pattern: 368


Rectangular




Dims	Options	Conn's
A=Radius	Six Parts Left Lap=None	C1=None
B=Left Height	Connector=Left	
C=Length	Vee Depth Female=0.000	
D=Six Parts Left Height	Vee Angle Female=30.000	
E=Right Height	Alternate Weathering=No	
	Clip Holes=No	

Seams S1=None

Damper:



Rectangular



D	ims	Options	Conn's
A=Width	B=Flat Left	Six Parts Left Lap=None	C1=None
C=Flat Right	D=Depth	Six Parts Right Lap=None	
E=Length		Parts=2	


Seams

S1=None S2=None

Damper:

Pattern: 382


Rectangular



Dims	Options	Conn's
A=Width	Notch Angle For Lid=45.000	C1=None
B=Depth	Collar Allowance=0.000	C2=None
C=Length	Diameter Type=Nominal	
D=Hole Width #1	Hole Adjust=0.000	
E=Hole Depth #1	Hole Type=Front	
F=Hole Radius #1	Vee Notch Angle=Default	
G=Hole Inset #1	Swap Hole Dims For Side=No	
H=Hole Offset #1	Cost Supports=No	
I=Hole Collar #1		
J=Hole Rotation #1		
		Seams
		S1=None
		S2=None

Damper: None

Rectangular



Dims	Ontions	Conn's
DIIIIS	Options	COIIIIS
A=Left Width	Six Parts Left Lap=None	C1=None
B=Right Width	Six Parts Right Lap=None	
C=Depth	Parts=2	
D=Length		
E=Bottom Radius		
F=Top Radius		
G=Cross Break		

Seams S1=None S2=None

Damper:

Pattern: 397


Rectangular



Dims	Options	Conn's
A=Radius	Six Parts Left Lap=None	C1=None
B=Left Height	Connector=Left	
C=Length	Vee Depth Female=0.000	
D=Left Angle	Vee Angle Female=30.000	
E=Six Parts Left Height	Alternate Weathering=No	
F=Right Angle	Clip Holes=No	
G=Right Height	Split Radius Parts=No	


Seams S1=None

Damper:



4/18/2016 courtesy of Applied software 43


Rectangular



B=Btm Depth	Vee Depth Male=Auto	C2=None
C=Top Width	Vee Depth Female=Auto	
D=Top Depth	Vee Angle Male=30	
E=Angle	Vee Angle Female=30	
F=Top Extension	Offset=Top Down	
G=Bottom Extension	Bending=Left	
H=Inner Radius	Allow Central Tie Rods=Yes	
I=Offset	Splitter Slit Angle=10.000	
	Intersect Splitter Holes=No	
	·	Seams
		S1=None

Throat Type=Radius

A=Btm Width



Pattern: 401 Rectangular

	Dims		Options	Conn's
A=a	B=b	C=e	Vee Notch Angle=90	C1=None
			Duct Adjust=0.000	
			Minimum Part Area=0.000	



Seams

Damper:

C1=None

Damper:

courtesy of 4/18/2016 44

Rectangular






	Dime		Outions	Cample
	Dims		Options	Conn's
A=a	B=b	C=l	Straight Type=1 Part Straight Female Allow=Shortest Side	C1=None C2=None
			1xU,1xl=Shortest Side	
			Connector Fold Notch=Use Default	
			Vee Notch Depth=Auto	
			Vee Notch Angle=30.000	
			Connector Fold Notch=Use Default	
			Vee Notch Depth=Auto	
			Vee Notch Angle=30.000	
			Beading=No	
			Insulation UI=Shortest Side	Seams
				S1=None

Damper:


Pattern: 411 Rectangular



A=a R=h C=l Straight Type=1 Part Straight C1=None	Dims		Options	Conn's
Female Allow=Shortest Side C2=None 1xU,1xl=Shortest Side C2=N	A=a B=b	C=I	Straight Type=1 Part Straight Female Allow=Shortest Side 1xU,1xl=Shortest Side Connector Fold Notch=Use Default Vee Notch Depth=Auto Vee Notch Angle=30.000 Connector Fold Notch=Use Default Vee Notch Depth=Auto Vee Notch Depth=Auto Vee Notch Angle=30.000 Beading=No	C1=None C2=None Seams

Damper:

Rectangular






Dim	5	Options	Conn's
A=a B=b C=l	D=e E=f	Straight Type=1 Part Straight	C1=None
F=a G=b		Female Allow=Shortest Side 1xU,1xl=Shortest Side	C2=None
		Connector Fold Notch=Use Default Vee Notch Depth=Auto	
		Vee Notch Angle=30.000 Duct Adjust=0.000	
		Connector Fold Notch=Use Default Vee Notch Depth=Auto	
		Vee Notch Angle=30.000	Seams
		Beading=No Insulation UI=Shortest Side	S1=None

Damper:

Pattern: 415 Rectangular




	Dims	5		Options	Conn's
A=a B=	b C=c	D=d	E=e	1 Part Straight=Yes	C1=None
F=f G=	:				C2=None

Seams

S1=None


Damper:

Rectangular





	D	ims		Options	Conn's
a	B=d	C=b	D=I	Options Throat Type=Mitred 2 Parts=Yes Vee Depth Male=Auto Vee Depth Female=Auto Vee Notch Angle=30.000 Connector Fold Notch=Use Default Vee Notch Depth=Auto Vee Notch Angle=30.000 Connector Fold Notch=Use Default Vee Notch Angle=30.000 Connector Fold Notch=Use Default Vee Notch Depth=Auto Vee Notch Angle=30.000	Conn's C1=None C2=None Seams
				Dynamic Hole Adjust=Auto	S1=None

Damper: None None



Pattern: 420 Rectangular






		Dims	;		Options	Conn's
A=a F=I	B=b	C=e	D=f	E=r	Throat Type=Radius Length Adjust For Part 4=0.000 Length Adjust For Part 3=0.000 Vee Depth Male=Auto Vee Depth Female=Auto Vee Angle Male=30 Vee Angle Female=30 Auto Oversize=Normal Seam Number For Throat= 2 Part Wrapper=No Leg Lengths=No Allow Central Tie Rods=Yes Riser Bend=No Mark Splitter Sides=No	C1=None C2=None Seams S1=None S2=None

Damper:

4/18/2016 47

Rectangular




Dims	Options	Conn's
B=b C=d D=e E=f G=l	Throat Type=Radius Length Adjust For Part 4=0.000 Length Adjust For Part 3=0.000 Vee Depth Male=Auto Vee Depth Female=Auto Vee Angle Male=30 Vee Angle Female=30 Auto Oversize=Normal Seam Number For Throat= 2 Part Wrapper=No Leg Lengths=No Allow Central Tie Rods=Yes Riser Bend=No Mark Splitter Sides=No	C1=None C2=None Seams S1=None S2=None

Damper:

Pattern: 430

Rectangular



	D: .			0 ::	
B=b	Dims C=e	D=f	E=r	Options Throat Type=Radius Length Adjust For Part 4=0.000 Length Adjust For Part 3=0.000 Vee Depth Male=Auto Vee Depth Female=Auto Vee Angle Male=30 Vee Angle Female=30 3 Parts=No Auto Oversize=Normal Seam Number For Throat= 2 Part Wrapper=No	Conn's C1=None C2=None
				Leg Lengths=No Allow Central Tie Rods=Yes Riser Bend=No Mark Splitter Sides=No	S1=None S2=None
					Damper:


4/18/2016 courtesy of Applied software. 48


F=r

A=a

F=l

Rectangular






		Dims			Options	Conn's
A=a	B=b	C=d	D=e	E=f	Throat Type=Radius	C1=None
F=r	G=l				Length Adjust For Part 4=0.000	C2=None
					Length Adjust For Part 3=0.000	
					Vee Depth Male=Auto	
					Vee Depth Female=Auto	
					Vee Angle Male=30	
					Vee Angle Female=30	
					3 Parts=No	
					Auto Oversize=Normal	
					Seam Number For Throat=	
					2 Part Wrapper=No	Seams
					Leg Lengths=No	S1=None
					Allow Central Tie Rods=Yes	S2=None
					Riser Bend=No	
					Mark Splitter Sides=No	
					•	

Damper:

Pattern: 440
Rectangular






	Dims	Options	Conn's
A=a	B=b	2 Parts=No	C1=None
C=c	D=d	3 Parts=No	C2=None
E=h	F=m	Vee Depth Male=Auto	
G=l	H=Angle	Vee Depth Female=Auto	
		Vee Notch Angle=20.000	
		Taper Notch If Straight Edge (Female)=No	
		Female Allow=Shortest Slope	
		2-Sided Part Allowance=Auto	
		Taper Notch If Straight Edge (Male)=No	
		Use Taper Notch For 2 Parts=Yes	
		Connector Fold Notch=Use Default	Seams
		Vee Notch Depth=Auto	S1=None
		Vee Notch Angle=30.000	
		Input=Length	
		Vee Notch Depth If Straight Edge (Female)	
		Maximum Angle=180.000	Damper:
		Splitter Turnover=0.000	Damper.
		Splitter Extension=0.000	
		Splitter Adjust=0.000	
		Connector Fold Notch=Use Default	
		Vee Notch Depth=Auto	
		Vee Notch Angle=30.000	
		Splitter Hole Diameter=0.000	
		Number Of Holes=0.000	
		Splitters=Half	
		Hole Inset=0.000	
		Fixing Holes on Turnover=No	
		Seam Cut Back=0.000	


4/18/2016 courtesy of Applied software 49

Rectangular



	Dims	Options	Conn's
A=a	B=b	2 Parts=No	C1=None
C=c	D=d	3 Parts=No	C2=None
E=e	F=f	Vee Depth Male=Auto	
G=h	H=m	Vee Depth Female=Auto	
I=I	J=Angle	Vee Notch Angle=20.000	
		Taper Notch If Straight Edge (Female)=No	
		Female Allow=Shortest Slope	
		2-Sided Part Allowance=Auto	
		Taper Notch If Straight Edge (Male)=No	
		Use Taper Notch For 2 Parts=Yes	
		Connector Fold Notch=Use Default	Seams
		Vee Notch Depth=Auto	S1=None
		Vee Notch Angle=30.000	
		Input=Length	
		Vee Notch Depth If Straight Edge (Female)	
		Maximum Angle=180.000	Damper:
		Splitter Turnover=0.000	bumper.
		Splitter Extension=0.000	
		Splitter Adjust=0.000	
		Connector Fold Notch=Use Default	
		Vee Notch Depth=Auto	
		Vee Notch Angle=30.000	
		Splitter Hole Diameter=0.000	
		Number Of Holes=0.000	
		Splitters=Half	
		Hole Inset=0.000	
		Fixing Holes on Turnover=No	
		Seam Cut Back=0.000	

Pattern: 450
Rectangular/Round





Dims	Options	Conn's
A=a	Cross Break=2	C1=None
B=b	Length Break=1	C2=None
C=d	Diameter Type=Nominal	
D=h	Seam Position=Width	
E=m	Marker Type=Notch	
F=l	Offset Width=Left In	
G=Corner Radius	Offset Depth=Bottom Up	
	Inlet=1	
	Outlet=2	
	Fold Notch Depth=Full Allowance	
	V Notch Rectangular Extension=No	Seams
	Seam Cut Back=None	S1=None
	Cut Back Allowance (%)=50.000	
	2 Parts 90 Degrees Seam=No	

Damper: None

4/18/2016 50

Rectangular/Round





Dims	Options	Conn's
A=a	Cross Break=2	C1=None
B=b	Length Break=1	C2=None
C=d	Diameter Type=Nominal	
D=e	Seam Position=Width	
E=f	Marker Type=Notch	
F=h	Offset Width=Left In	
G=m	Offset Depth=Bottom Up	
H=l	Inlet=1	
I=Corner Radius	Outlet=2	
	Fold Notch Depth=Full Allowance	
	V Notch Rectangular Extension=No	Seams
	Seam Cut Back=None	S1=None
	Cut Back Allowance (%)=50.000	
	2 Parts 90 Degrees Seam=No	

Damper: None

Pattern: 460

Rectangular



Dims	Options	Conn's
A=a	Vee Depth Male=Auto	C1=None
B=b	Vee Depth Female=Auto	C2=None
C=e	Vee Notch Angle=30.000	
D=h	Offset=Bottom Up	
E=m	Split Mitre=No	
F=l		
G=Angle		
H=Left Extension		
I=Right Extension		
J=Right Width		
		Seams
		S1=None

Damper: None None


Rectangular

Dims	Options	Conn's
A=a	Vee Depth Male=Auto	C1=None
B=b	Vee Depth Female=Auto	C2=None
C=d	Vee Notch Angle=30.000	
D=e	Offset=Bottom Up	
E=h	Split Mitre=No	
F=m		
G=l		
H=Angle		
I=Left Extension		
J=Right Extension		
K=Right Width		Seams
		S1=None


Damper: None None

Pattern: 470

Rectangular




Dims	Options	Conn's
A=a	Throat Type=Radius	C1=None
B=b	3 Parts=No	C2=None
C=d	Vee Depth Male=Auto	C3=None
D=h	Vee Depth Female=Auto	
E=i	Vee Notch Angle=30.000	
F=j	Hole Diameter=0.500	
G=p	Hole Spacing=2.000	
H=q	Splitters=No	
l=r	Inlet=1	
J=Splitter Distance	Outlet=2	Seams
		S1=None




Damper:

Rectangular



Dims	Options	Conn's
A=a	Throat Type=Radius	C1=None
B=b	3 Parts=No	C2=None
C=d	Vee Depth Male=Auto	C3=None
D=e	Vee Depth Female=Auto	
E=h	Vee Notch Angle=30.000	
F=i	Hole Diameter=0.500	
G=j	Hole Spacing=2.000	
H=p	Splitters=No	
I=q	Inlet=1	
J=r	Outlet=2	
K=Splitter Distance		Seams
•		S1=None



Pattern: 472

Rectangular




Dims	Options	Conn's
A=Left Width	Vee Depth Male=Auto	C1=None
B=Depth	Vee Depth Female=Auto	C2=None
C=Right Width	Vee Notch Angle=30.000	
D=Centre Length	Length Includes Extensions=No	
E=Left Extension	Centre Width=No	
F=Right Extension		
G=Offset		
H=Angle		
=Total Length		

Damper:

S1=None

Damper:




Rectangular



Dims	Options	Conn's
A=a	Vee Depth Male=Auto	C1=None
B=b	Vee Depth Female=Auto	C2=None
C=d	Vee Angle Male=30	C3=None
D=e	Vee Angle Female=30	
E=h	Offset Depth=Bottom Up	
F=i	Offset Width=Left Out	
G=j		
H=I		
I=m		
J=Branch Height		
· ·		Seams

S1=None S2=None

Damper:



Pattern: 501 Rectangular/Equipment



	Dims	Options	Conn's
A=Width	B=Depth	Install Type=Plain	C1=None
C=Length	D=Inset	Control Type=None	C2=None
E=Sides	F=Top	Type=Single	
		Temperature Type=None	
		Draw Type=None	
		Lines=No	
		Cost Supports=No	
		Lines Type=Quantity	
		Lines=3.000	

Damper:

Seams

Rectangular/Equipment



	Dims	Options	Conn's
A=Width	B=Depth	Install Type=Plain	C1=None
C=Length	D=Inset	Control Type=None	C2=None
E=Sides	F=Top	Type=Single	
G=Bottom		Temperature Type=None	
		Draw Type=None	
		Lines=No	
		Connector 1 Outside=No	
		Connector 2 Outside=No	
		Cost Supports=No	
		Lines Type=Quantity	
		Lines=3.000	Seams

Damper:

Pattern: 503 Rectangular/Equipment



Dims	Options	Conn's
A=Width	Position From=Edge	C1=None
B=Depth	Lines=3	C2=None
C=Height	Rotation=0.000	
D=Plate Border (Width)	Arrows/Lines=None	
E=Plate Border (Depth)	Arrows/Lines Sides=0	
	Lines/Circles Spacing=1.000	
	Arrows Direction=Auto	
	Circles=No	
	Arrows Type=1	

Seams

Damper:

Rectangular



Dims	Options	Conn's
A=Width	Number Of Locks=0	C1=None
B=Depth	Area Of Influence X=0.000	C2=None
C=Turnover	Area Of Influence Y=0.000	
D=Corner Radius	Area Of Influence Z=0.000	
E=Inner Diameter	Mirror=No	
F=Outer Diameter	Dynamic Hole Adjust=Auto	
G=Depth #1		
H=Depth #2		
I=Inset		

Seams

Damper:

Pattern: 505 Rectangular/Equipment



Dims	Options	Conn's
A=Width	Type=Supply	C1=None
B=Depth	Position From=Edge	C2=None
C=Height	Lines=3	
D=Plate Border (Width)	Rotation=0.000	
E=Plate Border (Depth)	Arrows/Lines=None	
	Arrows/Lines Sides=0	
	Lines/Circles Spacing=1.000	
	Arrows Direction=Auto	
	Circles=No	
	Arrows Type=1	
	Cost Supports=No	Seams

Damper:


Rectangular/Equipment



]	Dims	Options	Conn's
A=Width	B=Depth	Install Type=Plain	C1=None
C=Length	D=Inset	Control Type=None	
E=Sides	F=Top	Type=Single	
G=Bottom		Temperature Type=None	
		Draw Type=None	
		Lines=No	
		Connector 1 Outside=No	
		Connector 2 Outside=No	
		Cost Supports=No	
		Lines Type=Quantity	
		Lines=3.000	Seams

Damper:

Pattern: 507 Rectangular/Equipment



Dims	Options	Conn's
A=Width	Type=Plain	C1=None
B=Depth	Type=Single	C2=None
C=Length	Type=Multiple Banks	
D=Damper Angle	X-Offset=0.000	
	Y-Offset=0.000	
	Develop=No	

Seams

Damper:

Rectangular/Equipment



Dims	Options	Conn's
A=Width	Type=Plain	C1=None
B=Depth	Type=Single	C2=None
C=Length	Type=Multiple Banks	
D=Damper Angle	X-Offset=0.000	
	Y-Offset=0.000	
	Develop=No	

Seams

Damper:

Pattern: 515 Rectangular/Equipment




Dims	Options	Conn's
A=Width	Type=Plain	C1=None
B=Depth	Type=Single	
C=Length	Type=Multiple Banks	
D=Damper Angle	X-Offset=0.000	
	Y-Offset=0.000	
	Develop=No	

Seams

Damper:

Rectangular/Equipment



	Dims	Options	Conn's
A=Width	B=Depth	Type=Heater	C1=None
C=Length		Chevron=0	C2=None
		Develop=No	

Seams

Damper:

Pattern: 519 Rectangular/Equipment




	Dims	Options	Conn's
A=Width	B=Depth	Draw Type=Attenuator	C1=None
C=Length		Develop=No	C2=None
		Lines Type=Quantity	
		Lines=3.000	

Seams

Damper:

Rectangular/Standard/Equipment



	Dims	Options	Conn's
A=Width	B=Depth	Inlet=1	
C=Length		Outlet=1	
		Library=Duct	
		Type=None	
		Cost Supports=No	

Seams

Damper:


Pattern: 525

Rectangular



Dims	Options	Conn's
A=Width In	Folds=Out	C1=None
B=Depth In	Offset Width=Right In	C2=None
C=Width Out	New Pattern=No	
D=Depth Out		
E=Length		
F=Angle		
G=Extension In		
H=Extension Out		
I=Offset Width		
		Seams
		S1=None

Damper:









courtesy of 4/18/2016 60

Rectangular





Dims	Options	Conn's
A=Top Width	Throat Type=Radius	C1=None
B=Depth	Length Adjust For Part 4=0.000	C2=None
C=Btm Width	Length Adjust For Part 3=0.000	
D=Top Inner Extension	Vee Depth Male=Auto	
E=Bottom Inner Extension	Vee Depth Female=Auto	
F=Inner Radius	Vee Angle Male=30	
G=Top Outer Extension	Vee Angle Female=30	
H=Bottom Outer Extension	Auto Oversize=Normal	
	Seam Number For Throat=	
	Leg Lengths=No	
	Allow Central Tie Rods=Yes	Seams
	Riser Bend=No	S1=None
	Folding Lines=No	S2=None

Damper:

Pattern: 535
Rectangular/Equipment



	Dims	Options	Conn's
A=Width	B=Depth	Draw Type=None	C1=None
C=Length		Develop=No	C2=None
		Lines Type=Quantity	
		Lines=3.000	

Seams

Damper:

4/18/2016 courtesy of Applied software 61


Rectangular

	ims	Options	Conn's
A=Width	B=Depth	Branch Parts=1	C1=None
C=Length #1	D=Angle	Input=Both Lengths	C2=None
E=Length #2	F=Width		




Seams S1=None


Damper:



Pattern: 761


Rectangular






Dims	Options	Conn's
A=Top Width	Throat Type=Radius	C1=None
B=Depth	Length Adjust For Part 4=0.000	C2=None
C=Btm Width	Length Adjust For Part 3=0.000	
D=Angle	Vee Depth Male=Auto	
E=Top Inner Extension	Vee Depth Female=Auto	
F=Bottom Extension	Vee Angle Male=30	
G=Inner Radius	Vee Angle Female=30	
H=Outer Radius	3 Parts=No	
I=Top Outer Extension	Auto Oversize=Normal	
	Seam Number For Throat=	
	2 Part Wrapper=No	Seams
	Leg Lengths=No	S1=None
	Allow Central Tie Rods=Yes	S2=None
	Riser Bend=No	
	Mark Splitter Sides=No	
		Damper:

Rectangular



	Dims		Options	Conn's
A=a B=b	C=c	D=d	Hole=Top	C1=None
E=e F=f	G=g	H=h	Hole=Top	C2=None
l=i J=J:	1 K=J2	L=J3	Hole=Top	
M=K1 N=	K2 O=K3	P=l	Number of Holes - Side A=8	
Q=p R=r	•		Number of Holes - Side L=4	
			Number of Holes - Side L=3	
			Number of Holes - Side L=3	
			Hole Diameter=0.400	
			Hole Inset=Auto	
			Vee Notch Depth=0.100	
			Vee Notch Angle=30.000	Seams
			2 Parts=No	
			Door Size Reduction=0.000	
			Holes Draw Detail=Auto	
			Add CAD Nodes=No	












Pattern: 765


Rectangular



	Dims	Options	Conn's
A=b	B=g	Corners=No	
C=h	D=Angle	Sides=Angle	
E=o	F=p	x=0.200	
G=r	H=s	y=0.400	
l=t		z=0.800	
		v=0.800	
		u=0.080	
		w=0.080	
		e=0.080	
		f=0.080	
		i=0.000	Seams
		j=0.000	

Damper:


Damper:






4/18/2016 courtesy of software 63


Rectangular





Dims	Options	Conn's
A=Btm Width	Right Throat Type=Radius	C1=None
B=Depth	Left Throat Type=Radius	C2=None
C=Top Width	Vee Depth Male=Auto	C3=None
D=Right Width	Vee Depth Female=Auto	C4=None
E=Left Width	Vee Angle Male=30	
F=Height	Vee Angle Female=30	
G=Right Height	Right Heel Type=Radius	
H=Left Height	Left Heel Type=Radius	
I=Right Radius	Junction Notch=Use Default	
J=Left Radius	Vee Notch Angle=20.000	
K=Right Angle	2 Part Wrapper=No	Seams
L=Left Angle	Top Right=Straight	S1=None
M=Btm Right Extension	Top Left=Straight	S2=None
N=Btm Left Extension	Outlet=2	
O=Right Extension		
P=Left Extension		Damper:
Q=Top Extension		24

Pattern: 801 Rectangular




Dims	Options	Conn's
A=Btm Width	Throat Type=Radius	C1=None
B=Btm Depth	Vee Depth Male=Auto	C2=None
C=Top Width	Vee Depth Female=Auto	
D=Top Depth	Vee Angle Male=30	
E=Angle	Vee Angle Female=30	
F=Top Extension	Offset=Top Down	
G=Bottom Extension	Bending=Left	
H=Inner Radius	Allow Central Tie Rods=Yes	
I=Outer Radius	Straight Edge Wrappers=No	
J=Offset	Splitter Slit Angle=10.000	
	Intersect Splitter Holes=No	Seams
	·	S1=None

Damper:

courtesy of Applied Software 4/18/2016 64

Rectangular





Seams


Damper:



Pattern: 810 Rectangular/Round




Dims	Options	Conn's
A=Width In	Cross Break=2	C1=None
B=Depth In		C2=None
C=Radius In		
D=Width Out		
E=Depth Out		
F=Radius Out		
G=Length		
H=Angle In		
I=Angle Out		
J=Offset Width		
K=Offset Depth		Seams
L=Extension In		S1=None
M=Extension Out		



Damper:

courtesy of 4/18/2016 65

Rectangular



	ims	Options	Conn's
A=Length	B=Width	Vee Depth Male=Auto	C1=None
C=Height D=Angle		Vee Depth Female=Auto	
E=Extension		Vee Notch Angle=30.000	
		Use Vee Notch=No	
		Number Of Parts=3	


Seams

S1=None

Damper:

Pattern: 819


Rectangular



Dims	Options	Conn's
A=Top Width	Length Adjust For Part 4=0.000	C1=None
B=Depth	Length Adjust For Part 3=0.000	C2=None
C=Angle	Vee Depth Male=Auto	
D=Top Inner Extension	Vee Depth Female=Auto	
E=Bottom Extension	Vee Angle Male=30	
	Vee Angle Female=30	
	3 Parts=No	
	Seam Number For Throat=	
	Attenuator=No	
	Leg Lengths=No	
	Allow Central Tie Rods=Yes	Seams
	Riser Bend=No	S1=None

Damper:

Rectangular



Dims	Options	Conn's
A=Left Width	Six Parts Left Lap=None	C1=None
B=Right Width	Six Parts Right Lap=None	
C=Depth	Parts=2	
D=Length		
E=Bottom Radius		
F=Top Radius		
G=Cross Break		

Seams S1=None S2=None

Damper:

	•					
	•					
	•			•		
	1		1	•		1
Г	1		1			1
Γ]	Γ]			1
Γ]]]
Γ]]			
]]			
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		
				•		

Pattern: 834

Rectangular




Dims	Options	Conn's
A=Radius	Six Parts Left Lap=None	C1=None
B=Angle	Six Parts Right Lap=None	C2=None
C=Length	Allowance=Left	C3=None
D=Front Hole Diameter		
E=Back Hole Diameter		
F=Lid Pipe Radius		
G=Lid Pipe Length		
H=Base Pipe Radius		
I=Base Pipe Length		
J=Parts Left & Right		
		Seams
		S1=None
		S2=None
		S3=None

S4=None Damper:

Rectangular






Dims	Options	Conn's
A=Btm Width	Right Throat Type=Radius	C1=None
B=Btm Depth	Vee Depth Male=Auto	C2=None
C=Top Width	Vee Depth Female=Auto	C3=None
D=Top Depth	Vee Angle Male=30	
E=Right Width	Vee Angle Female=30	
F=Right Depth	Right Heel Type=Radius	
G=Top Offset	Junction Notch=Use Default	
H=Right Offset	Vee Notch Angle=20.000	
I=Height	Right Folds=End Point	
J=Right Height	Inlet=1	
K=Right Radius	Outlet=2	Seams
L=Right Angle	Top Right=Straight	S1=None
M=Bottom Extension		
N=Right Extension		
O=Top Inset		
P=Top Extension		Damper:
		bamper.

Pattern: 836

Rectangular







	Dims	Options	Conn's
	A=Left Width	Vee Depth Male=Auto	C1=None
	B=Left Depth	Vee Depth Female=Auto	C2=None
	C=Right Width	Vee Angle Male=30	
	D=Right Depth	Vee Angle Female=30	
	E=Centre Width	Left Offset Depth=Top Down	
	F=Centre Depth	Right Offset Depth=Top Down	
	G=Left Length	Equal Corner Radius=No	
	H=Right Length		
	I=Centre Length		
	J=Left Extension		
	K=Right Extension		Seams
	L=Left Offset Width		S1=None
	M=Left Offset Depth		
	N=Right Offset Width		
	O=Right Offset Depth		
	P=Left Top Radius		Damper:
	Q=Left Bottom Radius		'
	R=Right Top Radius		
	S=Right Bottom Radius		
1			

4/18/2016 courtesy of software. 68

Rectangular







	Dims	Options	Conn's
	A=Btm Width	Right Throat Type=Radius	C1=None
	B=Btm Depth	Left Throat Type=Radius	C2=None
	C=Btm Left Width	Vee Depth Male=Auto	C3=None
	D=Btm Right Width	Vee Depth Female=Auto	C4=None
	E=Top Width	Vee Angle Male=30	C5=None
	F=Top Depth	Vee Angle Female=30	
	G=Right Width	Gaps=0.000	
	H=Right Depth	Add Connector Allowance To One Side On	
	I=Left Width		
	J=Left Depth		
	K=Right Offset		Seams
	L=Left Offset		S1=None
	M=Top Offset		
	N=Top Inset		
	O=Height		
	P=Right Radius		Damper:
	Q=Left Radius		bamper.
	R=Right Angle		
	S=Left Angle		
	T=Btm Right Extension		
	U=Btm Left Extension		
	V=Top Extension		
	W=Right Extension		
	X=Left Extension		
\neg			

Pattern: 848

Rectangular







Dims	Options	Conn's
A=Btm Width	Left Throat Type=Radius	C1=None
B=Btm Depth	Vee Depth Male=Auto	C2=None
C=Btm Left Width	Vee Depth Female=Auto	C3=None
D=Top Width	Vee Angle Male=30	C4=None
E=Top Depth	Vee Angle Female=30	
F=Left Width	Gaps=0.000	
G=Left Depth	Add Connector Allowance To One Side On	
H=Left Offset		
I=Top Offset		
J=Top Inset		
K=Height		Seams
L=Left Radius		S1=None
M=Left Angle		
N=Btm Right Extension		
O=Btm Left Extension		
P=Top Extension		Damper:
Q=Left Extension		Damper.

4/18/2016 courtesy of software. 69

Rectangular






Dims	Options	Conn's
A=Btm Width	Right Throat Type=Radius	C1=None
B=Btm Depth	Left Throat Type=Radius	C2=None
C=Btm Left Width	Vee Depth Male=Auto	C3=None
D=Right Width	Vee Depth Female=Auto	C4=None
E=Right Depth	Vee Angle Male=30	
F=Left Width	Vee Angle Female=30	
G=Left Depth	Gaps=0.000	
H=Right Offset	Add Connector Allowance To One Side On	
I=Left Offset		
J=Right Radius		
K=Left Radius		Seams
L=Right Angle		S1=None
M=Left Angle		
N=Btm Right Extension		
O=Btm Left Extension		
P=Right Extension		Damper:
Q=Left Extension		Damper.

Pattern: 852 Rectangular/Round






Dims		Options	Conn's
A=Pipe Diameter	Inlet=1		C1=None
B=Angle	Outlet=2		C2=None
C=Pipe Length			C3=None
D=Inset			
E=Branch Height			
F=Branch Depth			
G=Branch Width			
H=Branch Gauge			
I=Extension			

Seams
S1=None
S2=None
S3=None
S4=None
S5=None Damper:

Rectangular







8.	0 11	6 1
Dims	Options	Conn's
A=Top Length	3 Parts=No	
B=Top Width	Vee Notch Angle=20.000	
C=Depth	-	
D=Btm Length		
E=Btm Width		
F=Top Left Ext		
G=Top Right Ext		
H=Btm Left Ext		
I=Left Depth		
J=Right Depth		
K=Gauge		Seams
L=Hole Diameter		S1=None
M=X-Offset		S2=None
N=Y-Offset		

Damper:

Pattern: 854
Rectangular/Round/Flat Oval






Dims	Options	Conn's
A=Btm Width	Bottom Diameter Type=Nominal	C1=None
B=Btm Depth	Left Diameter Type=Nominal	C2=None
C=Bottom Radius	Right Diameter Type=Nominal	C3=None
D=Left Width	Seam Position=Top	C4=None
E=Left Depth		
F=Left Radius		
G=Right Width		
H=Right Depth		
I=Right Radius		
J=Left Angle		
K=Right Angle		Seams
L=Height		S1=None
M=Left Offset		
N=Right Offset		
O=Bottom Collar		
P=Left Collar		Damper:
Q=Right Collar		24
R=Left Offset Depth		
S=Right Offset Depth		

4/18/2016 courtesy of Applied software 71


Rectangular



Dims	Options	Conn's
A=Btm Width		C1=None
B=Btm Depth		
C=Top Width		
D=Top Depth		
E=Hole Diameter		
F=Height		
G=Offset Width		
H=Offset Depth		
I=Bottom Extension		
J=Collar		
K=Angle		Seams



Pattern: 860
Rectangular



Dims	Options	Conn's
\=Width	Vee Depth Male=Auto	C1=None
B=Depth	Vee Depth Female=Auto	
C=Height	Vee Angle Male=30	
D=Top Radius	Vee Angle Female=30	
E=Bottom Extension		


Seams
S1=None

Damper:

Damper:

4/18/2016 courtesy of Applied software 72

Rectangular/Standard




	Dims	Options	Conn's
A=Width	B=Depth	Type=1 Part Straight	C1=None
C=Length		Notch Angle For Lid=45.000	
		Lid Adjust=0.000	
		Cost Supports=No	

Seams

S1=None S2=None


Damper:



Pattern: 862

Rectangular


4/18/2016



Options	Conn's
Correct Hole Sizes=No	C1=None
Dynamic Hole Adjust=Auto	C2=None
	Correct Hole Sizes=No

Seams

Damper:



73


Rectangular



Dims	Options	Conn's
A=Width	Type=Inside	
B=Length		
C=Depth		
D=Top Width		
E=Radius In		
F=Radius Out		
G=Turnover		
H=Extension		

Seams S1=None

Damper:



Pattern: 866

Rectangular



	Dims	Options	Conn's
A=Width C=Length	B=Depth	Connector Fold Notch=Use Default Vee Notch Depth=Auto Vee Notch Angle=30.000 Override=None	C1=None C2=None
		Connector Fold Notch=Use Default Vee Notch Depth=Auto Vee Notch Angle=30.000 Beading=No Lengths Include Connector Adjust=No Override Cut Type=None	Seams
		Insulation Parts=Same Insulation UI=Shortest Side Machine Cut If Dynamic Branches=No	S1=None S2=None

Damper:




Rectangular



Dims		Options	Conn's
A=Width	3 Parts=No		
B=Depth			
C=Length			
D=Top			
E=Border			
F=Extension			
G=Fixing Hole Diameter			
H=Hole Inset			
I=Hole Spacing			


Seams

Damper:



Pattern: 882


Rectangular



Dims	Options	Conn's
A=Width In		C1=None
B=Depth		C2=None
C=Width Out		C3=None
D=Angle Out		
E=Length		
F=Slope Angle		
G=Extension		


Seams S1=None

Damper:



courtesy of Applied Software 4/18/2016 75


Rectangular



Dims	Options	Conn's
A=Width	Vee Depth Male=Auto	C1=None
B=Depth	Vee Depth Female=Auto	
C=Angle	Vee Notch Angle=30.000	
D=Extension	Use Vee Notch=No	
E=Hole Width		
F=Hole Depth		
G=Hole Radius		
H=Offset Width		
I=Offset Depth		
J=Hole Width		
K=Hole Depth		Seams
L=Hole Radius		S1=None
M=Offset Width		
N=Offset Depth		
O=Step In Depth		
P=Step In Height		Damper:
Q=Depth		bumper.

Pattern: 898 Rectangular/Standard


4/18/2016



Dims	Options	Conn's
A=Width	Vertical=1	
B=Height	Horizontal=1	
C=Depth	Shelf Recess=0.000	
D=Kick Height	Kick Recess=0.000	
E=Centre Stile Width	Doors=None	

Seams

Damper:



courtesy of Applied Software 76

Rectangular/Round/Flat Oval/Standard/Equipment


Options Inlet=1 Outlet=1 Pipework=No Show Boundaries=No


Seams

Damper:

Pattern: 903

Rectangular





Dims Options Conn's A=Width Vee Notch Depth=0.000 B=Depth Vee Notch Angle=0 C=Height D=Door Depth E=Top Thickness F=Side Thickness G=Door Overhang H=Turnover


Seams

Damper:

Rectangular/Standard/Structure/Equipment



Pattern: 913
Rectangular/Round/Equipment



Dims	Options	Conn's
A=Depth	Type=Full	C1=None
B=Width	Rotation=Vertical	C2=None
C=Height	Closed=Yes	
D=Flange	Hole Type=Circle/Ellipse	
E=Flange	Draw as Single Line=No	
F=Radius	Full=No	
G=Radius	Connectors=Yes	
H=Web	Hole Rotation=0	
I=Left Horizontal Angle	Export=No	
J=Right Horizontal Angle		
K=Left Vertical Angle		Seams
L=Right Vertical Angle		
M=Turnover #1		
N=Turnover #2		
O=Hole Inset		
P=Hole Offset		Damper:
Q=Hole Width		·
R=Hole Depth		
S=Hole Spacing		
T=Number Of Holes		
U=Plate Width #1		
V=Plate Depth #1		
W=Plate Thickness #1		
X=Plate Inset #1		
Y=Plate Offset #1		
Z=Plate Width #2		
a=Plate Depth #2		
b=Plate Thickness #2		

Dims	Options	Conn's
A=Width	Mirror=No	C1=None
B=Depth	Base Depth=Yes	C2=None
C=Length	Cost Supports=No	
D=Height		
E=X Distance		
F=Y Distance		
G=Diameter		
H=Rotation		
I=Base Height		
J=Base Width		
K=Base Depth		Seams
L=Extension		

Damper:

4/18/2016 courtesy of software 78

Rectangular/Equipment



Dims	Options	Conn's
A=Width	Install Type=Plain	C1=None
B=Depth	Sex Type=Male	C2=None
C=Length	Control Type=None	
D=Inset	Type=Single	
E=Inset	Draw Type=None	
F=Sides	Temperature Type=None	
G=Top	Draw Type=None	
H=Bottom	Lines=No	
I=Extension	Type=Auto	
J=Right Extension	Cost Supports=No	
K=Sides	Lines Type=Quantity	Seams
L=Bottom	Lines=3.000	
M=Top		

Damper:

Pattern: 915

Rectangular

4/18/2016




Dims	Options	Conn's
Diameter		

A=Diameter B=Inner Radius C=Angle


Seams


S1=None

Damper:



Rectangular





Dims	Options	Conn's
A=Width	Turnover=In	C1=None
B=Depth	Turnover=Top	C2=None
C=Length	Vee Notch Depth=Auto	
D=Turnover #1	Vee Notch Angle=0.000	
E=Turnover #2	Marker Depth=0.000	
	Marker Angle=0.000	
	Type=Rectangular	
	Maximum Stretchout=10000.000	

Seams

Damper:

Pattern: 919


Rectangular




Options	Conn's
Vee Notch Depth=Auto	C1=None
Vee Notch Angle=0.000	C2=None
Marker Depth=0.000	
Marker Angle=0.000	
Parts=2	
	Vee Notch Depth=Auto Vee Notch Angle=0.000 Marker Depth=0.000 Marker Angle=0.000


Seams S1=None

Damper:



Rectangular





Dims	Options	Conn's
A=Width	Turnover=In	C1=None
B=Depth	Vee Notch Depth=Auto	C2=None
C=Depth	Vee Notch Angle=0.000	
D=Length	Marker Depth=0.000	
E=Extension	Marker Angle=0.000	
F=Turnover #1	Type=Rectangular	
G=Turnover #2	Maximum Stretchout=10000.000	

Seams

Damper:

Pattern: 921
Rectangular/Standard



Options	Conn's
Type=Rectangular	C1=None
Vee Notch Depth=0.000	
Vee Notch Angle=0.000	
	Type=Rectangular Vee Notch Depth=0.000


Seams

Damper:



4/18/2016 courtesy of software 81


Rectangular



	Dims	Options	Conn's
A=Width C=Length	B=Depth	Connector Fold Notch=Use Default Vee Notch Depth=Auto Vee Notch Angle=30.000 Override=None Connector Fold Notch=Use Default Vee Notch Depth=Auto Vee Notch Angle=30.000 Beading=No Insulation UI=Shortest Side	C1=None C2=None


Seams S1=None S2=None

Damper:



Pattern: 926 Rectangular






Dims	Options	Conn's
A=Left Width	Item Connector Len1=0.000	C1=None
B=Left Depth	Item Connector Len2=0.000	
C=Length	3 Parts=Yes	
D=Right Width	Connector=No	
E=Right Depth	Seam Extension=No	
F=Offset Width	Vee Depth Male=Auto	
G=Offset Depth	Vee Depth Female=Auto	
H=Left Extension	Vee Angle Male=90.000	
I=Right Extension	Vee Angle Female=90.000	
J=Step In Depth	Use Vee Notch=No	
K=Depth	Chamfer Seam Allowances=Yes	Seams
	Rotation=0	S1=None
	Cost Supports=No	S2=None

Damper:


Rectangular



Dims	Options	Conn's
A=Width	Notch Angle For Seam=30.000	C1=None
B=Depth		C2=None
C=Length		
D=Inlet Width		
E=Inlet Depth		
F=Inlet Length		
G=Inlet Offset Width		
H=Inlet Offset Depth		
I=Outlet Width		
J=Outlet Depth		
K=Outlet Length		Seams
L=Outlet Offset Width		S1=None
M=Outlet Offset Depth		S2=None


Damper:


Pattern: 929
Rectangular



Dims	Options	Conn's
A=Width	Front Top and Back Parts=1	C1=None
B=Depth	Pipe Parts=Yes	C2=None
C=Outlet	Hole Adjust=0.000	
D=Diameter	Air Guide=Yes	
E=Height	Air Guide Adjust=0.000	
F=Back	Access Door=Round	
G=Top Width	Pipe Parts=	
H=Sides	Air Guide=	
I=Top Depth	Vee Depth Male=Auto	
J=Pipe Length	Vee Depth Female=Auto	
K=Extension	Vee Angle Male=30	Seams
L=Hole Diameter	Vee Angle Female=30	S1=None
M=Tie Rod Position #1	Front Hole Offset=Centre	S2=None
N=Tie Rod Hole Diameter	Back Hole Offset=Centre	
O=Tie Rod Position #2		
P=Front Hole Offset		Damper:
Q=Back Hole Offset		'

Rectangular





Dims	Options	Conn's
A=Top Width	Vee Angle Female=20	C1=None
B=Btm Width	Vee Angle Male=20	
C=Top Height	Vee Depth Female=Auto	
D=Bottom Height	Vee Depth Male=Auto	
E=Length	Chamfer Notches On Outer Corners=No	
F=Offset	3 Part Wrap=No	
	Connector Allowance=4 Sides	
	Cost Supports=No	

Seams S1=None S2=None

Damper:

Pattern: 939






Dims	Options	Conn's
A=Width	Vee Depth Male=Auto	C1=None
B=Depth	Vee Depth Female=Auto	C2=None
C=Length	Vee Angle Male=30	C3=None
D=Extension In	Vee Angle Female=30	C4=None
E=Extension Out	Offset Width=Left In	
F=Offset Width	Restricted Flow=Warning	
G=Radius		
H=Connector Inset		

Seams S1=None S2=None


Damper:


Rectangular/Ductboard



	_		
Dims	Opt	tions	Conn's
A=Width In	2 Parts=No	Fixing Holes on Tur	C1=None
B=Depth In	3 Parts=No	Show Fold Angles=	C2=None
C=Width Out	Vee Depth Male=A		
D=Depth Out	Vee Depth Female=		
E=Length	Vee Notch Angle=2		
F=Extension In	Taper Notch If Strai		
G=Extension Out	Female Allow=Shor		
H=Offset Width	2-Sided Part Allowa		
I=Offset Depth	Offset Width=Left In		
J=Angle	Offset Depth=Botto		
	Taper Notch If Strai		Seams
	Use Taper Notch F		S1=None
	Connector Fold Not		
	Vee Notch Depth=		
	Vee Notch Angle=3		
	Input=Length		Damper:
	Vee Notch Depth If		Damper.
	Maximum Angle=1		
	Splitter Turnover=0		
	Splitter Extension=		
	Splitter Adjust=0.000		
	Connector Fold Not		
	Vee Notch Depth=		
	Vee Notch Angle=3		
	Splitter Hole Diame		
	Number Of Holes=		
	Splitters=Half		

Pattern: 943 Rectangular/Ductboard






Dims	Options	Conn's
A=Top Width	Throat Type=Radius	C1=None
B=Depth	Length Adjust For Part 4=0.000	C2=None
C=Angle	Length Adjust For Part 3=0.000	
D=Top Inner Extension	Vee Depth Male=Auto	
E=Bottom Extension	Vee Depth Female=Auto	
F=Inner Radius	Vee Angle Male=30	
	Vee Angle Female=30	
	Auto Oversize=Normal	
	Seam Number For Throat=	
	Leg Lengths=No	
	Allow Central Tie Rods=Yes	Seams
	Riser Bend=No	S1=None
	Mark Splitter Sides=No	
	Outer Mitre=300.000	


Hole Inset=0.000

Damper:

Rectangular/Ductboard




Dims	Options	Conn's
A=Width In	Vee Depth Male=Auto	C1=None
B=Depth In	Vee Depth Female=Auto	C2=None
C=Width Out	Vee Angle Male=30	
D=Depth Out	Vee Angle Female=30	
E=Length	Offset Width=Left In	
F=Extension In	Offset Depth=Top Down	
G=Extension Out	Restricted Flow=Warning	
H=Offset Width		
I=Offset Depth		
J=Left Radius		
K=Right Radius		Seams
-		S1=None



Pattern: 945 Rectangular/Ductboard




Dims	Options	Conn's
A=Btm Width	Throat Type=Radius	C1=None
B=Depth	Vee Depth Male=Auto	C2=None
C=Left Width	Vee Depth Female=Auto	C3=None
D=Right Width	Vee Notch Angle=30.000	
E=Right Radius	Hole Diameter=0.500	
F=Left Radius	Hole Spacing=2.000	
G=Btm Right Extension	Splitters=No	
H=Btm Left Extension	Inlet=1	
I=Right Extension	Outlet=2	
J=Left Extension		
K=Splitter Distance		Seams
•		S1=None



Damper:


Damper:

Rectangular/Ductboard



Dims	Options	Conn's
A=Btm Width	Right Throat Type=Radius	C1=None
3=Depth	Left Throat Type=Radius	C2=None
C=Right Width	Right Heel Type=Radius	C3=None
D=Left Width	Left Heel Type=Radius	
=Height	2 Part Wrapper=No	
=Right Radius	Outlet=2	
G=Left Radius		
H=Right Angle		
=Left Angle		
=Btm Right Extension		
K=Btm Left Extension		Seams
=Right Extension		S1=None
M=Left Extension		S2=None
N=Top Extension		

Damper:




Pattern: 947
Rectangular/Ductboard




Dims	Options	Conn's
A=Top Width	Branch Parts=Auto	C1=None
B=Depth		C2=None
C=Height		
D=Btm Width		
E=Bottom Extension		

Seams

Damper:




Rectangular/Ductboard




Dims	Options	Conn's
A=Btm Width	Right Throat Type=Radius	C1=None
B=Depth	Right Heel Type=Radius	C2=None
C=Top Width	2 Part Wrapper=No	C3=None
D=Right Width	Top Right=Straight	
E=Height	Outlet=2	
F=Right Height		
G=Right Radius		
H=Right Angle		
I=Bottom Extension		
J=Right Extension		
K=Top Extension		Seams
		S1=None
		S2=None

Damper:




Pattern: 951 Rectangular/Ductboard



Dims	Options	Conn's
A=Btm Width	Right Throat Type=Radius	C1=None
B=Depth	Left Throat Type=Radius	C2=None
C=Top Width	Right Heel Type=Radius	C3=None
D=Right Width	Left Heel Type=Radius	C4=None
E=Left Width	2 Part Wrapper=No	
F=Height	Top Right=Straight	
G=Right Height	Top Left=Straight	
H=Left Height	Outlet=2	
I=Right Radius		
J=Left Radius		
K=Right Angle		Seams
L=Left Angle		S1=None
M=Btm Right Extension		S2=None
N=Btm Left Extension		
O=Right Extension		
P=Left Extension		Damper:
Q=Top Extension		bumper.
7		

4/18/2016 courtesy of software. 88


Rectangular/Ductboard




Dims	Options	Conn's
A=Top Width	Length Adjust For Part 4=0.000	C1=None
B=Depth	Length Adjust For Part 3=0.000	C2=None
C=Btm Width	Vee Depth Male=Auto	
D=Angle	Vee Depth Female=Auto	
E=Top Inner Extension	Vee Angle Male=30	
F=Bottom Extension	Vee Angle Female=30	
	3 Parts=No	
	Seam Number For Throat=	
	2 Part Wrapper=No	
	Leg Lengths=No	
	Allow Central Tie Rods=Yes	Seams
	Riser Bend=No	S1=None

Damper:

Pattern: 953 Rectangular/Ductboard





Dims	Options	Conn's
A=Top Width	Throat Type=Radius	C1=None
B=Depth	Length Adjust For Part 4=0.000	C2=None
C=Btm Width	Length Adjust For Part 3=0.000	
D=Angle	Vee Depth Male=Auto	
E=Top Inner Extension	Vee Depth Female=Auto	
F=Bottom Extension	Vee Angle Male=30	
G=Inner Radius	Vee Angle Female=30	
	Auto Oversize=Normal	
	Seam Number For Throat=	
	Leg Lengths=No	
	Allow Central Tie Rods=Yes	Seams
	Riser Bend=No	S1=None
	Mark Splitter Sides=No	
	Outer Mitre=300.000	

Damper:

Rectangular/Ductboard



Dims	Options	Conn's
A=Btm Width	3 Parts=No	C1=None
B=Depth	Vee Depth Male=Auto	C2=None
C=Left Width	Vee Depth Female=Auto	C3=None
D=Right Width	Vee Notch Angle=30.000	
E=Bottom Extension	Hole Diameter=0.500	
F=Right Extension	Hole Spacing=2.000	
G=Left Extension	Splitters=No	
H=Splitter Distance	Inlet=1	
	Outlet=2	

Seams

S1=None

Damper:


Pattern: 955 Rectangular/Ductboard




Dillis	Options	COIIII 3
A=Left Width	Split Mitre=No	C1=None
B=Depth		C2=None
C=Right Width		
D=Length		
E=Left Extension		
F=Right Extension		
G=Offset Width		
H=Angle		
I=Left Extension		
J=Right Extension		
K=Right Width		Seams
		S1=None

Damper: None None

Rectangular/Ductboard






Dims	Options	Conn's
A=Width	Collar Allowance=0.000	C1=None
B=Depth	Diameter Type=Nominal	C2=None
C=Length	Hole Adjust=0.000	
D=Hole Width #1	Position From=Centre	
E=Hole Depth #1	Use Vee Notch=No	
F=Hole Radius #1	Vee Notch Angle=0.000	
G=Hole Inset #1		
H=Hole Offset #1		
I=Hole Collar #1		
J=Hole Rotation #1		
		Seams
		S1=None

S2=None

Damper: None


Pattern: 957 Rectangular/Ductboard



	Dims	Options	Conn's
A=Width	B=Depth	Type=1 Part Straight	C1=None
C=Length			

Seams

Damper:




Rectangular/Ductboard

	Dims	Options	Conn's	
A=Width	B=Depth		C1=None	




Seams

Damper:




Pattern: 959

Rectangular



Options	Conn's
Vee Depth Male=Auto	C1=None
Vee Depth Female=Auto	C2=None
Vee Notch Angle=20.000	
Taper Notch If Straight Edge (Female)=No	
Female Allow=Shortest Slope	
Offset Width=Left In	
Offset Depth=Bottom Up	
Taper Notch If Straight Edge (Male)=No	
Input=Length	
Vee Notch Depth If Straight Edge (Female)	-
_	Seams
Splitter Turnover=0.000	S1=None
Splitter Extension=0.000	
!	
	Damper:
!	·
3	
Seam Cut Back=0.000	
	Vee Depth Male=Auto Vee Depth Female=Auto Vee Notch Angle=20.000 Taper Notch If Straight Edge (Female)=No Female Allow=Shortest Slope Offset Width=Left In Offset Depth=Bottom Up Taper Notch If Straight Edge (Male)=No Input=Length Vee Notch Depth If Straight Edge (Female) Maximum Angle=180.000 Splitter Turnover=0.000

Rectangular/Round




Dims	Options	Conn's
A=Diameter	Vee Depth Male=0.000	C1=None
B=Left Height	Vee Angle Male=30.000	
C=Right Height	Vee Depth Female=0.000	
D=Length	Vee Angle Female=30.000	
E=Right Length	Notch Out=No	
	Use Ends Seam 3=No	
	Split Radius=No	
	Close Middle=No	

Seams

S1=None S2=None S3=None

Damper:



Pattern: 963 Rectangular/Round




Dims	Options	Conn's
A=Diameter	Vee Depth Male=0.000	C1=None
B=Left Height	Vee Angle Male=30.000	
C=Right Height	Vee Depth Female=0.000	
D=Length	Vee Angle Female=30.000	
E=Left Length	Notch Out=No	
F=Right Length	Use Ends Seam 3=No	
	Split Radius=No	
	Close Middle=No	

5	e	a	Ï	n	į

S1=None S2=None S3=None

Damper:



courtesy of 4/18/2016 93

Rectangular/Round




Dims	Options	Conn's
A=Width	Vee Depth Male=0.000	C1=None
B=Depth	Vee Angle Male=30.000	
C=Length	Vee Depth Female=0.000	
D=Left Radius	Vee Angle Female=30.000	
E=Top Radius	Notch Out=No	

Seams

S1=None S2=None


Damper:





Pattern: 966
Rectangular/Standard






Dims	Options	Conn's
A=Width	Top Folds=2	C1=None
B=Depth	Bottom Folds=1	
C=Top Extension #1	Left Folds=1	
D=Top Fold Angle #1	Right Folds=1	
E=Top Extension #2	Attach=	
F=Top Fold Angle #2	Attacher Side=Top	
G=Bottom Extension #1	Attacher Extension=1	
H=Bottom Fold Angle #1	Mirror Left/Top=Auto	
I=Left Extension #1	Rotate Left/Top=Auto	
J=Left Fold Angle #1	Mirror Right/Bottom=Auto	
K=Right Extension #1	Rotate Right/Bottom=Auto	Seams
L=Right Fold Angle #1	Notch Corners=No	
M=Attach #1		
N=Attach #2		
O=Attach #3		
P=Top Inset		Damper:
Q=Bend Radius		

4/18/2016 courtesy of Applied 94

Rectangular




Diver	Outions	Connels
Dims	Options	Conn's
A=Width	Height=Up Slope	
B=Height	Notch=Vee Notch	
C=Depth	Input=Slope Angle	
D=Slope Angle		
E=Rise X On 12		
F=Up Slope Flange		
G=Down Slope Flange		
H=Left Flange		
I=Right Flange		
J=Cant Angle		
K=Cant Height		Seams
L=Cant Depth		S1=None
M=Top Flange Down		S2=None
N=Top Flange In		

Damper:


Pattern: 972
Rectangular/Standard






	Dims	Options	Conn's
A=Width	B=Depth	Straight Type=1 Part Straight	C1=None
C=Length		Female Allow=Shortest Side	C2=None
		1xU,1xI=Shortest Side	C3=None
		Connector Fold Notch=Use Default	C4=None
		Vee Notch Depth=Auto	C5=None
		Vee Notch Angle=30.000	C6=None
		Connector Fold Notch=Use Default	
		Vee Notch Depth=Auto	
		Vee Notch Angle=30.000	
		Beading=No	
		Vertical=No	Seams
		Adjust=0.000	S1=None
		Right Offset=6.000	
		Left Offset=6.000	
		Insulation UI=Shortest Side	
			Damper:

Rectangular





Dims	Ontions	Conn's
Dims A=Width In B=Depth In C=Width Out D=Depth Out E=Length F=Offset Width G=Offset Depth H=Angle I=Seam Inset	Type=Auto Offset Width=Left In Offset Depth=Bottom Up Vee Notch Depth=Auto Vee Notch Angle=30.000 Input=Length Maximum Angle=180.000 Splitters=Half Splitter Turnover=0.000 Splitter Extension=0.000 Splitter Adjust=0.000 Splitter Hole Diameter=0.000 Number Of Holes=0.000 Hole Inset=0.000 Fixing Holes on Turnover=No	Conn's C1=None C2=None Seams S1=None

Pattern: 981

Rectangular



0	0	0	0	0	0	0	0	0	0
0	/							/	0
0	`						/	,	0
0									0
0									0
0									0
0									0
0									0
0		,					`		0
0	0	0	0	0	0	0	0	0	0

Dims	Options	Conn's
A=Width #1	Vee Notch Angle=5.000	C1=None
B=Depth #1	Specify Holes=By Number Of	C2=None
C=Width #2	Holes Across=10	
D=Depth #2	Holes Down=10	
E=Flange Length		
F=Flange Angle		
G=Hole Diameter		
H=Holes Inset		
I=Holes Offset		
		Seams

Damper:

Damper:

Rectangular/Equipment



Dims	Options	Conn's
A=Width	Type=Supply	C1=None
B=Depth	Position From=Edge	C2=None
C=Height	Lines=3	
D=Plate Border (Width)	Rotation=0.000	
E=Plate Border (Depth)	Arrows/Lines=None	
	Arrows/Lines Sides=0	
	Lines/Circles Spacing=1.000	
	Arrows Direction=Auto	
	Circles=No	
	Arrows Type=1	
		Seams

Damper:

Pattern: 986


Rectangular



Dims	Options	Conn's
A=Width	Pipe Parts=Yes	C1=None
B=Depth	Branch Parts=Yes	C2=None
C=Length	Branch Diameter Type=Nominal	C3=None
D=Left Extension	Straight Type=1 Part Straight	
E=Right Extension	Female Allow=Shortest Side	
F=Branch Width	1xU,1xl=Shortest Side	
G=Branch Depth	Connector Fold Notch=Use Default	
H=Branch Length	Vee Notch Depth=Auto	
I=Angle	Vee Notch Angle=30.000	
J=Inset	Connector Fold Notch=Use Default	
K=Offset	Vee Notch Depth=Auto	Seams
L=Extension	Vee Notch Angle=30.000	S1=None
	Branch Rotation=0	S2=None
	Branch Allowance To Pipe=0.000	


Damper: None

Rectangular



Dims	Options	Conn's
\=Width	Pipe Parts=Yes	C1=None
3=Depth	Branch Parts=Yes	C2=None
C=Length	Branch Diameter Type=Nominal	C3=None
D=Left Extension	Straight Type=1 Part Straight	C4=None
E=Right Extension	Female Allow=Shortest Side	
=Branch Width	1xU,1xl=Shortest Side	
G=Branch Depth	Connector Fold Notch=Use Default	
H=Branch Length	Vee Notch Depth=Auto	
=Angle	Vee Notch Angle=30.000	
=Inset	Connector Fold Notch=Use Default	
<=Offset	Vee Notch Depth=Auto	Seams
_=Extension	Vee Notch Angle=30.000	S1=None
M=Branch Width	Branch Rotation=0	S2=None
N=Branch Depth	Branch Rotation=90	S3=None
D=Branch Length	Branch Allowance To Pipe=0.000	
P=Angle		Damper: None
Q=Inset		None
R=Offset		NOTIC
S=Extension		

Pattern: 996 Rectangular/Round/Equipment



Dims	Options	Conn's
A=Width	Type=Supply	C1=None
B=Depth	Position From=Edge	C2=None
C=Height	Type=Round	C3=None
D=Diameter	Rotation=0.000	C4=None
E=Collar	Collar=No	C5=None
F=Plate Border (Width)	Arrows/Lines=None	C6=None
G=Plate Border (Depth)	Arrows/Lines Sides=0	C7=None
	Lines/Circles Spacing=1.000	C8=None
	Arrows Direction=Auto	
	Circles=No	
	Arrows Type=1	Seams
	Diffuser Type=None	
	Cost Supports=No	

Damper:

Rectangular/Round/Flat Oval/Standard/Equipment

Dims Options Conn's

Inlet=1
Outlet=1
Pipework=No
Show Boundaries=No
Faces=No

Seams

Damper:

Pattern: 1105
Rectangular/Standard


Dims Options Conn's

Show Elements=All


Seams

Damper:

Rectangular/Ductboard




Dims	Options	Conn's
A=Btm Width	Left Throat=Radius	C1=None
B=Depth	Right Throat=Radius	C2=None
C=Left Bottom Width		C3=None
D=Right Bottom Width		C4=None
E=Left Width		
F=Top Width		
G=Right Width		
H=Top Length #1		
I=Top Length #2		
J=Bottom Extension		
K=Left Extension		Seams
L=Top Extension		S1=None
M=Right Extension		
N=Left Radius		
O=Top Radius		
P=Right Radius		Damper:




Pattern: 1121 Rectangular/Ductboard





Dims	Options	Conn's
A=Btm Width	Right Throat Type=Radius	C1=None
B=Btm Depth	Left Throat Type=Radius	C2=None
C=Right Width	Vee Depth Male=Auto	C3=None
D=Right Depth	Vee Depth Female=Auto	
E=Left Width	Vee Angle Male=30	
F=Left Depth	Vee Angle Female=30	
G=Right Offset	Vee Notch Angle=20.000	
H=Left Offset	2 Part Wrapper=No	
I=Height	Right Folds=End Point	
J=Right Radius	Left Folds=End Point	
K=Left Radius	Inlet=1	Seams
L=Right Angle	Outlet=2	S1=None
M=Left Angle		S2=None
N=Btm Right Extension		
O=Btm Left Extension		
P=Right Extension		Damper:
Q=Left Extension		Damper.
J		


Rectangular/Ductboard



Dims	Options	Conn's
A=Btm Width	Throat Type=Radius	C1=None
B=Btm Depth	Vee Depth Male=Auto	C2=None
C=Top Width	Vee Depth Female=Auto	
D=Top Depth	Vee Angle Male=30	
E=Angle	Vee Angle Female=30	
F=Top Extension	Offset=Top Down	
G=Bottom Extension	Bending=Left	
H=Inner Radius	Allow Central Tie Rods=Yes	
I=Offset	Splitter Slit Angle=10.000	
	Intersect Splitter Holes=No	
	•	Seams


S1=None

Damper:




Pattern: 1124

Rectangular




Dims	Options	Conn's
A=Btm Width	Same Widths=Yes	C1=None
B=Btm Depth	Left Rotation=Left	C2=None
C=Left Top Width	Right Rotation=Right	C3=None
D=Right Top Width	Left Throat Type=Radius	
E=Btm Left Extension	Right Throat Type=Radius	
F=Btm Right Extension	Inner Wrap Length Adjust=0.000	
G=Left Extension	Outer Wrap Length Adjust=0.000	
H=Left Inner Radius	Vee Depth Male=Auto	
I=Left Angle	Vee Depth Female=Auto	
J=Right Extension	Vee Angle Male=30	
K=Right Inner Radius	Vee Angle Female=30	Seams
L=Right Angle	Auto Oversize=Normal	S1=None
M=Gap Width	Seam Number For Throat=	S2=None
N=C2 Depth		
O=C3 Depth		


Damper:



courtesy of Applied Software 4/18/2016 101

Rectangular







Dims	Options	Conn's
A=Btm Width	Same Depths=Yes	C1=None
B=Btm Depth	Back Rotation=Left	C2=None
C=Back Top Width	Front Rotation=Right	C3=None
•	· ·	C3-None
D=Front Top Width	Back Throat Type=Radius	
E=Btm Back Extension	Front Throat Type=Radius	
F=Btm Front Extension	Inner Wrap Length Adjust=0.000	
G=Back Extension	Outer Wrap Length Adjust=0.000	
H=Back Inner Radius	Vee Depth Male=Auto	
I=Back Angle	Vee Depth Female=Auto	
J=Front Extension	Vee Angle Male=30	
K=Front Inner Radius	Vee Angle Female=30	Seams
L=Front Angle	Auto Oversize=Normal	S1=None
M=Gap Depth	Seam Number For Throat=	S2=None
N=C2 Depth		
O=C3 Depth		

Damper:

Pattern: 1126


Rectangular





Dims	Opt	ions	Conn's
A=Btm Width	Same Widths=Yes	Vee Notch Angle=3	C1=None
B=Depth	= Bend Options ===	Vee Notch Depth If	C2=None
C=Bend Top Width	Bend Rotation=Left	Taper Notch If Strai	C3=None
D=Taper Width Out	Throat Type=Radius	Taper Notch If Strai	
E=Taper Depth Out	Inner Wrap Length	Use Taper Notch F	
F=Bottom Extension	Outer Wrap Length	Seam Cut Back=0.0	
G=Bend Extension	Vee Depth Male=A		
H=Bend Inner Radius	Vee Depth Female=		
I=Bend Angle	Vee Angle Male=30		
J=Taper Extension Out	Vee Angle Female=		
K=Taper Length	Auto Oversize=Nor		Seams
L=Taper Angle	Seam Number For		S1=None
M=Taper Offset Width	= Taper Options ==		S2=None
N=Taper Offset Depth	Input=Length		S3=None
O=Gap Width	2 Parts=No		
P=C2 Depth	3 Parts=No		Damper:
Q=C3 Depth	Vee Depth Male=A		Damper.
	Vee Depth Female=		
	Vee Notch Angle=20		
	Female Allow=Shor		
	2-Sided Part Allowa		
	Offset Width=Left In		
	Offset Depth=Botto		
	Connector Fold Not		
	Vee Notch Depth=		
	Vee Notch Angle=3		
I	Connector Fold Not		
	Vee Notch Depth=		


Rectangular




Dims	Options	Conn's
A=Btm Width	Same Widths=Yes	C1=None
B=Depth	= Bend Options === Bend Options =	C2=None
C=Bend Top Width	Bend Rotation=Left	C3=None
D=Square-To-Round Dia	Throat Type=Radius	
E=Bottom Extension	Inner Wrap Length Adjust=0.000	
F=Bend Extension	Outer Wrap Length Adjust=0.000	
G=Bend Inner Radius	Vee Depth Male=Auto	
H=Bend Angle	Vee Depth Female=Auto	
I=Square-To-Round Collar	Vee Angle Male=30	
J=Square-To-Round Length	Vee Angle Female=30	
K=Square-To-Round Slop	Auto Oversize=Normal	Seams
L=Square-To-Round Offse	Seam Number For Throat=	S1=None
M=Square-To-Round Offs	= Square To Round Options === Square To	S2=None
N=Gap Width	Cross Break=2	S3=None
O=C2 Depth	Length Break=1	S4=None
	Diameter Type=Nominal	Damper: None
	Seam Position=Width	24pc
	Marker Type=Notch	
	Input=Length	
	Offset Width=Left In	
	Offset Depth=Bottom Up	
	Inlet=1	
	Outlet=3	
	Fold Notch Depth=Full Allowance	
1	Use Join Seam=Yes	
J		

Pattern: 1128


Rectangular





	Dims	Options	Conn s
	A=Btm Width	Same Widths=Yes	C1=None
	B=Btm Depth	Vertical Center=No	C2=None
	C=Top Width	Input=Length	
	D=Top Depth	2 Parts=No	
	E=Bottom Extension	3 Parts=No	
	F=Top Extension	Vee Depth Male=Auto	
	G=Length	Vee Depth Female=Auto	
	H=Taper Angle #1	Vee Notch Angle=20.000	
	I=Taper Angle #2	Female Allow=Shortest Slope	
	J=Taper Offset Width #1	2-Sided Part Allowance=Auto	
	K=Taper Offset Depth	Offset Width=Left In	Seams
	L=Gap Width	Offset Depth=Bottom Up	S1=None
		Connector Fold Notch=Use Default	S2=None
		Vee Notch Depth=Auto	S3=None
		Vee Notch Angle=30.000	
		Connector Fold Notch=Use Default	Damper:
		Vee Notch Depth=Auto	24po
		Vee Notch Angle=30.000	
		Vee Notch Depth If Straight Edge (Female)	
		Taper Notch If Straight Edge (Male)=No	
		Taper Notch If Straight Edge (Female)=No	
		Use Taper Notch For 2 Parts=Yes	
		Seam Cut Back=0.000	
		Width To Depth Ratio=Always Two Parts	
l			

Rectangular





Dims	Options	Conn's
A=Width	Same Widths=Yes	C1=None
B=Depth	Connector Fold Notch=Use Default	C2=None
C=Length	Vee Notch Depth=Auto	
D=Gap Width	Vee Notch Angle=30.000	
	Connector Fold Notch=Use Default	
	Vee Notch Depth=Auto	
	Vee Notch Angle=30.000	
	Oversize Check=Yes	
	Width To Depth Ratio=Always Two Parts	


Seams S1=None S2=None S3=None

Damper:

Pattern: 1130
Rectangular/Ductboard



Dims	Options	Conn's
A=Btm Width	Left Throat=Radius	C1=None
B=Depth	Right Throat=Radius	C2=None
C=Left Bottom Width		C3=None
D=Left Width		C4=None
E=Right Width		
F=Bottom Extension		
G=Left Extension		
H=Right Extension		
I=Left Radius		
J=Right Radius		
		Seams S1=None




Damper:

Rectangular/Ductboard




Dims	Options	Conn's
A=Btm Width	Right Throat=Radius	C1=None
B=Depth	mgne mode-nadias	C2=None
C=Right Bottom Width		C3=None
D=Top Width		C4=None
E=Right Width		C4-NOILE
o .		
F=Top Length #1		
G=Top Length #2		
H=Bottom Extension		
I=Top Extension		
J=Right Extension		
K=Top Radius		Seams
L=Right Radius		S1=None

Damper:




Pattern: 1133

Rectangular



Dims	Options	Conn's
A=Width	Straight Type=1 Part Straight	C1=None
B=Depth	Female Allow=Shortest Side	C2=None
C=Length	1xU,1xI=Shortest Side	
D=Damper Thickness	Connector Fold Notch=Use Default	
E=Damper Clearance	Vee Notch Depth=Auto	
F=Damper Center Diameter	Vee Notch Angle=30.000	
G=Damper Angle	Connector Fold Notch=Use Default	
H=Damper Inset	Vee Notch Depth=Auto	
I=Handle Width	Vee Notch Angle=30.000	
J=Handle Depth	Oversize Check=Yes	
K=Handle Length	Beading=No	Seams
	Damper Type=Angled	S1=None
	Damper Direction=Vertical	
	Handle Type=Manual	
	Handle Side=Top	
		Damper:

Rectangular



Dims	Options	Conn's
A=Left Width	Wrap Parts=1	C1=None
B=Middle Width	Inner Wrap Length Adjust=0.000	C2=None
C=Right Width	Outer Wrap Length Adjust=0.000	
D=Depth	Vee Depth Male=Auto	
E=Height	Vee Depth Female=Auto	
F=Left Height	Vee Angle Male=30	
G=Right Height	Vee Angle Female=30	
- •	Combine Cheeks And Wrapper=No	


Damper:

S1=None S2=None S3=None

Seams

Pattern: 1136 Rectangular/Ductboard

Dims Options Conn's A=Width B=Depth Input=Angle C1=None C=Height D=Angle E=Extension F=Depth




S2=None

Seams

Damper:

S1=None

Rectangular/Ductboard




Dims	Options	Conn's
A=Btm Width	Input=Angle	C1=None
B=Depth		
C=Top Width		
D=Height		
E=Angle		
F=Extension		
G=Depth		

Seams S1=None S2=None

Damper:


Pattern: 1139

Rectangular



Dims	Options	Conn's
A=Top Width	Vee Depth Male=Auto	C1=None
B=Depth	Vee Depth Female=Auto	C2=None
C=Left Width	Vee Angle Male=30	C3=None
D=Btm Width	Vee Angle Female=30	
E=Top Extension	· ·	
F=Left Extension		
G=Bottom Extension		
H=Hole Diameter		
I=Hole Inset		
J=Hole Offset		
		Seams
		S1=None
		S2=None

Damper:




courtesy of Applied Software 4/18/2016 107

Rectangular





Dims	Options	Conn's
A=Top Width	Vee Depth Male=Auto	C1=None
B=Depth	Vee Depth Female=Auto	C2=None
C=Left Width	Vee Angle Male=30	C3=None
D=Right Width	Vee Angle Female=30	
E=Btm Width		
F=Top Extension		
G=Left Extension		
H=Right Extension		
I=Bottom Extension		
J=Hole Diameter		
K=Hole Inset		Seams
L=Hole Offset		S1=None
		S2=None

Damper:




Pattern: 1143
Rectangular/Standard






Dims	Options	Conn's
A=Left	Top Folds=2	C1=None
B=Depth	Bottom Folds=1	
C=Top Extension #1	Left Folds=1	
D=Top Fold Angle #1	Right Folds=1	
E=Top Extension #2	Attach=	
F=Top Fold Angle #2	Attacher Side=Left and Right	
G=Bottom Extension #1	Attacher Extension=Front	
H=Bottom Fold Angle #1		
I=Left Extension #1		
J=Left Fold Angle #1		
K=Right Extension #1		Seams
L=Right Fold Angle #1		
M=Attach #1		
N=Attach #2		
O=Attach #3		
P=Inset		Damper:
Q=Bend Radius		
R=Right		
S=Angle		

Rectangular/Ductboard





Dims	Options	Conn's
A=Top Width	3 Part Wrap=No	C1=None
B=Btm Width	Connector Allowance=4 Sides	
C=Top Height		
D=Bottom Height		
E=Length		
F=Offset		

Seams S1=None S2=None

Damper:

Pattern: 1146

Rectangular



Dims	Options	Conn's
A=Width In	Frame=Yes	C1=None
B=Depth	Vee Depth Male=0.400	C2=None
C=Width Out	Vee Angle Male=30.000	C3=None
D=Angle Out	Vee Depth Female=0.400	
E=Length #1	Vee Angle Female=30.000	
F=Length #2	Seam Angle=45.000	
G=Slope Angle		
H=Bottom Extension		
I=Extension Out		
J=Frame Width		
K=Frame Depth		Seams
L=Frame Radius		S1=None
M=Frame Mitre		

Damper:

Rectangular




Dims	Options	Conn's
A=Width In	Frame=Yes	C1=None
B=Depth	Vee Depth Male=0.400	C2=None
C=Width Out	Vee Angle Male=30.000	C3=None
D=Angle Out	Vee Depth Female=0.400	
E=Length #1	Vee Angle Female=30.000	
F=Length #2	Seam Angle=45.000	
G=Slope Angle		
H=Bottom Extension		
I=Extension Out		
J=Frame Width		
K=Frame Depth		Seams
L=Frame Radius		S1=None
M=Frame Mitre		

Damper:


Pattern: 1148

Rectangular



Dims	Opt	ions	Conn's
A=Width In	2 Parts=No	Fixing Holes on Tur	C1=None
B=Depth In	3 Parts=No	Seam Cut Back=0.0	C2=None
C=Width Out	Vee Depth Male=A		
D=Depth Out	Vee Depth Female=		
E=Length	Vee Notch Angle=2		
F=Extension In	Taper Notch If Strai		
G=Extension Out	Female Allow=Shor		
H=Offset Width	2-Sided Part Allowa		
I=Offset Depth	Offset Width=Left In		
J=Angle	Offset Depth=Botto		
K=Extension In	Taper Notch If Strai		Seams
L=Extension Out	Use Taper Notch F		S1=None
	Connector Fold Not		
	Vee Notch Depth=		
	Vee Notch Angle=3		
	Input=Length		Damper:
	Vee Notch Depth If		
	Maximum Angle=1		
	Splitter Turnover=0		
	Splitter Extension=		
	Splitter Adjust=0.000		
	Connector Fold Not		
	Vee Notch Depth=		
	Vee Notch Angle=3		
	Splitter Hole Diame		
	Number Of Holes=		
	Splitters=Half		
	Hole Inset=0.000		

Rectangular



Dims	Options	Conn's
A=Width	Vee Depth Male=0.400	C1=None
B=Depth	Vee Angle Male=30.000	C2=None
C=Height	Vee Depth Female=0.400	
D=Open Height	Vee Angle Female=30.000	
E=Flashing Width	Lid Dims=Actual	
F=Flashing Depth	Show Lid=On Top	
G=Edge Front		
H=Edge Down		
I=Lid Width		
J=Lid Top Depth		
K=Lid Bottom Depth		Seams
L=Lid Height		S1=None

Damper:

Conn's

C1=None

C2=None

C3=None


Pattern: 1153 Rectangular/Ductboard



D=Left Depth	
E=Right Width Out	
F=Right Depth	
G=Left Height	
H=Right Height	
I=Left Straight	
J=Right Straight	
K=Left Length	Seams
L=Right Length	S1=None
M=Btm Left Extension	S2=None
N=Btm Right Extension	
O=Left Extension	
P=Right Extension	Damper:
Q=Left Offset Width	bumper.
R=Left Offset Depth	
S=Right Offset Width	
T=Right Offset Depth	

Options

2 Part Wrapper=No



4/18/2016 courtesy of software 111

Dims


A=Btm Width

B=Btm Depth

C=Left Width Out


Rectangular/Ductboard






Dims	Options	Conn's
A=Btm Width	2 Part Wrapper=No	C1=None
B=Btm Depth		C2=None
C=Left Width In		C3=None
D=Left Width Out		
E=Left Depth		
F=Right Width In		
G=Right Width Out		
H=Right Depth		
I=Left Height		
J=Mid Height		
K=Right Height		Seams
L=Left Straight		S1=None
M=Right Straight		S2=None
N=Left Length		
O=Right Length		
P=Btm Left Extension		Damper:
Q=Btm Right Extension		54pc
R=Left Extension		
S=Right Extension		
T=Left Offset Width		
U=Left Offset Depth		
V=Right Offset Width		
W=Right Offset Depth		
X=Left Angle		
Y=Right Angle		

Pattern: 1155 Rectangular/Ductboard



Dims	Options	Conn's
A=Btm Width	Heel=Square	C1=None
B=Btm Depth	2 Part Wrapper=No	C2=None
C=Right Width Out		C3=None
D=Right Depth		
E=Right Height		
F=Right Straight		
G=Right Length		
H=Btm Left Extension		
I=Btm Right Extension		
J=Right Extension		
K=Right Offset Width		Seams
L=Right Offset Depth		S1=None
		S2=None

Damper:



4/18/2016 courtesy of Applied software. 112

Rectangular


Di	ims	Options	Conn's
A=Width	B=Height	Lines Input=Spacing	C1=None
C=X Spacing	D=Y Spacing	X Visible (0.0 to 1.0)=0.250	
		Y Visible (0.0 to 1.0)=0.250	
		Internal Lines=No	

Seams

Damper:

Pattern: 1166

Rectangular



Dims	Options	Conn's
A=Btm Width	Type=Normal	C1=None
B=Btm Depth	Angled Ends=No	C2=None
C=Right Width	Wrap Parts=1	
D=Right Depth	Vee Depth Male=Auto	
E=Bottom Length	Vee Depth Female=Auto	
F=Right Length	Vee Angle Male=30	
G=Bottom Extension	Vee Angle Female=30	
H=Right Extension	Rotation=None	
I=Bottom Offset	Direction=C1 In C2 Out	
J=Right Offset		
		Seams
		S1=None


Damper:

Rectangular




Dims	Options	Conn's
A=Btm Width	Type=Normal	C1=None
B=Btm Depth	Sides Same=Yes	C2=None
C=Left Width	Angled Ends=No	C3=None
D=Left Depth	Wrap Parts=1	
E=Right Width	Vee Depth Male=Auto	
F=Right Depth	Vee Depth Female=Auto	
G=Bottom Length	Vee Angle Male=30	
H=Right Length	Vee Angle Female=30	
I=Bottom Extension	Cheeks 2 Parts=No	
I=Right Extension		
K=Bottom Offset		Seams
L=Right Offset		S1=None
M=Right Mid Angle		

Damper:




Pattern: 1171

Rectangular



Dims	Options	Conn's
A=Left Width	Input=Angle And Inner & Right Lengths	C1=None
B=Depth	Type=Straight	C2=None
C=Right Width	Vee Depth Male=0.400	
D=Inner Length	Vee Angle Male=30.000	
E=Outer Length	Vee Depth Female=0.400	
F=Left Length	Vee Angle Female=30.000	
G=Right Length		
H=Left Extension		
I=Right Extension		
J=Total Angle		
		Seams
		S1=None



Damper:


4/18/2016 courtesy of Applied software 114

Rectangular




Dims	Options	Conn's
A=Left Width	Input=Angle And Inner & Right Lengths	C1=None
B=Depth	Type=Radius	C2=None
C=Right Width	Vee Depth Male=0.400	
D=Inner Length	Vee Angle Male=30.000	
E=Outer Length	Vee Depth Female=0.400	
F=Left Length	Vee Angle Female=30.000	
G=Right Length	-	
H=Left Extension		
I=Right Extension		
J=Total Angle		
		Seams
		S1=None

Damper:




Pattern: 1178
Rectangular/Ductboard



Dims	Options	Conn's
A=Width In	2 Parts=No	C1=None
B=Depth In	3 Parts=No	C2=None
C=Width Out	Vee Depth Male=Auto	
D=Depth Out	Vee Depth Female=Auto	
E=Length	Vee Notch Angle=20.000	
F=Extension In	Taper Notch If Straight Edge (Female)=No	
G=Extension Out	Female Allow=Shortest Slope	
H=Offset Width	2-Sided Part Allowance=Auto	
I=Offset Depth	Offset Width=Left In	
J=Angle	Offset Depth=Bottom Up	
K=Extension In	Taper Notch If Straight Edge (Male)=No	Seams
L=Extension Out	Use Taper Notch For 2 Parts=Yes	S1=None
	Connector Fold Notch=Use Default	
	Vee Notch Depth=Auto	
	Vee Notch Angle=30.000	
	Input=Length	Damper:
	Vee Notch Depth If Straight Edge (Female)	24
	Maximum Angle=180.000	
	Splitter Turnover=0.000	
	Splitter Extension=0.000	
	Splitter Adjust=0.000	
	Connector Fold Notch=Use Default	
	Vee Notch Depth=Auto	
	Vee Notch Angle=30.000	
	Splitter Hole Diameter=0.000	
	Number Of Holes=0.000	
	Splitters=Half	
	Hole Inset=0.000	

4/18/2016 courtesy of Applied software 115

Rectangular



Dims	Options	Conn's
A=Btm Width	Same Widths=Yes	C1=None
B=Btm Depth	Right Throat=Radius	C2=None
C=Btm Left Width	Vee Depth Male=Auto	C3=None
D=Btm Right Width	Vee Depth Female=Auto	
E=Right Width	Vee Angle Male=30	
F=Right Depth	Vee Angle Female=30	
G=Top Width	Seam Top Arcs=No	
H=Top Depth	Cheeks Seam=Male	
=Top Length #1	Junction Seam Cutback (Up)=0.000	
I=Top Length #2		
K=Bottom Extension		Seams
L=Right Extension		S1=None
M=Top Extension		S2=None
N=Right Offset		
O=Top Offset		
P=Right Radius		Damper:
Q=Top Radius		Damper.

Pattern: 1180

Rectangular





Dims	Options	Conn's
A=Width	Input=Number Of Lines	C1=None
B=Height	Lines=10.000	
C=Inner Radius		
D=Angle		
E=Flange		

Seams

Damper:

Rectangular






	Dims	Options	Conn's
A=Width C=Height	B=Depth D=Radius	Develop Parts=2 Vee Depth Male=0.400 Vee Depth Female=0.400 Vee Angle Male=30 Vee Angle Female=30	C1=None

Seams S1=None S2=None

Damper:

Pattern: 1190 Rectangular/Round





Dims	Options	Conn's
A=Width	Diameter Type=Nominal	C1=None
B=Depth	Round Parts=1	C2=None
C=Diameter	Rect Parts=1	
D=Btm Left Ext	Body Cross Break=1	
E=Btm Right Ext	Body Length Break=1	
F=Top Upper Extension	Seam Position=Width	
G=Top Lower Extension	Marker Type=Notch	
H=Inner Length #1	Inlet=1	
I=Inner Length #2	Outlet=2	
J=Offset Depth		
K=Angle		Seams
		S1=None
		S2=None

Damper:

courtesy of 4/18/2016 117

Rectangular/Standard/Equipment



Options	Conn's
Symmetrical=Yes	C1=None
	C2=None

Seams

Damper:

Pattern: 1193 Rectangular/Ductboard



D	ims	Options	Conn's
A=Length	B=Width #1		C1=None
C=Depth #1	D=Width #2		C2=None
E=Depth #2	F=Width #3		
G=Depth #3	H=Width #4		
I=Depth #4	J=Width #5		
K=Depth #5			
·			

Seams S1=None

Damper:

Rectangular/Standard/Equipment



Dims	Options	Conn's
A=Width	Detail=Low	C1=None
B=Height		C2=None
C=Length		
D=Mid Width		
E=Mid Inset		
F=Mid Offset		
G=End Width		
H=End Height		
I=Thickness		
J=Radius		
K=Curve (0.0-1.0)		Seams

Damper:

Pattern: 1196


Rectangular



Dims	Options	Conn's
A=Top Width	Type=A	C1=None
B=Top Height	Draw Connectors=Yes	C2=None
C=Bottom Width	Notch Corners=Yes	C3=None
D=Bottom Height	Develop Ends=No	
E=Radius		
F=Angle		

Seams S1=None S2=None

Damper:




4/18/2016 courtesy of Applied software 119

Rectangular/Standard/Equipment



Dims	Options	Conn's
A=Width	Profile=Rectangular	C1=None
B=Depth	Pipework=No	C2=None
C=Bearer Extn	Drop Rod Diameter=0.400	C3=None
D=Left Angle	Bearer Width=2.000	
E=Right Angle	Bearer Thickness=0.400	
F=Right Rod Extn Above	Oversized Item=No	
G=Left Rod Extn Above	Area of Influence=0.000	
H=Rod Extn Below	A of I: Filled Circle=No	
I=Length A	A of I: Circle Thickness=0.100	
J=Length B	Export=All	
K=Supported Width	Export Rod Size=Yes	Seams
L=Supported Depth	Front Seismic Rod=No	
M=Right Rod Offset	Back Seismic Rod=No	
N=Left Rod Offset	Left Seismic Rod=No	
	Right Seismic Rod=No	
	Front Seismic Rod=No	Damper:
	Back Seismic Rod=No	24
	Left Seismic Rod=No	
	Right Seismic Rod=No	
	Use Support Settings=Yes	
	Point Load A=0.000	
	Point Load B=0.000	

Pattern: 1241 Rectangular/Standard/Equipment



Dims	Options	Conn's
A=Width	Profile=Rectangular	C1=None
B=Depth	Bearer Width=2.000	C2=None
C=Top Length	Bearer Thickness=0.400	C3=None
D=Bearer Extn	Area of Influence=0.000	
E=Length A	A of I: Filled Circle=No	
F=Length B	A of I: Circle Thickness=0.100	
G=Supported Width	Export=All	
H=Supported Depth	Export Rod Size=Yes	
	Use Support Settings=Yes	
	Point Load A=0.000	
	Point Load B=0.000	Seams

Damper:


Rectangular/Standard/Equipment



Dims	Options	Conn's
A=Width	Profile=Rectangular	C1=None
B=Depth	Number Of Round Sections=Auto	C2=None
C=Bearer Extn	Drop Rod Diameter=0.400	C3=None
D=Right Rod Extn Above	Bearer Thickness=0.000	
E=Left Rod Extn Above	Hex End=Yes	
F=Rod Extn Below	Roller Rod Diameter=0.600	
G=Length A	Area of Influence=0.000	
H=Length B	A of I: Filled Circle=No	
I=Supported Width	A of I: Circle Thickness=0.100	
J=Supported Depth	Export=All	
	Export Rod Size=Yes	Seams
	Use Support Settings=Yes	
	Point Load A=0.000	
	Point Load B=0.000	

Damper:


Pattern: 1250 Rectangular/Standard/Equipment




Dims	Options	Conn's
A=Width	Profile=Rectangular	C1=None
B=Depth	Bearer Width=2.000	C2=None
C=Top Length	Bearer Thickness=0.400	C3=None
D=Bearer Extn	Area of Influence=0.000	
E=Bottom Extension	A of I: Filled Circle=No	
F=Length A	A of I: Circle Thickness=0.100	
G=Length B	Straps=Both	
H=Supported Width	Export=All	
I=Supported Depth	Export Rod Size=Yes	
	Use Support Settings=Yes	
	Point Load A=0.000	Seams
	Point Load B=0.000	

Damper:

Rectangular/Standard





	Dims	Options	Conn's
A=Width	B=Depth	Straight Type=1 Part Straight	C1=None
C=Length		Female Allow=Shortest Side	C2=None
		1xU,1xI=Shortest Side	C3=None
		Connector Fold Notch=Use Default	C4=None
		Vee Notch Depth=Auto	C5=None
		Vee Notch Angle=30.000	C6=None
		Connector Fold Notch=Use Default	
		Vee Notch Depth=Auto	
		Vee Notch Angle=30.000	
		Beading=No	
		Vertical=No	Seams
		Adjust=0.000	S1=None
		Right Offset=6.000	
		Left Offset=6.000	
		Insulation UI=Shortest Side	
			Damper:

Pattern: 4522 Rectangular/Equipment



Dims	Options	Conn's
A=Width	Sex Type=Male	C1=None
B=Depth	Type=Auto	C2=None
C=Length	Open Top/Sides=No	
D=Extension	Pattern=None	
E=Right Extension		
F=Wire X Spacing		
G=Wire Y Spacing		
. •		

Seams

Damper: