# **Avalanche Pro 3000**

1. Ir	itroduction	4
	1.1. About the Avalanche Pro 3000	4
	1.2. Package Contents	4
	1.3. Important Safety Information	4
	1.4. Product Registration	4
	1.5. Contact Information	5
2. S	afety Precautions	
	General Safety Guidelines	
	Avalanche Specific Safety Guidelines	
	Beacon Safety Guidelines	
	Shovel Safety Guidelines	
	Probe Safety Guidelines	
	Battery Safety Guidelines	
3. A	ssembly and Setup	
	3.1 Unboxing	
	3.2 Charging	8
	3.3 Beacon Setup	8
	3.4 Shovel and Probe Assembly	8
	3.5 Backpack Adjustment	8
	3.6 Self-Test	8
	3.7 Ready for Use	8
4. U	sing the Beacon	0
	4.1 Activating the Beacon	0
	4.2 Locating the Beacon Signal	0
	4.3 Testing the Beacon	0
	4.4 Maintaining the Beacon	0
	4.5 Using the Beacon in an Emergency	10
5. U	sing the Shovel	11
	5.1 Assembling the Shovel	
	5.2 Using the Shovel	11
	5.3 Storing the Shovel	11
6. U	sing the Probe	
	6.1 Preparing the Probe	
	6.2 Locating the Buried Victim	12
	6.3 Confirming the Victim's Location	12

	6.4 Returning the Probe to its Compact Form
	6.5 Maintenance and Storage of the Probe
7. ľ	Maintenance and Care
	7.1 General Maintenance
	7.2 Beacon Maintenance
	7.3 Shovel and Probe Maintenance
	7.4 Storage
	7.5 Battery Replacement
	7.6 Inspection and Testing
	7.7 Repairs
8. Tı	Froubleshooting
	8.1 Avalanche Beacon Not Turning On
	8.2 Shovel Handle Loosening
	8.3 Probe Not Deploying Smoothly
	8.4 LED Indicator Not Functioning
	8.5 General Malfunction

#### 1. Introduction

Welcome to the user manual for the Avalanche Pro 3000, the ultimate snow gear for backcountry safety. This manual will guide you through the features and operation of the Avalanche Pro 3000, ensuring you have the knowledge to stay safe and prepared during your outdoor adventures. Please read this manual carefully before using the Avalanche Pro 3000 to make the most of its potential and ensure your safety.

#### 1.1. About the Avalanche Pro 3000

The Avalanche Pro 3000 is a high-tech snow gear designed to keep you safe in the event of an avalanche. It features a built-in beacon, shovel, and probe, allowing for quick and efficient rescue operations in case of an emergency. The Avalanche Pro 3000 is essential for backcountry enthusiasts who prioritize safety during their adventures.

#### 1.2. Package Contents

When you receive your Avalanche Pro 3000, please ensure that the package includes the following items:

- Avalanche Pro 3000 transceiver
- Shovel
- Probe
- User Manual

It is important to check the contents of the package upon receipt to ensure that all necessary components are included. If any items are missing, please contact our customer support for assistance.

# 1.3. Important Safety Information

Before using the Avalanche Pro 3000, it is crucial to familiarize yourself with its operation and safety features. This manual provides important safety information and guidelines for using the Avalanche Pro 3000 in a backcountry environment. Please pay close attention to all safety warnings and recommendations to ensure a safe and enjoyable experience with the product.

# 1.4. Product Registration

To ensure that you receive important product updates and information, we recommend registering your Avalanche Pro 3000 with PowderPeak. By registering your product, you will also have access to our customer support for any questions or assistance you may need. To register your product, please visit our website and complete the registration process.

#### 1.5. Contact Information

If you have any questions, concerns, or require assistance with your Avalanche Pro 3000, please do not hesitate to contact our customer support team. We are here to assist you and ensure that you have a safe and enjoyable experience with our product.

# 2. Safety Precautions

#### **General Safety Guidelines**

- Always ensure that the Avalanche Pro 3000 is properly charged and in good working condition before heading out into the backcountry.
- Familiarize yourself with the operation of the beacon, shovel, and probe before use.
- Never use the Avalanche Pro 3000 if any of its components are damaged or malfunctioning.

#### **Avalanche Specific Safety Guidelines**

- When venturing into avalanche-prone areas, always travel with a partner and ensure both parties are equipped with functioning Avalanche Pro 3000 units.
- Stay updated on avalanche forecasts and avoid high-risk areas when the danger level is elevated.
- In the event of an avalanche, follow standard avalanche safety procedures and use the Avalanche Pro 3000 for rescue operations.

# **Beacon Safety Guidelines**

- When using the beacon function, ensure that it is set to the correct mode for the situation (search or transmit).
- Practice using the beacon in various scenarios to familiarize yourself with its operation.

# **Shovel Safety Guidelines**

- When using the shovel, ensure that the handle is securely attached to the blade and that it is locked in place before use.
- Use caution when digging in avalanche debris to avoid injury to yourself or others.

# **Probe Safety Guidelines**

- Handle the probe with care to avoid bending or breaking the sections.
- When conducting a search with the probe, use a systematic approach to cover the search area thoroughly.

# **Battery Safety Guidelines**

- Only use the specified rechargeable batteries for the Avalanche Pro 3000.
- Do not attempt to disassemble or modify the battery pack in any way.

# 3. Assembly and Setup

#### 3.1 Unboxing

When you receive your Avalanche Pro 3000, ensure that all components are included in the package. The box should contain the Avalanche Pro 3000 backpack, beacon, shovel, and probe. Carefully inspect each item for any damage that may have occurred during shipping.

# 3.2 Charging

Before your first use, ensure that the Avalanche Pro 3000 is fully charged. Use the provided USB cable to connect the backpack to a power source. The charging indicator light will turn green once the battery is fully charged, which may take up to 4 hours.

#### 3.3 Beacon Setup

To power on the beacon, press and hold the power button located on the front of the backpack for 3 seconds. The beacon will emit a series of beeps and the LED display will indicate that it is active. The beacon should be worn at all times in a front-facing position.

# 3.4 Shovel and Probe Assembly

The shovel handle can be connected to the blade by aligning the grooves and twisting it clockwise until it locks in place. The probe should be extended to its full length and locked in position using the locking mechanism located on the probe shaft.

# 3.5 Backpack Adjustment

Before heading out into the backcountry, adjust the straps on the Avalanche Pro 3000 to ensure a comfortable and secure fit. The shoulder straps, waist belt, and chest strap can be adjusted to accommodate your body size and gear load.

#### 3.6 Self-Test

Perform a self-test of the Avalanche Pro 3000 by following the instructions in the user manual. This will ensure that all components are functioning properly before each use.

# 3.7 Ready for Use

Once the Avalanche Pro 3000 is fully assembled and all components have been tested, you are ready for your backcountry adventure. Always remember to check the battery levels and perform a beacon range test before venturing into avalanche terrain.

# 4. Using the Beacon

The Avalanche Pro 3000 is equipped with a state-of-the-art beacon to help guide rescuers to your location in the event of an avalanche. The beacon is a crucial tool for backcountry safety and should be used and maintained with care.

# 4.1 Activating the Beacon

To activate the beacon, locate the power switch on the front of the device. Slide the switch to the ON position, indicated by the green symbol. The device will emit a series of audio and visual signals to indicate that it is operational. Ensure that the beacon is securely attached to your clothing or gear before venturing into the backcountry.

# 4.2 Locating the Beacon Signal

In the event of an avalanche, the beacon can be used to transmit a signal to rescuers. To activate the signal, press and hold the red distress button located on the top of the beacon. The beacon will emit a strong signal that can be picked up by search and rescue teams equipped with compatible receivers.

# 4.3 Testing the Beacon

Regularly test the beacon to ensure that it is functioning properly. The Avalanche Pro 3000 beacon features a built-in self-test function that can be activated by pressing the test button on the side of the device. Follow the manufacturer's instructions for conducting a self-test and ensure that the beacon passes the test before each backcountry excursion.

# 4.4 Maintaining the Beacon

To maintain the beacon, keep it clean and free from debris. Avoid exposing the beacon to extreme temperatures or moisture, as this can affect its performance. Check the battery indicator regularly to ensure that the beacon is equipped with a fully charged battery before each use. Replace the battery as needed according to the manufacturer's instructions.

# 4.5 Using the Beacon in an Emergency

In the event of an avalanche, activate the distress signal on the beacon and keep it accessible at all times. If buried in snow, the beacon's signal can help rescuers locate and dig out the victim more quickly and efficiently.

# 5. Using the Shovel

The Avalanche Pro 3000 comes with a high-quality, durable shovel that is designed for efficient snow removal during rescue operations. The shovel is an essential tool for digging out a buried person in an avalanche, so it is important to be familiar with its features and how to use it effectively.

#### 5.1 Assembling the Shovel

To assemble the shovel, follow these simple steps:

- 1. Locate the shovel handle, which is color-coded in red for easy identification.
- 2. Slide the handle into the shaft of the shovel until it clicks into place.
- 3. Make sure the handle is securely attached to the shaft before use.

#### 5.2 Using the Shovel

When using the Avalanche Pro 3000 shovel for snow removal, follow these guidelines:

- 1. Grip the handle firmly with both hands, positioning them at the appropriate hand grip markings for optimal leverage.
- 2. Push the shovel blade into the snow at a slight angle to maximize the amount of snow you can move with each scoop.
- 3. Lift the snow and throw it to the side, clearing a path to access the buried person.

# 5.3 Storing the Shovel

After use, it is important to properly store the shovel to maintain its performance and prolong its lifespan. Follow these steps for storing the shovel:

- 1. Clean the shovel blade to remove any dirt or snow residue.
- 2. Collapse the shaft and handle, ensuring a compact and secure fit for storage.
- 3. Store the collapsed shovel in the designated compartment of the Avalanche Pro 3000 backpack for easy access during future use.

By following these simple instructions for using and storing the shovel, you can ensure that it is always ready for quick and efficient snow removal during rescue operations.

# 6. Using the Probe

The Avalanche Pro 3000 comes equipped with a high-quality probe for locating buried victims in case of an avalanche. Follow the steps below to correctly use the probe during a rescue operation.

#### 6.1 Preparing the Probe

Before using the probe, ensure that it is fully extended by pulling the sections apart until they are locked into place. The probe will click when each section is fully extended.

# 6.2 Locating the Buried Victim

To use the probe, hold it firmly with both hands and start probing the snow in a systematic pattern. Begin probing at the last seen point of the victim and move diagonally across the avalanche path. The probe should be pushed vertically into the snow, ensuring it penetrates the full depth.

#### 6.3 Confirming the Victim's Location

Once the probe hits an object, leave it in place and mark the spot with a marker flag. Continue probing the area in a spiral pattern to confirm the victim's location. Once the victim's position is confirmed, leave the probe in place to assist the rescue team in pinpointing the victim's location.

# 6.4 Returning the Probe to its Compact Form

After the rescue operation, collapse the probe by unscrewing the bottom section and carefully folding each section back together. Ensure that all sections are securely locked in place to prevent any accidental extension during storage.

# 6.5 Maintenance and Storage of the Probe

After each use, inspect the probe for any damage, such as bent or broken sections. If any damage is found, contact PowderPeak customer service for assistance. Store the probe in a dry place at room temperature, and avoid exposing it to extreme heat or cold.

#### 7. Maintenance and Care

#### 7.1 General Maintenance

To ensure the optimal performance of your PowderPeak Avalanche Pro 3000, it is important to perform regular maintenance. After each use, thoroughly clean the shovel and probe and inspect for any damage. Store the beacon in a dry and cool place to avoid moisture damage.

#### 7.2 Beacon Maintenance

The built-in beacon in the Avalanche Pro 3000 requires regular testing to ensure proper functionality. Perform a beacon self-check according to the instructions provided in the user manual before each trip into the backcountry. Replace the batteries annually, even if they appear to have remaining charge. Refer to the user manual for specific instructions on how to replace the batteries.

#### 7.3 Shovel and Probe Maintenance

The shovel and probe included in the Avalanche Pro 3000 are essential tools in the event of an avalanche. After each use, clean off any snow and inspect for any signs of damage. Pay special attention to the locking mechanisms and handles to ensure they are in proper working condition. Grease any moving parts as necessary to maintain smooth operation.

# 7.4 Storage

When not in use, store the Avalanche Pro 3000 in a dry and cool environment. Ensure that the beacon is turned off to conserve battery life. Store the shovel and probe in their designated compartments to prevent damage or loss. Avoid exposing the gear to extreme temperatures or direct sunlight for prolonged periods.

# 7.5 Battery Replacement

The Avalanche Pro 3000 beacon operates on a lithium battery. When the battery needs replacement, use only the recommended battery type specified in the user manual. Follow the instructions provided for battery replacement to ensure proper installation and functionality of the beacon.

# 7.6 Inspection and Testing

Regularly inspect all components of the Avalanche Pro 3000 for signs of wear or damage. Test the beacon, shovel, and probe according to the guidelines provided in the user manual. As part of your pre-trip preparation, perform a complete inspection of the gear to verify that it is in proper working condition.

#### 7.7 Repairs

In the event that any part of the Avalanche Pro 3000 requires repair, contact an authorized service center for assistance. Attempting to repair or modify the gear yourself may compromise its performance and safety features. Always follow the recommendations and instructions provided by PowderPeak for repairs and servicing.

# 8. Troubleshooting

#### 8.1 Avalanche Beacon Not Turning On

If the Avalanche Pro 3000 beacon is not turning on, please follow these steps to troubleshoot the issue:

- 1. Check the battery compartment to ensure the batteries are properly installed.
- 2. Make sure the battery terminals are clean and free from corrosion.
- 3. If the issue persists, replace the batteries with new ones, ensuring they are inserted in the correct polarity.

#### 8.2 Shovel Handle Loosening

If the handle of the shovel on your Avalanche Pro 3000 becomes loose, follow these steps to resolve the issue:

- 1. Use a screwdriver to tighten the screws connecting the handle to the shovel blade.
- 2. Ensure the screws are tightened securely to prevent the handle from loosening during use.

# 8.3 Probe Not Deploying Smoothly

If the probe on your Avalanche Pro 3000 is not deploying smoothly, please try the following troubleshooting steps:

- 1. Ensure the locking mechanism is fully disengaged before attempting to deploy the probe.
- 2. Clean any dirt or debris from the probe sections to ensure smooth deployment.
- 3. If the issue persists, apply a small amount of lubricant to the probe sections to facilitate smooth deployment.

# 8.4 LED Indicator Not Functioning

If the LED indicator on your Avalanche Pro 3000 is not functioning properly, follow these steps to troubleshoot the issue:

- 1. Check the battery compartment to ensure the batteries are properly installed.
- 2. If the batteries are correctly installed, replace them with new ones to see if this resolves the issue.

3. If the LED indicator still does not work, contact customer support for further assistance.

#### 8.5 General Malfunction

If your Avalanche Pro 3000 experiences a general malfunction not covered by the previous troubleshooting steps, please contact PowderPeak customer support for assistance.